Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- MCombo /
- MCombo Power Lift Recliner Chair R7096/6160-7095Fabric User Manual

MCombo 6160-7095Fabric

MCombo Power Lift Recliner Chair R7096/6160-7095Fabric User Manual

Model: 6160-7095Fabric

INTRODUCTION

This manual provides essential information for the safe and efficient operation, assembly, and maintenance of your MCombo Power Lift Recliner Chair. Please read it thoroughly before use and retain it for future reference.

The MCombo Power Lift Recliner Chair is designed to provide comfort and assistance, featuring a power lift mechanism, heat, and massage functions, along with convenient built-in features.

SAFETY INFORMATION

- Consult your doctor before use if you have any health concerns.
- Keep the product away from children and pets to prevent accidental injury or damage.
- Ensure all electrical connections are secure and properly grounded. Do not use if cords are damaged.
- Do not allow liquids to spill on electrical components or controls.
- · Avoid placing heavy objects on the chair or its moving parts.
- Do not attempt to disassemble or repair the chair yourself. Contact customer support for assistance.
- Ensure there is adequate clearance around the chair during operation to prevent obstruction or pinching.
- Maximum weight recommendation: 350 Pounds. Do not exceed this limit.

ASSEMBLY INSTRUCTIONS

The MCombo Power Lift Recliner Chair is designed for easy assembly, typically taking about 20 minutes for a novice with no tools required. It arrives in multiple boxes for easier handling.

Steps:

- 1. Unpack all components from the boxes. Ensure all parts (armrests, backrest, accessories box, manual, base) are present.
- 2. Position the chair base in the desired location.

- 3. Attach the armrests to the chair base.
- 4. Connect the backrest to the chair base and armrests.
- 5. Plug in all necessary wiring connections as indicated in the included manual.
- 6. Connect the power cord to a suitable electrical outlet.

Refer to the detailed assembly diagrams in the physical user manual for visual guidance.

OPERATING INSTRUCTIONS

Power Lift Assistance

The chair features a counter-balanced lift mechanism with a TUV certified actuator to assist users in standing up or sitting down easily, reducing stress on the back and knees.

- To stand up: Use the remote control to gently raise the chair. The chair will tilt forward, lifting you to a standing position.
- To sit down: Use the remote control to lower the chair. It will slowly tilt back and down, allowing you to sit comfortably.



Image: Remote control for the MCombo Power Lift Recliner, highlighting the simple two-button operation for lift and recline functions.

Reclining Functions

The chair offers multiple reclining positions, up to 150 degrees, for various activities such as TV viewing, reading, or napping.

- TV Viewing Position: Use the remote to adjust the footrest and backrest to a comfortable upright or slightly reclined position suitable for watching television.
- **Full Recline Position:** For deep relaxation or sleeping, use the remote to fully recline the backrest and extend the footrest to a 150-degree angle.



Image: The MCombo Power Lift Recliner shown in its maximum 150-degree recline position, ideal for extended relaxation.

Heat and Massage Functions

The chair includes lumbar heating and full-body vibration massage for enhanced comfort.

- Massage: The chair features 8 vibration nodes with 5 massage modes and 2 intensity levels. Use the dedicated massage remote to select your preferred settings.
- **Heat:** A lumbar heating zone provides warmth. The heating function operates independently of the vibration massage.
- Both heat and massage functions include 10/20/30 minute auto-off timers for safety and convenience.

Lumbar Heating Massage

Heating function works separately from vibration.



- **8** Vibration Nodes
- 3 Massage Modes
- **3** Intensity Levels



Lumbar Heat





Image: The MCombo Power Lift Recliner with an overlay indicating the 8 vibration points and lumbar heating area, alongside the remote control for these features.

Convenience Features

- **USB Charging Port:** A built-in USB charging port allows you to power your devices without leaving your seat.
- Cup Holders: Integrated cup holders keep beverages within easy reach.
- Pockets: Side and front pockets provide storage for remotes, magazines, or other small items.
- Armrest Loop: An armrest loop securely holds the remote to prevent drops.




Image: A detailed view of the MCombo Power Lift Recliner's convenience features, including USB and Type-C ports, cup holders, and side pockets.

Product Videos

Your browser does not support the video tag.

Video: An official MCombo video demonstrating the features and comfort of the Power Lift Recliner R7092, including its lift mechanism and overall design.

Your browser does not support the video tag.

Video: An official MCombo video showcasing the Power Lift Recliner 7095 series, highlighting its various functionalities and design elements.

MAINTENANCE

- **Cleaning:** Spot clean the fabric as needed. Use a mild detergent and a damp cloth. Avoid harsh chemicals that may damage the fabric.
- Inspection: Regularly inspect all electrical cords and connections for any signs of wear or damage.
- Moving the Chair: If moving the chair, ensure it is in the fully upright, non-reclined position. Disconnect power before moving.

• **General Care:** Keep the chair away from direct sunlight and heat sources to prevent fading or material degradation.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair does not operate.	Power cord unplugged, circuit breaker tripped, remote control issue.	Check power connection, reset circuit breaker, ensure remote batteries (if applicable) are functional or remote is properly connected.
Chair movement is jerky or slow.	Obstruction in mechanism, low power, worn components.	Check for obstructions under or around the chair. Ensure stable power supply. If problem persists, contact support.
Heat/Massage not working.	Remote issue, connection problem.	Ensure the massage/heat remote is properly connected and functional. Check for any loose wires.

If you encounter issues not listed here or if solutions do not resolve the problem, please contact MCombo customer support.

SPECIFICATIONS

• Brand: MCombo

• Model Name: 6160-7095Fabric

Color: Dark GreySize: Medium-Wide

• **Product Dimensions:** 38.2"D x 41.7"W x 43.7"H

Seat Length: 27.2 Inches
Seat Depth: 21 inches
Seat Height: 19.1 Inches

• Seat Back Interior Height: 27.6 Inches

• Arm Height: 26 Inches

• Maximum Weight Recommendation: 350 Pounds

• Material: Fabric (OEKO-TEX Standard 100 certified), Foam (CertiPUR-US certified)

• **Special Features:** Power Lift Assistance, Lumbar Heat, Full-Body Vibration Massage, USB Charging Port, Cup Holders, Side Pockets.

• Reclining Position Count: Multiple (up to 150 degrees)

• Item Weight: 146 pounds



Image: Detailed dimensions of the MCombo Power Lift Recliner in various positions (upright, TV, reclined).

WARRANTY AND SUPPORT

Your MCombo Power Lift Recliner Chair is backed by a **2-Year Limited Warranty**. This warranty covers free replacements for the following components:

- · Reclining/Lifting Mechanisms
- · Electrical Systems
- Upholstery & Cushions
- Wood/Metal Frame Structures

For warranty claims, technical support, or any questions regarding your product, please contact MCombo customer service. Refer to the contact information provided with your purchase or visit the official MCombo website.

© 2025 MCombo. All rights reserved.

