

Jpbaisqic ECOVACS DEEBOT X1 Omni

Jpbaisqic Replacement Parts Instruction Manual

For ECOVACS Deebot X1 Omni, X1 TURBO, X1 Plus Robot Vacuum Cleaners

INTRODUCTION

This manual provides essential information for the installation, maintenance, and optimal use of Jpbaisqic replacement parts designed for ECOVACS Deebot X1 series robot vacuum cleaners. Regular replacement of these components ensures your vacuum operates at peak performance, maintaining a clean and healthy environment.

COMPATIBILITY

These replacement parts are fully compatible with the following ECOVACS Deebot robot vacuum cleaner models:

- ECOVACS DEEBOT X1 Omni
- ECOVACS DEEBOT X1 TURBO
- ECOVACS DEEBOT X1 Plus

PACKAGE CONTENTS

The replacement kit includes the following components:

- 1 x Main Brush
- 6 x Side Brushes
- 3 x HEPA Filters
- 4 x Mop Cloths
- 3 x Dust Bags

INSTALLATION GUIDE

All replacement parts are designed for easy installation without the need for special tools. Refer to your ECOVACS Deebot user manual for specific instructions on accessing the component compartments.

1. Main Brush Installation

To replace the main brush, open the brush cover on the underside of your robot vacuum. Remove the old main brush and insert the new one, ensuring it clicks securely into place. Close the brush cover.




Image: Main brush made of high-quality rubber and soft bristles for effective cleaning.




Image: Detailed view of the main brush showing its construction and flexible edges.

2. Side Brush Installation

The side brushes can be easily removed and installed by gently pulling them off or pushing them onto their designated posts on the underside of the vacuum. Ensure the brushes are firmly attached.




Image: Side brushes designed for efficient sweeping of debris from edges and corners.

3. HEPA Filter Installation

Locate the dustbin on your robot vacuum. Open the dustbin and remove the old HEPA filter. Insert the new filter, ensuring it is seated correctly to maintain proper air filtration. Close the dustbin.




Image: High-efficiency HEPA filter designed to capture dust and small particles.

4. Mop Pad Installation

Attach the mop pads to the designated mop plate on your robot vacuum. These pads typically use a hook-and-loop fastening system for easy attachment and removal.




Image: Washable mop pads made of microfiber for effective cleaning of smooth floors.

5. Dust Bag Installation

Open the dust collection compartment on your vacuum's auto-empty station. Remove the full dust bag and insert a new one, ensuring it is properly sealed within the compartment.




Image: Effective filtration vacuum dust bags with a two-layer design and self-sealing feature.

MAINTENANCE AND REPLACEMENT SCHEDULE

To ensure your ECOVACS Deebot maintains optimal cleaning performance, it is recommended to replace the components according to the following guidelines. Actual replacement frequency may vary based on usage and environment.

- **General Recommendation:** Replace the entire kit every 3-6 months.
- **Main Brush:** Inspect regularly for wear and tangles. Replace as needed, typically every 6-12 months.
- **Side Brushes:** Check for bending or damage. Replace every 3-6 months. These brushes are washable and reusable.
- **HEPA Filters:** Clean regularly by tapping out dust. Replace every 2-3 months to maintain filtration efficiency.
- **Mop Cloths:** Wash after each use. Replace every 1-3 months depending on wear. These mop cloths are washable and reusable.
- **Dust Bags:** Replace when full. Typically lasts 6-8 weeks depending on cleaning frequency and debris volume.



Image: Mop pad submerged in water, illustrating its washable and reusable nature.

TROUBLESHOOTING

If you experience issues after replacing parts, consider the following:

- **Reduced Cleaning Performance:** Ensure all brushes are free of tangles and debris. Verify that the HEPA filter is clean and correctly installed.
- **Unusual Noise:** Check that the main brush and side brushes are properly seated and not obstructed.
- **Poor Suction:** Confirm the dust bag is correctly installed and not full. Ensure the HEPA filter is clean.
- **Mop Not Cleaning Effectively:** Ensure mop pads are clean and properly attached.

For further troubleshooting, refer to your ECOVACS Deebot robot vacuum's official user manual or contact ECOVACS customer support.

SPECIFICATIONS

Component	Material / Feature	Quantity
Main Brush	High-quality rubber and soft bristles	1
Side Brushes	Durable nylon, washable and reusable	6
HEPA Filters	High-efficiency filtration material	3
Mop Cloths	Microfiber, highly absorbent, washable and reusable	4
Dust Bags	2-layer non-woven fabric, self-sealing design	3

Item Dimensions (L x W x H): 5.2 x 2 x 8 inches

Item Weight: 0.3 Kilograms (10.5 ounces)

Manufacturer: JIN PENG

WARRANTY AND SUPPORT

Specific warranty information for these replacement parts is not provided in the product details. For any product-related inquiries or support, please contact the seller directly through your purchase platform.