

[Manuals.plus](#) /

› [warmiplanet](#) /

› warmiplanet Flush Mount Ceiling Fan User Manual

warmiplanet WICF06-3

warmiplanet Flush Mount Ceiling Fan User Manual

Model: WICF06-3
Brand: warmiplanet

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your warmiplanet 52-Inch Flush Mount Ceiling Fan with Lights and Remote Control. Designed for indoor use, this fan features a quiet DC motor, dimmable LED lighting with adjustable color temperature, and a multi-function remote for convenient control. Please read this manual thoroughly before installation and use to ensure safe and efficient operation.

2. IMPORTANT SAFETY INFORMATION

Always disconnect power at the main circuit breaker before installing, cleaning, or servicing the fan. Ensure all electrical connections comply with local codes and ordinances. If you are unfamiliar with electrical wiring, consult a qualified electrician. The fan must be mounted to a ceiling joist or support structure capable of supporting the fan's weight (15.84 lbs). Do not bend the blade holders during installation or cleaning. Ensure all screws are tightened securely. Do not operate the fan if any part is damaged.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning installation.

- Ceiling Fan Motor Assembly
- Fan Blades (3)
- LED Light Kit
- Remote Control

- Mounting Bracket
- Hardware Bag (screws, washers, wire nuts)
- User Manual



Figure 3.1: Overview of the warmiplanet Flush Mount Ceiling Fan, including the fan unit, remote control, and reversible blades.

4. PRODUCT SPECIFICATIONS

Feature	Specification
Brand	warmiplanet
Model Name	WICF06-3
Color	Antique Nickel
Material	Metal, Glass
Style	3 Blades
Light Fixture Form	Close to Ceiling

Feature	Specification
Room Type	Indoor
Product Dimensions	52"L x 52"W x 11.3"H
Power Source	DC
Installation Type	Flush Mount
Special Feature	Dimmable
Control Method	Remote
Light Source Type	LED
Wattage	28 watts (LED Light: 22 watts)
Voltage	120 Volts
Item Weight	15.84 Pounds
Number of Blades	3
Air Flow Capacity	2268 Cubic Feet Per Minute
Batteries Required	2 AAA batteries (included)

Multi-functional Remote Control



Timer Setting

Easy-to-use Timer Option







 6 Wind Speeds	 3 Color Temperature & Dimmable	 Natural Breezes	 Reversible Function
---	--	---	---

Figure 4.1: Detailed product dimensions, indicating a 52-inch span and 11.3-inch height from the ceiling, suitable for various room sizes.

5. INSTALLATION GUIDE

Follow these steps for proper installation. It is recommended to have assistance during certain steps, especially when handling the fan motor.

5.1. Pre-Installation

- Turn off power at the circuit breaker.
- Ensure the mounting location can support the fan's weight.
- Unpack all components and verify against the package contents list.

5.2. Install the Mounting Bracket

Secure the mounting bracket to the ceiling junction box using the provided machine screws. If installing on a wooden ceiling, use wood screws. Ensure the bracket is firmly attached.

Quiet Operation

Equipped with high quality and quiet DC motor



Figure 5.1: The fan's quiet operation, ideal for bedrooms, with noise levels around 30dB, comparable to a whisper.

5.3. Hang the Motor and Wire Connections

Carefully hang the fan motor assembly onto the J-hook of the mounting bracket. Connect the power live wire (black), neutral wire (white), and ground wire (green) from the ceiling to the corresponding wires on the fan using wire nuts. Ensure all connections are secure.

Space-Saving Designed for Low Floors



Figure 5.2: The fan's space-saving flush mount design, with a total height of only 11.3 inches, making it suitable for rooms with lower ceilings.

5.4. Install the Fan Blades

Attach each fan blade to the motor assembly using the provided screws and washers. Tighten all screws firmly to prevent shaking during operation.

5.5. Install the Light Source

Connect the wires of the LED light source to the corresponding wires on the fan motor. Secure the light source to the fan using the designated screws. Ensure the light plate is aligned and tightened.



Figure 5.3: The fan's versatile lighting options, offering three color temperatures (3000K, 4000K, 6000K) and dimmable brightness from 10% to 100%.

5.6. Final Assembly

Rotate the light shade until it is securely fastened to the fan. Once all components are installed, restore power at the circuit breaker.

5.7. Installation Video

For a visual guide, please refer to the official installation video:

Your browser does not support the video tag.

Video 5.1: Official warmiplanet 52 inch ceiling fan installation video. This video provides a step-by-step visual guide for the complete installation process.

6. OPERATING INSTRUCTIONS

Your warmiplanet ceiling fan is controlled by a multi-function remote control. Ensure the remote has 2 AAA batteries installed.

6.1. Remote Control Functions

Suitable for All Seasons



Figure 6.1: The multi-functional remote control, providing comprehensive control over fan speeds, light settings, and timer functions.

- **Power On/Off:** Press the power button to turn the fan and light on or off.
- **Fan Speed:** Select from 6 available speeds (1-6) to adjust airflow.
- **Light Control:**
 - Press the light button to cycle through 3 color temperatures: Cool White (6000K), Natural Light (4000K), and Warm White (3000K).
 - Hold the light button to dim the light from 10% to 100%. The light has a memory function and will retain

the last setting.

- **Timer Function:** Set the fan to turn off automatically after 1 hour or 4 hours.
- **Natural Breeze Mode:** Activates a fluctuating fan speed to simulate a natural breeze.

6.2. Reversible Function (Seasonal Use)

The fan features a reversible DC motor for year-round comfort. A small switch on the motor housing allows you to change the blade direction.

- **Summer Mode (Counter-Clockwise Updraft):** Blades rotate counter-clockwise, pushing air downwards to create a cooling breeze.
- **Winter Mode (Clockwise Downdraft):** Blades rotate clockwise, drawing air upwards to circulate warm air trapped near the ceiling.

Product Dimension



Figure 6.2: Illustration of the fan's reversible function, optimizing air circulation for both cooling in summer and warming in winter.

6.3. Product Demonstration Videos

View these videos for a demonstration of the fan's features and operation:

Your browser does not support the video tag.

Video 6.1: Warmiplanet 52 inch ceiling fan showing video. This video demonstrates the fan's operation, including light adjustment and motor reversal.

Your browser does not support the video tag.

Video 6.2: 52inch Ceiling Fan with Lights and Remote Product Show. This video highlights various features of the fan, including its lighting and remote control capabilities.

7. MAINTENANCE

Regular maintenance helps prolong the life and performance of your ceiling fan.

- **Cleaning:** Use a soft, damp cloth to clean the fan blades and motor housing. Do not use abrasive cleaners or solvents.
- **Blade Balance:** Check fan blades periodically for any wobbling. If wobbling occurs, ensure all blade screws are tight. A balancing kit (not included) may be used if necessary.
- **Light Source:** The LED light source is designed for long life and is replaceable. Contact customer support for replacement parts if needed.

8. TROUBLESHOOTING

If you experience issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause & Solution
Fan does not start	<ul style="list-style-type: none">◦ Check circuit breaker and wall switch.◦ Ensure all wire connections are secure.◦ Verify remote control batteries are installed correctly and charged.
Light does not work	<ul style="list-style-type: none">◦ Check light wire connections.◦ Ensure the light is not dimmed to its lowest setting.◦ If the LED light went out after extended use, it may need replacement. Contact customer support.
Fan wobbles	<ul style="list-style-type: none">◦ Ensure all blade screws are tightened.◦ Check that the mounting bracket is securely fastened to the ceiling.◦ Verify blades are not bent or damaged.
Humming noise from fan	<ul style="list-style-type: none">◦ Ensure all screws are tight, especially on the mounting bracket and motor housing.◦ Verify that the fan is not touching any part of the ceiling or surrounding objects.◦ Some DC motors may produce a minimal hum, which is generally normal. If excessive, contact customer support.

Problem	Possible Cause & Solution
Remote control not responding	<ul style="list-style-type: none">◦ Replace remote control batteries.◦ Ensure there are no obstructions between the remote and the fan receiver.◦ Re-pair the remote with the fan if necessary (refer to specific pairing instructions in the full manual, if available).

9. WARRANTY AND CUSTOMER SUPPORT

warmiplanet stands behind the quality of its products.

- **Motor Warranty:** 10-year warranty for the DC motor.
- **Other Parts Warranty:** 2-year warranty for all other fan components.
- **Customer Support:** We offer 24-hour customer support. If you have any questions, concerns, or require assistance with installation or troubleshooting, please feel free to contact us. We aim to reply within 24 hours and provide the best possible service.

Contact information can typically be found on the product packaging or the official warmiplanet website.