

[Manuals.plus](#) /

> [Olakids](#) /

> Olakids Kids Ride-On Excavator (Model TQ10168YW) Instruction Manual

Olakids TQ10168YW

Olakids Kids Ride-On Excavator Instruction Manual

Model: TQ10168YW

IMPORTANT SAFETY INFORMATION

Read all instructions before assembly and use of the Olakids Kids Ride-On Excavator. Failure to follow these safety instructions may result in serious injury.

- Adult assembly required.
- Adult supervision is required at all times when the product is in use.
- Recommended for children aged 3 years and older.
- Maximum weight capacity: 77 lbs (35 kg).
- Ensure all fasteners are securely tightened before each use. Periodically check for loose parts.
- Do not use near stairs, hills, roadways, or swimming pools.
- Always wear appropriate safety gear, such as a helmet, when operating the ride-on toy.
- Operate only on flat, level surfaces. Avoid uneven terrain, steep inclines, or slippery surfaces.
- Keep hands, feet, and clothing away from moving parts.
- This product is designed for outdoor use.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly.

- 1 x Ride-on Excavator
- 1 x Detachable Cargo Trailer
- 1 x Shovel
- 1 x Rake
- 1 x Instruction Manual
- Necessary assembly hardware (screws, nuts, etc.)

SETUP AND ASSEMBLY

Assembly of the Olakids Kids Ride-On Excavator requires adult supervision and tools. Follow the steps below for proper assembly.

Assembly Video Guide

Your browser does not support the video tag.

This video demonstrates the assembly process for the Olakids Kids Ride-On Excavator. It shows how to connect various parts, including the main body, wheels, steering wheel, and excavator arm, providing a visual guide for installation.

Step-by-Step Assembly

- 1. Attach the Front Axle:** Secure the front axle to the main body of the excavator using the provided fasteners. Ensure it is firmly attached to allow for steering.
- 2. Install the Wheels:** Mount the wheels onto the axles. Ensure all wheels are securely fastened with the appropriate caps or nuts to prevent them from coming off during use.
- 3. Connect the Steering Column and Steering Wheel:** Insert the steering column into the designated opening and attach the steering wheel. Ensure the horn button is functional if applicable.
- 4. Assemble the Excavator Arm and Bucket:** Attach the excavator arm to the front of the vehicle. Connect the bucket to the arm, ensuring the control lever mechanism is correctly aligned for proper operation (flipping, lifting, lowering).
- 5. Attach the Seat:** Secure the seat to the main body.
- 6. Connect the Pedal Mechanism:** Ensure the foot pedals are correctly linked to the drive mechanism for forward and backward movement.
- 7. Attach the Detachable Trailer:** Connect the trailer hitch to the rear of the excavator. The trailer should attach and detach easily.
- 8. Final Check:** Before first use, inspect all connections, screws, and moving parts to ensure they are secure and functioning correctly.



Image: A child happily operating the Olakids Ride-On Excavator with its detachable trailer in a park filled with autumn leaves.

OPERATING INSTRUCTIONS

This section details how to operate your Olakids Kids Ride-On Excavator safely and effectively.

Basic Operation

- **Pedal Movement:** The excavator is pedal-powered. Push the pedals forward to move forward and backward to reverse.
- **Steering:** Use the steering wheel to control the direction of the front wheels.
- **Horn:** Press the button on the steering wheel to activate the horn.



Foot Pedal



Air Horn



Steering Wheel



Comfortable Seat

Image: Detailed views of the foot pedal for propulsion, the air horn on the steering wheel, the steering wheel itself, and the comfortable seat designed for children.

Excavator Bucket Control

The front bucket is manually controlled using a gear lever.

- **Lifting and Lowering:** Use the control handle to raise and lower the front bucket.
- **Flipping/Tilting:** The bucket can be flipped or tilted to dump its contents. Operate the control handle to achieve this action.

Easy to Control



Image: An illustration demonstrating the manual control of the excavator's front bucket, showing its ability to flip, raise, and lower using the side control handle.

Using the Detachable Trailer

The included trailer can be attached to the rear of the excavator to transport small items.

- **Attachment:** Align the trailer hitch with the connection point at the rear of the excavator and secure it.
- **Detachment:** Unlatch the trailer from the excavator when not needed.
- **Capacity:** The trailer is designed to carry lightweight items such as toys, sand, or small garden tools. Do not overload.

Detachable Trailer

Shovel & Rake Included

Toy Organizer



Image: A detailed view of the detachable trailer, highlighting its capacity as a toy organizer and showing the included shovel and rake.

MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your ride-on excavator.

- **Cleaning:** Wipe the vehicle with a damp cloth to remove dirt and dust. Avoid using harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check all screws, nuts, and bolts for tightness. Tighten any loose fasteners.
- **Moving Parts:** Ensure the steering mechanism, pedals, and excavator arm move freely and are not obstructed.
- **Storage:** Store the excavator in a dry place, away from direct sunlight and extreme temperatures, to prevent material degradation.
- **Wheels:** Inspect wheels for wear and tear. The wear-resistant wheels are designed for various surfaces like asphalt, cement, brick, and wood roads.



Wear-resistant Wheels



Asphalt road



Cement floor



Brick road



Wood road

Image: A visual representation of the durable, wear-resistant wheels and the types of terrain suitable for operation, including asphalt, cement, brick, and wood surfaces.

TROUBLESHOOTING

If you encounter issues with your Olakids Kids Ride-On Excavator, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Vehicle does not move when pedaled.	Pedal mechanism disconnected or jammed.	Check the connection between the pedals and the drive wheels. Clear any obstructions.
Steering is difficult or unresponsive.	Steering column loose or obstructed.	Inspect the steering column for proper connection and ensure no debris is blocking movement. Tighten any loose bolts.
Excavator bucket does not move smoothly.	Control handle mechanism stiff or obstructed.	Check the control handle and bucket pivot points for obstructions. Ensure all connections are secure.

Problem	Possible Cause	Solution
Wheels wobble or fall off.	Wheel fasteners are loose or missing.	Immediately stop use. Re-attach wheels and securely tighten all fasteners. Refer to assembly instructions.

SPECIFICATIONS

Feature	Detail
Model Number	TQ10168YW
Brand	Olakids
Overall Dimensions (L x W x H)	66.5" x 16" x 20" (169 cm x 41 cm x 50 cm)
Net Weight	17.8 lbs (8.07 kg)
Weight Capacity	77 lbs (35 kg)
Material	PP (Polypropylene), Steel
Recommended Age	3+ Years Old (36-96 months)
Operation Mode	Manual (Pedal-powered)
Included Accessories	Detachable Trailer, Shovel, Rake
Assembly Required	Yes
Indoor/Outdoor Usage	Outdoor

Product Dimension



Image: A detailed diagram illustrating the dimensions of the ride-on excavator and its trailer, including length, width, height, and individual component measurements, along with the maximum weight capacity.

WARRANTY AND SUPPORT

Olakids products are manufactured with quality and safety in mind. For specific warranty details, please refer to the warranty card included with your purchase or contact Olakids customer service.

If you have any questions, require assistance with assembly, or need replacement parts, please contact Olakids customer support through their official website or the retailer where the product was purchased. Please have your model number (TQ10168YW) and purchase date available when contacting support.