



[Manuals.plus](#) /

> [MASXODRK](#) /

> Electric Scooter Adults with Seat,28/34 MPH Top Speed,34/50 Miles Range,800W/1600W/2500W Motor E-Scooter,11" Off-Road Tires,Double Braking Systems,Foldable Kick Scooter M5 PRO

MASXODRK M5 Pro

MASXODRK M5 Pro Electric Scooter User Manual

Model: M5 Pro | Brand: MASXODRK

INTRODUCTION

This user manual provides essential information for the safe and efficient operation, assembly, and maintenance of your MASXODRK M5 Pro Electric Scooter. Please read this manual thoroughly before first use and retain it for future reference.



The MASXODRK M5 Pro Electric Scooter, designed for powerful and comfortable rides.

SAFETY INFORMATION

Your safety is paramount. Always wear a helmet and appropriate protective gear when riding. Adhere to local traffic laws and regulations. Avoid riding in adverse weather conditions or on slippery surfaces. This product has passed stringent UL 2272 testing for safety.

- Always wear a helmet and protective gear.
- Familiarize yourself with local traffic laws.
- Do not ride under the influence of alcohol or drugs.
- Ensure all components are securely fastened before each ride.
- Avoid sudden braking or sharp turns at high speeds.

SETUP AND ASSEMBLY

The MASXODRK M5 Pro Electric Scooter comes 85% pre-assembled. The following steps detail the final assembly required before your first ride.

1. Unboxing and Component Check

Carefully remove all components from the packaging. Verify that all parts listed in the included components section are present and undamaged. Refer to the included manual for a complete list of parts.

Your browser does not support the video tag.

Video demonstrating the unboxing and initial assembly process for the M5 Pro Electric Scooter.



Image showing the electric scooter and its included accessories: charger, head bag, keys, seat, tools, and specification manual.

2. Handlebar Installation

Attach the handlebar to the main stem. Ensure all cables are properly connected and secured. Use the provided tools to tighten the screws firmly.

360° Full Light Design



Close-up view of the handlebar and front light assembly, highlighting the connections.

3. Seat Installation

Install the seat onto the designated mounting point on the scooter's deck. Adjust the seat height for comfortable riding. Secure the seat firmly with the provided fasteners.



DETACHABLE STORAGE BOX WITH KEY

SUITABLE FOR STORING DAILY SMALL ITEMS SUCH AS MINERAL WATER, KEYS, BOOKS, ETC

Image illustrating the enlarged inflatable saddle, designed for maximum comfort and support.

4. Storage Box Installation (Optional)

If your model includes a detachable storage box, attach it to the rear rack using the provided hardware. Ensure it is securely mounted and locked with the key.



Image showing the detachable storage box with key, suitable for small items like water bottles, keys, or a wallet.

OPERATING INSTRUCTIONS

1. Power On/Off

To power on the scooter, press and hold the power button on the display for a few seconds until the screen illuminates. To power off, press and hold the power button again until the display turns off.

2. Speed MPH Setting

The scooter features adjustable speed settings. Refer to the display and controls to cycle through available speed modes (e.g., 10 MPH, 20 MPH, 34 MPH). Always select a speed appropriate for your environment and skill level.

Your browser does not support the video tag.

Video tutorial on how to adjust the speed settings (MPH) on the scooter's display.



Image illustrating the three speed modes (10 MPH, 20 MPH, 34 MPH) and the scooter's ability to conquer various terrains.

3. Lift Speed Limit

To lift the speed limit, follow the instructions provided in the video. This feature allows the scooter to reach its maximum potential speed. Ensure you are in a safe and legal environment before utilizing this function.

Your browser does not support the video tag.

Video guide on how to lift the speed limit of the electric scooter.

4. Smart LCD Display

The scooter is equipped with a smart LCD display that provides real-time information including speed, battery level, distance traveled, light status, and cruise control activation.



Image of the smart LCD display showing speed, battery, distance, light, and cruise control indicators.

5. Folding Design

The M5 Pro features a 3-second foldable design for easy storage and transport. Locate the folding mechanism on the stem and follow the instructions to fold or unfold the scooter. Ensure the mechanism is securely locked before riding.

3 SECOND FOLDABLE DESIGN



Weight
80 LBS



Max Load
330 LBS



SUBWAY



BUS




TRUNK



Image demonstrating the compact folded size of the scooter, suitable for transport in subways, buses, or car trunks.

FEATURES OVERVIEW

The MASXODRK M5 Pro Electric Scooter is engineered with advanced features for performance, safety, and comfort.



Powerful 1600W Motor

Experience instant acceleration and a top speed of 34 MPH with a robust 1600W motor, effortlessly tackling hills and zipping through city streets. It also boasts a 30° climbing angle capability.



Long-Range 48V 20.8AH Battery

Power through up to 50 miles of thrilling rides with a high-performance battery, making your electric scooter the perfect companion for extended adventures and daily commutes. The battery is UL 2272 certified and features intelligent charging protection mechanisms including over-discharge, over-current, short circuit, over-heat, and balancing protection.



Rugged 11" Off-Road Tires & Dual Suspension

Equipped with durable 11" front and 10" rear off-road tires, this electric scooter ensures stability and traction on a wide range of surfaces, from smooth pavement to rough terrain. The dual shock absorption system, including front hydraulic damping and rear linkage suspension, provides a comfortable ride.



Double Braking Systems

Enhanced safety with front and rear brakes for reliable stopping power. Features include anti-slip, dual oil brake, E-ABS, waterproof brakes, and high-temperature resistance.



Bright LED Lighting for Visibility

Illuminate your path and enhance your visibility day or night with bright U7 front headlights and rear brake lights, ensuring you stay safe and seen on your electric scooter adventures. Includes turn signals for added safety.



Wide Non-Slip Deck

The 9.45-inch wide non-slip deck provides greater comfort and stability for your feet during rides.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your electric scooter.

- **Battery Care:** Charge the battery regularly, even when not in use, to maintain its health. Avoid fully draining the battery.
- **Tire Pressure:** Check tire pressure before each ride. Maintain recommended PSI for optimal performance and safety.
- **Cleaning:** Use a damp cloth to clean the scooter. Do not use high-pressure water jets or immerse the scooter in water.
- **Brake Inspection:** Regularly inspect brake levers, cables, and pads for wear and proper function. Adjust or replace as needed.
- **Fasteners:** Periodically check and tighten all screws and bolts to ensure they are secure.

TROUBLESHOOTING

If you encounter any issues with your MASXODRK M5 Pro Electric Scooter, please refer to the following common troubleshooting tips. For more complex problems, contact customer support.

Problem	Possible Cause	Solution
Scooter does not power on.	Low battery; loose connections.	Charge the battery; check all cable connections.
Reduced range or speed.	Low tire pressure; heavy load; uphill riding; cold weather.	Inflate tires to recommended PSI; reduce load; ride on flat terrain; battery performance may be reduced in cold.
Brakes feel loose or ineffective.	Brake cable needs adjustment; worn brake pads.	Adjust brake cable tension; replace worn brake pads.

SPECIFICATIONS

Feature	Detail
Brand	MASXODRK
Model Name	M5 Pro
Motor Power	1600W
Top Speed	34 MPH

Feature	Detail
Battery	48V 20.8AH Lithium Battery
Max Range	Up to 50 Miles
Tire Size	11 Inches (Front), 10 Inches (Rear) Off-Road Tires
Weight Limit	265 Pounds
Suspension Type	Dual Suspension (Front Hydraulic Damping, Rear Linkage)
Brake Style	Full Brake (Front & Rear)
Foldable	Yes
Included Components	Electric scooter, Scooter Bag, Manual, Charger, Tool

WARRANTY AND SUPPORT

MASXODRK offers a full warranty for your electric scooter. Scooter accessories with quality problems are eligible for one year free replacement parts, including the battery, motor, charger, controller, and voltage lock. For any issues or inquiries, please contact our customer service team via Amazon email. Our team is available 7 days a week, 24 hours a day, to provide professional after-sales service and support.

Your satisfaction is our top priority. We are committed to keeping you rolling hassle-free.



MASXODRK is committed to providing excellent after-sales service and technical support.