

Genesis 80GMB

Genesis 80GMB Nutrimax 2200W Blender Instruction Manual

Model: 80GMB | Brand: Genesis

1. INTRODUCTION AND IMPORTANT SAFEGUARDS

Thank you for choosing the Genesis 80GMB Nutrimax 2200W Blender. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new appliance. Please read all instructions carefully before first use and retain this manual for future reference.

Important Safety Instructions

- Read all instructions before operating the blender.
- Do not immerse the motor base in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Keep hands and utensils out of container while blending to reduce the risk of severe injury to persons or damage to the blender. A scraper may be used but only when the blender is not running.
- Blades are sharp. Handle with care.
- Always operate the blender with the lid in place.
- Do not blend hot liquids in the main jar without proper ventilation, as pressure buildup can cause

scalding.

2. PRODUCT OVERVIEW AND COMPONENTS

Familiarize yourself with the parts of your Genesis 80GMB Nutrimax Blender to ensure correct assembly and operation.



Figure 2.1: The complete Genesis 80GMB Nutrimax Blender, featuring its motor base, blending jar filled with fruits and ice, and the control panel. The design highlights its robust construction and readiness for use.



Figure 2.2: This image details essential parts of the blender. It shows the removable stainless steel blade assembly, the tamper for pushing ingredients, the intuitive control panel with various settings, and a graphic emphasizing the powerful 3 horsepower motor capable of 45,000 RPM.

Main Components:

1. **Motor Base:** Contains the powerful 2200W motor and control panel.
2. **Blending Jar:** A 2-liter capacity container for ingredients.
3. **Lid:** Secures the jar during operation and prevents spills.
4. **Tamper:** Used to push ingredients towards the blades for smoother blending.
5. **Blade Assembly:** Stainless steel blades designed for efficient blending and crushing.




Figure 2.3: This image presents a collection of recipe booklets, likely included with the blender, offering various 'NutriBoost' recipes such as Mood Improvement, Detox, Hormone Balance, Diabetes, and Energy Boosting. These provide inspiration for healthy blends.

3. SETUP AND FIRST USE

Unpacking

- Carefully remove all components from the packaging.
- Retain packaging materials for future storage or transport if needed.
- Check that all parts listed in the 'Product Overview' section are present and undamaged.

Cleaning Before First Use

Before using your blender for the first time, wash all parts that will come into contact with food:

1. Detach the blade assembly from the blending jar.
2. Wash the blending jar, lid, and blade assembly in warm, soapy water.
3. Rinse thoroughly and dry all parts.
4. Wipe the motor base with a damp cloth. Do not immerse the motor base in water.

Assembly

1. Ensure the motor base is placed on a stable, flat, and dry surface.

2. Securely attach the blade assembly to the bottom of the blending jar.
3. Place the assembled blending jar onto the motor base, ensuring it is seated correctly and locked into position (if applicable).
4. Plug the power cord into a suitable electrical outlet.

4. OPERATING INSTRUCTIONS

Your Genesis 80GMB Nutrimax Blender is designed for efficient blending of various ingredients. Always ensure the blender is properly assembled and the lid is secured before operation.



Figure 4.1: The Genesis 80GMB Blender in operation, actively blending a yellow liquid, suggesting its use for soups or smoothies. A cut squash is visible in the foreground, indicating the type of ingredients it can process.

Basic Blending Steps

1. **Prepare Ingredients:** Cut ingredients into appropriate sizes. For best results, add liquids first, then soft ingredients, followed by hard ingredients and ice. Do not overfill the jar beyond the maximum fill line.
2. **Secure Lid:** Place the lid firmly onto the blending jar. Ensure the lid is properly sealed.

3. **Select Setting:** Use the control panel to select your desired blending function.
4. **Start Blending:** Press the appropriate button to begin.
5. **Monitor:** Observe the blending process. If ingredients are not circulating, use the tamper through the lid opening to push them towards the blades. Never remove the lid or use other utensils while the blender is running.
6. **Stop:** Once desired consistency is achieved, press the stop button or allow the program to complete.
7. **Unplug:** Always unplug the blender from the power outlet after use.

Control Panel Functions

- **Variable Speed Control:** Adjust the blending speed manually for precise control over texture.
- **Pulse Function:** Provides short bursts of power for chopping or quick blending, ideal for coarse chopping or breaking down tough ingredients.
- **Pre-programmed Settings:** Your blender features optimized settings for common tasks:
 - **Smoothies:** For perfectly smooth beverages.
 - **Soups:** Designed for blending hot or cold soups.
 - **Bisque:** For creamy, thick soups.
 - **Grind:** Suitable for grinding nuts, coffee beans, or spices.
 - **Sauce:** For creating various sauces and dressings.
 - **Ice Cream:** For making frozen desserts.

5. CARE AND MAINTENANCE

Proper cleaning and maintenance will extend the life of your Genesis 80GMB Nutrimax Blender.

Cleaning

1. **Immediate Cleaning:** For quick cleaning, fill the blending jar halfway with warm water and a drop of dish soap. Secure the lid and run the blender on a low speed or use the 'Pulse/Clean' function for 30-60 seconds. Rinse thoroughly.
2. **Deep Cleaning:** Disassemble the blending jar, lid, and blade assembly. Wash these parts in warm, soapy water. The removable blades facilitate thorough cleaning. Use a brush to clean around the blades carefully. Rinse and dry completely.
3. **Motor Base:** Wipe the motor base with a soft, damp cloth. Never immerse the motor base in water or place it under running water.
4. **Stubborn Stains:** For stubborn stains or odors, soak the jar with a mixture of baking soda and water for a few hours before washing.

Storage

Store the blender in a clean, dry place. Ensure the power cord is neatly wrapped and not kinked. Do not store the blender with the jar assembled if it is still wet.

6. TROUBLESHOOTING

If you encounter issues with your blender, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; power outlet not working; jar not correctly seated; motor overheating.	Ensure the power cord is securely plugged into a working outlet. Check if the blending jar is properly seated on the motor base. If the motor is hot, unplug and let it cool for 15-30 minutes.
Ingredients are not blending smoothly or are stuck.	Too little liquid; too many ingredients; ingredients are too large; air pocket around blades.	Add more liquid. Reduce the amount of ingredients. Cut ingredients into smaller pieces. Use the tamper to push ingredients towards the blades (only when blender is running). Use the pulse function.
Blender leaks from the bottom of the jar.	Blade assembly not tightened; seal ring missing or damaged.	Ensure the blade assembly is securely tightened to the jar. Check if the rubber seal ring is correctly in place and undamaged. Replace if necessary.
Unusual noise or odor during operation.	Overloading; foreign object in jar; motor strain.	Reduce the load of ingredients. Stop the blender immediately and check for any foreign objects. If the issue persists, discontinue use and contact customer support.

7. PRODUCT SPECIFICATIONS

Technical details for the Genesis 80GMB Nutrimax 2200W Blender:

Feature	Detail
Brand	Genesis
Model Number	80GMB
Colour	Multicolor
Capacity	2 Liters
Power / Wattage	2200 watts
Material	Stainless Steel
Special Features	Removable Blade, Variable Speed Control, Pulse Function, Pre-programmed Settings
Item Weight	4.3 kg
Product Dimensions	22D x 35W x 30H centimetres
Power Source	Corded Electric

8. WARRANTY AND CUSTOMER SUPPORT

Warranty Information





The Genesis 80GMB Nutrimax 2200W Blender comes with a **Limited Warranty**. Please refer to the warranty card included with your product for specific terms, conditions, and duration of coverage. Keep your proof of purchase for warranty claims.


Customer Support

For any questions, technical assistance, or warranty claims, please contact Genesis customer support. Contact details can typically be found on the product packaging or the official Genesis website. When contacting support, please have your model number (80GMB) and proof of purchase ready.

© 2023 Genesis. All rights reserved.

Related Documents - 80GMB

	<p>2019 Genesis G70 Owner's Manual: Operation, Maintenance, and Safety Guide</p> <p>Your essential guide to the 2019 Genesis G70. This owner's manual provides detailed information on vehicle operation, safety features, maintenance, and specifications to ensure a safe and optimal driving experience.</p>
	<p>2022 Genesis G70 Owner's Manual</p> <p>Your essential guide to the 2022 Genesis G70. This owner's manual provides detailed information on vehicle operation, safety features, maintenance schedules, and all onboard systems for the Genesis G70 (Model NG9O-EU12B).</p>
	<p>Genesis Owner's Manual: Operation, Maintenance, and Specifications for Electric Vehicle</p> <p>Comprehensive owner's manual for Genesis electric vehicles, covering operation, maintenance, safety features, charging, and specifications. Essential guide for Genesis Branded Vehicle owners.</p>
	<p>Genesis Care Plan: Terms, Conditions, and Services</p> <p>Explore the comprehensive Genesis Care Plan, covering scheduled maintenance, roadside assistance, pick-up/delivery, courtesy cars, software updates, and connected services for Genesis vehicles in the UK.</p>

<div data-bbox="118 143 309 300"><p>OWNER'S MANUAL</p><p>Operation Maintenance Specifications</p><p><small>All information in this Owner's Manual is intended to provide the owner with the necessary knowledge to operate and maintain the vehicle properly. It is not intended to replace the vehicle's operation and maintenance manual. Always read the operation and maintenance manual for the vehicle before operating the vehicle. The information in this Owner's Manual is subject to change without notice. Please refer to the vehicle's operation and maintenance manual for the most current information. Please refer to the vehicle's operation and maintenance manual for the most current information. Please refer to the vehicle's operation and maintenance manual for the most current information.</small></p></div>	<p>Genesis Owner's Manual: Your Guide to Operation, Safety, and Maintenance</p> <p>This comprehensive owner's manual provides essential guidance for Genesis vehicle owners on safe operation, maintenance, and understanding of their vehicle's features, specifications, and systems.</p>
<div data-bbox="118 412 309 748"><p>2020 GENESIS G70 GETTING STARTED GUIDE AUDIO, CONNECTIVITY, AND NAVIGATION</p><p>GENESIS</p></div>	<p>2020 Genesis G70 Getting Started Guide: Audio, Connectivity, and Navigation</p> <p>A comprehensive guide for the 2020 Genesis G70, covering essential features for audio, smartphone connectivity (Android Auto, Apple CarPlay), phone pairing, making calls via voice commands, navigation system usage, and Genesis Connected Services. Learn how to customize your driving experience and stay connected.</p>