

[manuals.plus](#) /

› [ANJANK](#) /

› [ANJANK C16 Sunrise Alarm Clock User Manual](#)

ANJANK C16

ANJANK C16 Sunrise Alarm Clock User Manual

Model: C16

INTRODUCTION

Thank you for choosing the ANJANK C16 Sunrise Alarm Clock. This device is a versatile 4-in-1 unit designed to enhance sleep and wake-up routines, especially for children. It functions as a Wake-Up Light, Sleep Trainer, Alarm Clock, and Night Light. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance and user experience.



Image: The ANJANK C16 Sunrise Alarm Clock, featuring a circular light display with a smiley face and a digital time display below.

PRODUCT FEATURES

The ANJANK C16 Sunrise Alarm Clock integrates multiple functionalities to support healthy sleep and wake cycles:

- **4-in-1 Design:** Combines a Wake-Up Light, Sleep Trainer, Alarm Clock, and Night Light.
- **Gradual Sunrise Simulation:** Light gradually brightens from 0% to 100% over a user-selected duration (0, 10, 20, 30, 40, 50, or 60 minutes) before the alarm sounds, or can be set to turn off.
- **OK to Wake Sleep Training:** Utilizes animated facial expressions and light colors to indicate sleep, ready-to-wake, and wake-up times.
- **Dual Alarms:** Two independent alarms for flexible scheduling.
- **8 Natural Sounds:** Includes Chicks Chirp, Cuckoo, Bagpipe, Piano Music, Beep, Stream, Cricket, and Electric Bell, delivered via a 5W speaker.
- **Adjustable Alarm Volume:** 30 levels of volume, gradually increasing from 0 to 95dB within 15 seconds.

- **8 Night Light Colors:** Offers Orange, Yellow, Red, Green, Cyan, Blue, Purple, and White light options.
- **30-Level Night Light Brightness:** Fine-tune the night light intensity.
- **6-Level Clock Number Brightness:** Adjust the digital display brightness, including a completely dark screen option.
- **9-Minute Snooze:** Unlimited snooze cycles, with an option to disable.
- **Battery Memory:** Retains time and settings during power interruptions.



Image: Visual representation of the clock's core functions: Sunrise Light, Alarm Clock, and Sleep Trainer.

SETUP

Package Contents

- ANJANK C16 Sunrise Alarm Clock
- Power Adapter
- User Manual

Power Connection

1. Unpack all components from the box.
2. Connect the power adapter to the DC input port located on the back of the alarm clock.
3. Plug the power adapter into a standard electrical outlet. The clock display will illuminate.

Initial Time Setting

Upon first power-up, the clock may display a default time or require setting. Refer to the 'Setting Time' section under Operating Instructions for detailed steps.

OPERATING INSTRUCTIONS

Setting Time

1. Press and hold the 'Time Set' button (usually indicated by a clock icon) for 3 seconds. The hour digits will start flashing.
2. Use the '+' or '-' buttons to adjust the hour.
3. Press the 'Time Set' button again to confirm the hour and move to minute adjustment. The minute digits will flash.
4. Use the '+' or '-' buttons to adjust the minutes.
5. Press the 'Time Set' button once more to confirm and exit time setting mode.
6. Some models may offer 12/24-hour format selection during this process. Follow on-screen prompts if available.

Setting Alarms (Alarm 1 & Alarm 2)

The clock features two independent alarms. The process is similar for both.

1. Press and hold the 'Alarm 1' or 'Alarm 2' button (usually indicated by an alarm clock icon) for 3 seconds. The alarm hour digits will flash.
2. Use the '+' or '-' buttons to set the desired alarm hour.
3. Press the 'Alarm' button again to confirm the hour and move to minute adjustment.
4. Use the '+' or '-' buttons to set the desired alarm minutes.
5. Press the 'Alarm' button again to select the wake-up sound. Use '+' or '-' to cycle through the 8 available sounds (Chicks Chirp, Cuckoo, Bagpipe, Piano Music, Beep, Stream, Cricket, Electric Bell) or select 'OFF' for silent wake-up.
6. Press the 'Alarm' button again to set the alarm volume (30 levels). Use '+' or '-' to adjust.
7. Press the 'Alarm' button again to set the sunrise simulation duration (0, 10, 20, 30, 40, 50, or 60 minutes). This determines how long the light will gradually brighten before the alarm time.
8. Press the 'Alarm' button one last time to confirm all settings and activate the alarm. An alarm icon will appear on the display.

Dual alarms and 8 melodic sounds for a fresh start



Image: The ANJANK C16 clock displaying 9:00 AM with a warm orange light, illustrating the dual alarm and melodic sound features.

Sunrise Simulation

The sunrise simulation feature gradually increases light intensity to mimic a natural sunrise, promoting a gentle wake-up. This is set during the alarm setup process, allowing you to choose a duration from 0 to 60 minutes for the light to transition from 0% to 100% brightness.

Gently rise with gradual sunrise and nature sounds



Image: The ANJANK C16 clock on a bedside table, glowing with a warm light, symbolizing a gentle rise with gradual sunrise and nature sounds.

Sleep Training (OK to Wake)

This feature uses light and facial expressions to teach children about sleep and wake times.

- **Bedtime (Red Light, "Sleepy face"):** Indicates it's time for bed.
- **Ready-to-Wake (Yellow Light):** Appears up to 30 minutes before the set wake-up time, signaling to wait patiently.
- **Wake-Up (Green Light, "Smiley face"):** Indicates it's time to wake up.

To set the sleep training times, refer to the specific instructions in your product's full manual, as button sequences may vary. Generally, you will press and hold a dedicated 'Sleep Trainer' button, then set the desired sleep and wake times using the '+' and '-' buttons.

Use light & expression to help kids get to sleep and stay asleep

Bedtime! Time to sleep!



Image: The ANJANK C16 clock illustrating its sleep training feature with a yellow light and 'Ready-to-wake' text, and a red light with a 'Sleepy face' for bedtime.

Night Light Function

The clock can function as a night light with various color and brightness options.

1. Press the 'Light' button (often indicated by a light bulb icon) to turn on the night light.
2. Press the 'Light' button repeatedly to cycle through the 8 available colors: Orange, Yellow, Red, Green, Cyan, Blue, Purple, and White.
3. To adjust brightness, use the '+' or '-' buttons when the night light is active. There are 30 levels of brightness.
4. Press and hold the 'Light' button to turn off the night light.

Colorful glow table lamp

Create a cozy vibe with 8 colors and 30 brightness levels



Image: Three ANJANK C16 clocks showcasing various colorful glow options, demonstrating the 8 colors and 30 brightness levels available for the night light.

Display Brightness

Adjust the brightness of the digital time display to your preference.

1. Locate the 'Display Brightness' button (often indicated by a sun icon).
2. Press the button repeatedly to cycle through 6 levels of brightness, including a completely dark option.

Dim the digits for desired comfort



Image: The ANJANK C16 clock with its digits dimmed, positioned next to a sleeping child, illustrating the 6-level brightness adjustment for the display.

Snooze Function

When an alarm sounds, press any button on the top of the clock (except the 'Off' button) to activate the 9-minute snooze. The alarm will sound again after 9 minutes. This can be repeated indefinitely. To disable snooze, press the 'Off' button when the alarm sounds.

MAINTENANCE

Cleaning

- Ensure the device is unplugged before cleaning.
- Wipe the exterior with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the surface.
- Avoid getting moisture into any openings.

Storage

If storing the clock for an extended period, unplug it and keep it in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock not turning on / No display	Power adapter not connected or faulty.	Ensure the power adapter is securely plugged into the clock and a working electrical outlet. Try a different outlet.
Alarm not sounding	Alarm is not activated, volume is too low, or sound is set to 'OFF'.	Verify that the alarm is set and activated (alarm icon visible). Check alarm volume and ensure a sound is selected, not 'OFF'.
Display is too bright or too dim	Display brightness setting is incorrect.	Adjust the clock number brightness using the 'Display Brightness' button (sun icon) to cycle through the 6 levels.
Sunrise simulation not working	Sunrise duration not set or set to 0 minutes.	During alarm setup, ensure a sunrise simulation duration (e.g., 30 minutes) is selected, not 0 minutes.
Sleep trainer expressions/colors incorrect	Sleep and wake times for the trainer are incorrectly set.	Re-enter the sleep trainer settings and verify the programmed sleep and wake times.

SPECIFICATIONS

Feature	Specification
Brand	ANJANK
Model Number	C16
Colour	Blue
Product Dimensions	14.99 x 3.81 x 15.49 cm
Item Weight	699 g
Special Features	Sunrise Alarm Clock, Wake Up Light, Kids Sleep Trainer, Nightlight, Adjustable Brightness
Display Type	Digital
Alarm Sounds	8 (Chicks Chirp, Cuckoo, Bagpipe, Piano Music, Beep, Stream, Cricket, Electric Bell)
Night Light Colors	8 (Orange, Yellow, Red, Green, Cyan, Blue, Purple, White)
Night Light Brightness Levels	30

Feature	Specification
Clock Display Brightness Levels	6 (including off)
Alarm Volume Levels	30
Snooze Duration	9 minutes

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact ANJANK customer service through the retailer's platform or the official brand website. Please have your model number (C16) and purchase details ready when contacting support.

© 2024 ANJANK. All rights reserved.

Related Documents - C16

 User Guide for C16 True Wireless Stereo Earphones	<p>C16 True Wireless Stereo Earphones User Guide</p> <p>User guide for C16 True Wireless Stereo Earphones, covering specifications, setup, functions, charging, maintenance, and troubleshooting.</p>
 ANJANK Clock-AC003 Manuel de l'utilisateur	<p>ANJANK Clock-AC003 User Manual: Features, Setup, and Operation</p> <p>Comprehensive user guide for the ANJANK Clock-AC003 digital alarm clock, covering setup, features like FM radio, dual alarms, USB charging, and operation.</p>
 ANJANK AC-190 Wireless Charging FM Radio Alarm Clock Instruction Manual and Warranty	<p>ANJANK AC-190 Wireless Charging FM Radio Alarm Clock: Instruction Manual and Warranty</p> <p>Comprehensive instruction manual and warranty information for the ANJANK AC-190 Wireless Charging FM Radio Alarm Clock, covering features, setup, operation, and specifications.</p>

	<p>Anjank AC209 User Manual: White Noise Machine, Bluetooth Speaker, and Alarm Clock</p> <p>Comprehensive user manual for the Anjank AC209, a versatile device featuring a white noise machine with 20 soothing sounds, a Bluetooth speaker, an alarm clock with multiple ringtones, and a 7-color night light. Includes setup instructions, features, operation guides, and FCC compliance information.</p>
	<p>ANJANK AC-196 Digital Alarm Clock Radio User Manual and Warranty</p> <p>Comprehensive user manual and warranty information for the ANJANK AC-196 digital alarm clock radio, featuring dual alarms, FM radio, sleep timer, and USB charging.</p>
	<p>ANJANK AC190BT Bluetooth Speaker Alarm Clock with Wireless Charging User Manual</p> <p>Comprehensive user manual for the ANJANK AC190BT Bluetooth Speaker Alarm Clock, detailing features, setup, operation, alarm settings, FM radio, wireless charging, and FCC compliance information.</p>

Documents - ANJANK – C16

no relevant documents