



[Manuals.plus](#) /

› [HOMEenhancements](#) /

› HOMEenhancements 52" 5-Blade Modern Cylinder Fan Instruction Manual

## HOMEenhancements PC552 NK5SV/WL(LED SELECT)

# Instruction Manual for HOMEenhancements 52" 5-Blade Modern Cylinder Fan

Model: PC552 NK5SV/WL(LED SELECT)

## INTRODUCTION

---

This manual provides detailed instructions for the installation, operation, and maintenance of your HOMEenhancements 52" 5-Blade Modern Cylinder Fan. This ceiling fan features a sleek brushed nickel finish, silver/walnut reversible blades, and a selectable 3K/4K/5K Kelvin LED light kit with pull chain control. Please read this manual thoroughly before installation and use to ensure safe and efficient operation.

## SAFETY INFORMATION

---

Always follow basic safety precautions when installing and operating electrical appliances. Failure to do so could result in personal injury or property damage.

- Ensure the power is turned off at the circuit breaker before beginning installation or performing any maintenance.
- All wiring must be in accordance with national and local electrical codes.
- The mounting structure must be capable of supporting the weight of the fan (approximately 14.7 pounds).
- Do not operate the fan with damaged blades or housing.
- Keep hands, hair, and clothing away from moving fan blades.

## WHAT'S IN THE BOX

---

Your HOMEenhancements ceiling fan package includes the following components:

- Ceiling Fan Motor Housing (Brushed Nickel Finish)
- 5 Reversible Fan Blades (Silver/Walnut Finish)
- LED Light Kit with Selectable Color Temperature
- Pull Chains for Fan Speed and Light Control
- Mounting Hardware (including screws, washers, wire nuts, and mounting bracket)

- Down Rod (6 inches included)
- Instruction Manual



Image: The complete HOMEenhancements 52-inch 5-blade modern cylinder fan in brushed nickel finish, showing the motor housing, five blades, integrated light kit, and two pull chains.

## SETUP

---

This section outlines the general steps for installing your ceiling fan. For detailed wiring and assembly instructions, please refer to the included instruction manual specific to your model.

1. **Prepare for Installation:** Turn off power at the main circuit breaker. Ensure the electrical box is securely mounted and capable of supporting the fan.
2. **Mounting Bracket Installation:** Secure the mounting bracket to the electrical outlet box using the provided screws and washers.
3. **Wiring Connections:** Connect the fan's electrical wires to the household wiring according to the wiring diagram in

your specific manual. Use the provided wire nuts to secure connections.

4. **Assemble Fan Blades:** Attach the fan blades to the blade arms, ensuring they are securely fastened. You can choose between the silver or walnut side of the reversible blades.
5. **Attach Fan to Mounting Bracket:** Carefully lift the fan motor assembly and hang it from the mounting bracket. Secure the fan to the bracket as per the manual's instructions.
6. **Install Light Kit:** Connect the light kit wiring and attach the light kit assembly to the fan motor housing.
7. **Install Light Shade:** Secure the light shade to the light kit.



Image: An illustration highlighting the ease of installation, stating "Quick and Easy Installation!", "Install the fan in minutes!", and "No experts needed!".

## OPERATING INSTRUCTIONS

---

Your HOMEenhancements ceiling fan is designed for simple operation using the integrated pull chains.

- **Fan Speed Control:** One pull chain controls the fan speed. Pull the chain repeatedly to cycle through the available

speeds (e.g., High, Medium, Low, Off).

- **Light Control:** The other pull chain controls the integrated LED light.
  - Pull the chain once to turn the light ON.
  - Pull the chain again to cycle through the three selectable color temperatures: 3000K (Warm Light), 4000K (Cool Light), and 5000K (Daylight).
  - To dim the light, hold the pull chain for a few seconds while the light is on. Release when the desired brightness is achieved.
  - Pull the chain one more time to turn the light OFF.
- **Reversible Motor Function:** A switch on the fan motor housing allows you to reverse the direction of the fan blades.
  - For warm weather (cooling effect): Set the switch to make the blades rotate counter-clockwise, creating a downward airflow.
  - For cool weather (warm air circulation): Set the switch to make the blades rotate clockwise, creating an upward airflow that helps circulate warm air.



Image: The fan's selectable color temperature feature, illustrating 3000K (Warm Light), 4000K (Cool Light), and 5000K (Daylight) settings in a living room environment.

# Reversible Motor

**Warm** in Winter, **Cool** in Summer.



Image: A visual guide to the reversible motor, showing downward airflow for "Summer: Cool, Rapid Cooling" and upward airflow for "Winter: Warm Air Circulation."

## MAINTENANCE

Regular maintenance will help prolong the life and performance of your ceiling fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the finish or electrical components.
- **Blade Cleaning:** Dust the fan blades regularly to prevent dust buildup, which can affect performance and balance.
- **Tighten Screws:** Periodically check all screws on the fan and light kit to ensure they are tight. Loose screws can cause noise or wobble.
- **No Lubrication Needed:** The fan motor is permanently lubricated and does not require oiling.

## TROUBLESHOOTING


If you experience issues with your fan, consult the following common troubleshooting steps:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Blown fuse/tripped circuit breaker.	Check power supply; Verify all wire connections are secure (ensure power is off first); Check/reset circuit breaker.
Fan wobbles	Loose blade screws; Improperly balanced blades; Loose mounting bracket.	Tighten all blade screws; Use a balancing kit (not included) if necessary; Ensure mounting bracket is securely fastened.
Light does not work	Loose wire connections in light kit; Faulty LED module.	Check light kit wiring connections; Contact customer service if LED module is suspected to be faulty.
Fan is noisy	Loose screws; Fan not properly secured; Motor hum.	Check and tighten all screws; Ensure fan is securely mounted; A slight motor hum is normal, but excessive noise may indicate an issue.

## SPECIFICATIONS

Feature	Detail
Brand	HOMEnhancements
Model Number	PC552 NK5SV/WL(LED SELECT)
Product Dimensions	52"D x 52"W x 18"H (52 x 52 x 18 inches)
Weight	14.7 Pounds
Color	Brushed Nickel
Blade Finish	Silver / Walnut (Reversible)
Number of Blades	5
Light Type	Integrated LED
Light Color Temperature	3000K, 4000K, 5000K (Selectable)
Light Wattage	15 watts
Control Type	Pull Chain
Power Source	Corded Electric
Room Type	Indoors

# Product Dimensions



Bedroom



Office



Living Room

Image: A diagram illustrating the key dimensions of the fan, including its 52-inch width, 15-inch height, and the 6-inch included down rod.

## WARRANTY AND SUPPORT

All HOMEnhancements products come with a **1-year limited warranty**. This warranty covers defects in materials and workmanship under normal use.

For customer service, technical support, or warranty claims, please contact HOMEnhancements directly. Refer to the contact information provided on the product packaging or the official HOMEnhancements website.