

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [TOHUNZO](#) /

› [TOHUNZO IP68 Waterproof Swimming Headphones User Manual](#)

## TOHUNZO 125

# TOHUNZO IP68 Waterproof Swimming Headphones

Model: 125

## INTRODUCTION

Thank you for choosing the TOHUNZO IP68 Waterproof Swimming Headphones. These in-ear earphones are designed for various activities, including swimming, running, and gym workouts, offering both Bluetooth connectivity and built-in MP3 storage. This manual provides detailed instructions for proper setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device.

## PACKAGE CONTENTS

Please verify that all items are present in your package:

- 1x Sport Wireless Earphones
- 1x USB Magnetic Charging Cable
- 1x User Manual
- 3x Normal Ear Caps (3 sizes)
- 3x Waterproof Swimming Earplugs (3 sizes)



Figure 1: Included accessories for the TOHUNZO Model 125 headphones.

## PRODUCT FEATURES

- **IP68 Waterproof Rating:** Designed for full submersion, ideal for swimming and water sports.
- **Built-in 32GB MP3 Storage:** Store up to 10,000 songs directly on the device for offline listening, especially useful for underwater activities where Bluetooth signals are limited.
- **Bluetooth 5.4 Technology:** Provides stable wireless connection for general use outside of water.
- **Hi-Fi Sound Quality:** Delivers clear HD stereo sound for an immersive audio experience.
- **Magnetic Charging:** Ensures a secure and waterproof charging connection.
- **Long Playtime:** Up to 17 hours of battery life on a single charge.
- **Noise Control:** Active noise cancellation for focused listening.



Figure 2: The TOHUNZO Model 125 headphones demonstrating their waterproof design.

# ENJOY MUSIC ANYTIME

Built-in 32GB MP3 storage for uploading up to 10,000 songs



Figure 3: Built-in 32GB MP3 storage allows for music playback without a connected device.

## SETUP AND GETTING STARTED

### Charging the Headphones

Before first use, fully charge your headphones. The charging time is approximately 2 hours.

1. Connect the provided USB magnetic charging cable to the charging port on the headphones. The magnetic connection ensures proper alignment.
2. Plug the USB-A end of the cable into a compatible USB power source (e.g., computer USB port, wall adapter).
3. The indicator light on the headphones will show charging status (refer to the user manual for specific light indications).

### Uploading Music (MP3 Mode)

To use the headphones for swimming, music must be loaded onto the internal 32GB storage.

1. Connect the headphones to your computer using the magnetic USB charging cable.
2. The headphones will appear as a removable disk drive on your computer.

3. Drag and drop your MP3 audio files directly into the headphone's storage folder.
4. Safely eject the device from your computer once files are transferred.

## Bluetooth Pairing

For wireless listening outside of water, pair your headphones with a Bluetooth-enabled device.

1. Ensure the headphones are powered off.
2. Press and hold the power button until the indicator light flashes, indicating pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select "TOHUNZO 125" (or similar name) from the list to connect.
5. Once connected, the indicator light will change (refer to the user manual for specific light indications).

## OPERATING INSTRUCTIONS

---

### Controls

The headphones feature physical buttons for media control:

- **Power On/Off:** Press and hold the power button.
- **Play/Pause:** Single press the play/pause button.
- **Volume Up/Next Track:** Short press for volume up, long press for next track.
- **Volume Down/Previous Track:** Short press for volume down, long press for previous track.
- **Switch Modes (Bluetooth/MP3):** Press both volume up and down buttons simultaneously to switch between Bluetooth and MP3 playback modes.

### Wearing the Headphones Correctly

For secure fit and optimal performance, especially during swimming:

1. Position the earphone on your ear with the ear hook resting comfortably behind your ear.
2. Ensure the earbud is properly seated in your ear canal.
3. When swimming, it is recommended to cover the upper parts of your ear and the earphone with a swimming cap to help secure them and prevent water from dislodging them.

# IP68 WATERPROOF RATING

## In-Ear Swimming Headphones, Designed for Swimming



Figure 4: Proper wearing of headphones with a swimming cap for water activities.

### USAGE IN WATER

It is crucial to understand the limitations of Bluetooth technology in water:

- **Bluetooth mode is NOT supported underwater.** Water significantly interferes with Bluetooth signals, making wireless streaming unreliable or impossible when submerged.
- **Always use MP3 mode for swimming.** Ensure your desired music is loaded onto the headphones' internal storage before entering the water.
- Use the provided waterproof swimming earplugs (3 sizes) to create a tight seal and prevent water from entering your ear canal, which can affect sound quality and ear health.

# WATERPROOF ADVANTAGES OF in-EAR HEADPHONES



## in-EAR SWIMMING HEADPHONES

Water can't get into the ear canal, the sound of music is not disturbed



VS



## BONE CONDUCTION HEADPHONES

1. Water enters the ear canal, music sound is disturbed and has a murmur
2. Bone conduction headphones vibrate causing discomfort in the cheekbones

Figure 5: Advantage of in-ear headphones for swimming, preventing water intrusion into the ear canal.

# BLUETOOTH 5.3 SPORTS HEADSET

## 10M (33 FT) transmission range over open ground



**Bluetooth mode  
not supported  
underwater,  
please use MP3  
mode**

Figure 6: Important note: Bluetooth connectivity is not functional underwater; use MP3 mode.

## MAINTENANCE AND CARE

- **Cleaning:** After each use, especially after swimming, rinse the headphones with fresh water to remove chlorine or salt. Wipe them dry with a soft cloth.
- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- **Ear Tips:** Regularly clean the ear tips and replace them if they become worn or damaged to maintain sound quality and a proper seal.
- **Charging Port:** Ensure the magnetic charging contacts are clean and dry before charging to prevent corrosion.
- **Avoid Drops:** Dropping the headphones can compromise the waterproof seal. Handle with care.

## TROUBLESHOOTING

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Headphones not turning on.	Low battery.	Charge the headphones fully.
Cannot connect via Bluetooth.	Headphones not in pairing mode; device Bluetooth off; too far from device.	Ensure headphones are in pairing mode; enable Bluetooth on device; move closer to device (within 33 ft).
No sound or poor sound quality underwater.	Using Bluetooth mode; water in ear canal; improper ear tip seal.	Switch to MP3 mode; ensure ear tips are properly sealed and use waterproof earplugs; clear any water from ear canal.
Music not playing from MP3 storage.	Not in MP3 mode; no music files loaded; corrupted files.	Switch to MP3 mode; verify music files are loaded correctly; try re-uploading files.

## SPECIFICATIONS

- Model:** 125
- Brand:** TOHUNZO
- Water Resistance Level:** IP68 (Waterproof)
- Wireless Communication Technology:** Bluetooth 5.4
- Internal Storage:** 32GB (for MP3 playback)
- Battery Life:** Up to 17 Hours
- Charging Time:** 2 Hours
- Audio Driver Type:** Dynamic Driver
- Frequency Range:** 20 Hz - 20,000 Hz
- Noise Control:** Active Noise Cancellation
- Material:** Plastic, Silicone
- Item Weight:** 5.9 ounces

## WARRANTY AND SUPPORT

For warranty information, technical support, or any inquiries regarding your TOHUNZO IP68 Waterproof Swimming Headphones, please refer to the contact details provided on the product packaging or the official TOHUNZO website. Keep your purchase receipt for warranty claims.