

[Manuals.plus](#) /

> [Soozier](#) /

> Soozier Portable Basketball Hoop Instruction Manual

Soozier A61-046V00BK

Soozier Portable Basketball Hoop Instruction Manual

Model: A61-046V00BK

Brand: Soozier

1. INTRODUCTION

This manual provides essential information for the safe assembly, operation, and maintenance of your Soozier Portable Basketball Hoop. Please read these instructions thoroughly before use and retain them for future reference. This product is designed for both poolside and general outdoor use, featuring adjustable height and a stable, fillable base.





Image 1.1: Full view of the Soozier Portable Basketball Hoop, showcasing its design with a black backboard, red and blue net, and a sturdy base.

2. PRODUCT FEATURES

- **Dual-Use Design:** This portable basketball hoop can be configured for full-size outdoor play or adapted for poolside use by removing the center support section.
- **Adjustable Height:** The hoop height is adjustable to accommodate various player ages, heights, and skill levels. The full-size hoop height ranges from 90.5" to 120", and the poolside height ranges from 51.25" to

80.75".

- **Stable Fillable Base:** The base can be filled with water (143 lbs), sand (176 lbs), or a mixture of both (198 lbs) to ensure stability during play. It also includes a slot to hold a basketball.
- **Durable Construction:** Constructed with a heavy-duty steel frame, an impact-resistant and shatterproof backboard, and tear-proof nylon netting, designed to withstand outdoor conditions.
- **Portability:** Equipped with two wheels on the base for easy relocation.

DUAL-USE DESIGN



Poolside Basketball Hoop



Remove the
centre section
of the frame



Backyard Basketball Hoop

Image 2.1: Illustration of the dual-use design, demonstrating how the center section can be removed to convert the hoop from a backyard setup to a poolside setup.




Ball Holder



Heavy-duty Steel Frame



Shatterproof Backboard



Tear-proof Netting

Image 2.2: Detailed views of key components including the ball holder on the base, the heavy-duty steel frame, the shatterproof backboard, and the tear-proof nylon netting.

3. COMPONENTS (WHAT'S IN THE BOX)

Please verify that all components are present before beginning assembly:

- Basketball Hoop (Backboard, Rim, Net)
- Basketball Stand (Multiple sections for adjustable height)
- Wheeled Base
- Assembly Hardware (Bolts, nuts, washers, tools if included)
- Instruction Manual

4. SETUP AND ASSEMBLY

Assembly is required for this product. Follow the detailed instructions provided in the separate assembly guide included with your purchase. Ensure you have adequate space and any necessary tools before starting. It is

recommended to have at least two adults for assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Verify all components are present against the 'What's in the Box' list.
2. **Assemble the Base:** Attach any necessary support structures to the base as per the assembly guide.
3. **Attach the Pole Sections:** Connect the various pole sections, ensuring they are securely fastened. Pay attention to the height adjustment mechanism during this step.
4. **Mount the Backboard and Rim:** Securely attach the backboard to the upper pole section, followed by the rim and net.
5. **Fill the Base:** Once assembled, fill the base with water, sand, or a mixture of both to the recommended weight for stability. Ensure the cap is securely closed to prevent leakage.



Image 4.1: A detailed view of the sturdy base and the lower support structure of the basketball hoop, highlighting its robust design.

5. OPERATING INSTRUCTIONS

5.1 Adjusting Height

To adjust the hoop height:

1. Loosen the locking mechanism on the pole.
2. Carefully slide the upper pole section to the desired height. It is recommended to have assistance to prevent the pole from dropping.
3. Ensure the height is set within the specified range (90.5" - 120" for full-size, 51.25" - 80.75" for poolside).
4. Securely tighten the locking mechanism before use.

5.2 Converting for Poolside Use

To convert the hoop for poolside use:

1. Ensure the base is stable and the hoop is at its lowest adjustable height.
2. Identify the removable center section of the main pole.
3. Carefully detach and remove this center section as per the assembly guide.
4. Re-attach the upper and lower pole sections, ensuring all connections are secure.
5. Adjust the height to the desired poolside level (51.25" - 80.75").

5.3 Moving the Hoop

The hoop is equipped with wheels for portability:

1. Ensure the base is filled for stability.
2. Tilt the hoop slightly by lifting the opposite end of the base from the wheels.
3. Roll the hoop to the desired location.
4. Gently lower the base back down to ensure full contact with the ground before use.



Image 5.1: A close-up view of the base showing the integrated wheels, designed for easy tilting and relocation of the basketball hoop.

6. MAINTENANCE

Regular maintenance will extend the life of your basketball hoop:

- **Check Stability:** Periodically inspect the base for water or sand levels and refill as needed to maintain stability.
- **Inspect Hardware:** Regularly check all bolts, nuts, and connections for tightness. Tighten any loose hardware to ensure structural integrity.
- **Clean Surfaces:** Clean the backboard, pole, and base with mild soap and water. Avoid abrasive cleaners that could damage the materials.
- **Net Inspection:** Check the nylon net for any signs of wear or tearing. Replace the net if it becomes damaged.
- **Winter Storage:** In colder climates, it is recommended to empty the base of water to prevent freezing and cracking. Store the hoop in a sheltered area during winter months.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Hoop is unstable or tips easily.	Base is not sufficiently filled with water/sand.	Fill the base to its maximum capacity (198 lbs with sand and water). Ensure the cap is sealed.
Height adjustment mechanism is stuck or difficult to move.	Dirt or debris in the mechanism; bolts too tight.	Clean the adjustment area. Loosen bolts slightly if they are overtightened, then re-tighten after adjustment.
Water leakage from the base.	Base cap is not sealed properly or base is damaged.	Ensure the cap is tightly secured. Inspect the base for cracks; if damaged, contact customer support.
Net is torn or worn.	Normal wear and tear from use and weather exposure.	Replace the net with a compatible tear-proof nylon net.

8. SPECIFICATIONS

Feature	Detail
Brand	Soozier
Model Name	Basketball Hoop Stand
Item Model Number	A61-046V00BK
Material	Steel, Plastic, HDPE
Color	Black
Product Dimensions	35.5"D x 23.5"W x 145.75"H
Item Weight	44 Pounds
Indoor/Outdoor Usage	Outdoor
Special Feature	Adjustable Height, Portable, Shatterproof
Mounting Type	Free Standing
Target Audience	Youth & Adults
Included Components	Basketball Hoop, Basketball Stand, Wheeled base
Frame Material	Alloy Steel
Minimum Height	76.75 Inches
Maximum Height Recommendation	145.75 Inches
Hoop Height (Full-Size Use)	90.5" - 120"
Hoop Height (Poolside Use)	51.25" - 80.75"

Feature	Detail
Backboard Dimensions	43.25" W x 29.5" H
Base Dimensions	35.5" L x 23.5" W x 6" H
Base Fill Capacity (Water)	143 lbs
Base Fill Capacity (Sand)	176 lbs
Base Fill Capacity (Mixture)	198 lbs
Assembly Required	Yes
UPC	196393246085




Image 8.1: A technical diagram illustrating the key dimensions of the basketball hoop, including backboard size, base dimensions, and the range of adjustable heights for both full-size and poolside configurations.

9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact Soozier customer support directly. If you encounter any issues or require assistance with your product, please reach out to

the manufacturer's customer service department. Keep your proof of purchase for warranty claims.



© 2023 Soozier. All rights reserved.