

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [edx](#) /

› [edx Ergonomic Mesh Office Chair CH3766G User Manual](#)

edx CH3766G

edx Ergonomic Mesh Office Chair CH3766G User Manual

Model: CH3766G | Brand: edx

1. INTRODUCTION

Thank you for choosing the edx Ergonomic Mesh Office Chair. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure optimal use and longevity of your chair. Please read this manual thoroughly before assembly and retain it for future reference.

2. SAFETY INFORMATION

- Ensure all components are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the chair on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly.
- The maximum weight recommendation for this chair is **275 pounds**. Exceeding this limit may cause damage or injury.
- Keep children and pets away during assembly.
- Use the chair only for its intended purpose.

3. PACKAGE CONTENTS

Please verify that all the following parts are included in your package:

A: Backrest (x1)

B: Seat Cushion (x1)

C: Armrests (Left x1, Right x1)

D: Mechanism (x1)

E: Gas Lift (x1)

F: Base (x1)

G: Head Pillow (x1)

H: Casters (x5)

I: Legs for Base (x5)

J: Bolts for Backrest (x3)

K: Bolts for Mechanism (x4)

L: Bolts for Head Pillow (x2)

M: Bolts for Armrests (x2)

N: Bolts for Armrests (x4)

O: Bolts for Base Legs (x10)

P: Plastic Cover (x1)

Q: Wrench (x1)

4. ASSEMBLY INSTRUCTIONS

For a visual guide, please refer to the official installation video below:

Your browser does not support the video tag.

Video Description: This video demonstrates the step-by-step assembly process for the edx Ergonomic Mesh Office Chair, including attaching the base, armrests, mechanism, backrest, and headrest.

1. Step 1: Assemble the Chair Base

Divide the Base (F) into two parts. Using the Wrench (Q), install the 5 Legs (I) to the Base (F) with 10 Bolts (O). Then, press the 5 Casters (H) into the holes at the end of the Legs (I). Finally, place the Base Cover (part of F) back on the base and insert the Gas Lift (E) into the center hole of the Base (F).

Product Dimension

Seat height 19.48"-23.22"



Image Description: Diagram showing the overall dimensions of the chair and its 275 lbs weight capacity. This image helps visualize the assembled base structure.

2. Step 2: Attach Armrests to Seat Cushion

Turn the Seat Cushion (B) upside down. Install the Left Armrest (C-L) and Right Armrest (C-R) to the Seat Cushion (B) using 2 Bolts (M) and 4 Bolts (N). Ensure the armrests are securely fastened. *Note: The Seat (B) is marked with "FRONT"; please make sure the installation direction is correct.*

3. Step 3: Attach Mechanism to Seat Cushion

Attach the Mechanism (D) to the Seat Cushion (B) using 4 Bolts (K). Ensure the "FRONT" direction of the Mechanism (D) aligns with the "FRONT" direction of the Seat Cushion (B).

4. Step 4: Attach Backrest to Seat Assembly

Align the screw holes of the Backrest (A) and the Mechanism (D). Using the Wrench (Q), secure both completely with 3 Bolts (J).

5. Step 5: Connect Seat Assembly to Gas Lift

Align the hole on the Mechanism (D) with the Gas Lift (E). Carefully lower the assembled seat onto the Gas Lift and press down firmly until it is fully secured.

6. Step 6: Attach Head Pillow

Using the Wrench (Q), attach the Head Pillow (G) to the Backrest (A) with 2 Bolts (L). Then, attach the Plastic Cover (P) to conceal the hole.

5. OPERATING YOUR CHAIR

5.1. Height Adjustment

To adjust the chair's height, pull the lever located under the seat upwards. While pulling the lever, stand up to raise the chair or remain seated to lower it. Release the lever at the desired height.

5.2. Tilt and Rocking Function

The chair features a 90°-135° rocking function. Use the lever under the seat to engage or disengage the rocking motion. The tension of the rocking can be adjusted by turning the round knob located under the seat.



Image Description: Illustration showing the chair's 90°-135° rocking range and the location of the recline lock/rocking tension knob and height adjustment lever.

5.3. Adjustable Headrest

The headrest can be adjusted in height by 3.35 inches and rotated by 45 degrees to reduce neck pressure and provide optimal support.

Adjustable Headrest

Reduces neck pressure with 3.35 inches of adjustable height and 45 rotation



Image Description: Visual representation of the headrest's adjustable height (3.35 inches) and reversible angle (45 degrees).


5.4. Adjustable Lumbar Support

The ergonomic lumbar support is designed to conform to the natural curve of your lower back. It can be adjusted vertically by 1.96 inches and horizontally by 1.1 inches to provide personalized comfort and support.

Ergonomic Lumbar Support Office Chair



S-Shaped Design



Adjustable & Retractable



Comfortable Backrest Pad





Image Description: Detailed view of the adjustable and retractable lumbar support, highlighting its S-shaped design and vertical/horizontal adjustment capabilities.

5.5. Armrest Adjustment

The armrests are 3D adjustable, allowing for height adjustments of 3.54 inches to suit your preference and desk height.



Breathable Resilient Mesh Fabric



Thickened 4-Inch Sponge Material



Adjustable Height

Image Description: Close-up showing the breathable resilient mesh fabric, thickened 4-inch sponge material of the seat, and the 3.54-inch adjustable height feature of the armrests.

6. CARE AND MAINTENANCE

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the mesh or fabric.
- **Inspection:** Periodically check all bolts and screws to ensure they are tight. Retighten if necessary.
- **Casters:** Keep casters free of debris to ensure smooth rolling.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight may cause fading of the fabric and mesh.

7. TROUBLESHOOTING

- **Chair does not adjust height:** Ensure the gas lift lever is fully engaged and the gas lift is properly inserted into the base and mechanism.
- **Chair wobbles:** Check all bolts and screws, especially those connecting the base, mechanism, and armrests, and tighten them securely. Ensure the chair is on a flat, even surface.

- **Casters not rolling smoothly:** Check for hair or debris wrapped around the caster wheels. Clean them thoroughly.
- **Backrest feels loose:** Verify that the bolts securing the backrest to the mechanism are tightened.

8. PRODUCT SPECIFICATIONS

Feature	Specification
Brand	edx
Model Name	edx Office Chair (CH3766G)
Color	Grey
Product Dimensions	26"D x 27"W x 53"H
Maximum Weight Recommendation	275 Pounds
Back Style	Solid Back with Mesh
Special Features	Adjustable Backrest, Adjustable Headrest, Adjustable Height, Adjustable Lumbar, Rolling Casters
Material	Mesh, Sponge, Metal (Form Factor)
Certifications	BIFMA certified, SGS certified gas lift

9. WARRANTY AND SUPPORT

edx values customer satisfaction. If you encounter any issues with your office chair, please do not hesitate to contact us. We are committed to providing a solution that meets your satisfaction.

For support, please refer to the contact information provided with your purchase or visit the official edx website.