LIORQUE S7509

LIORQUE Projection Alarm Clock User Manual

Model: S7509

INTRODUCTION

Thank you for purchasing the LIORQUE Projection Alarm Clock. This manual provides detailed instructions for setting up, operating, and maintaining your new device. Please read this manual thoroughly before use to ensure proper function and to maximize your user experience.

Image: The LIORQUE Projection Alarm Clock, showing its main display, projection lens, and a smartphone connected for charging, alongside its power adapter.

PACKAGE CONTENTS

Please check the package contents upon unboxing:

- LIORQUE Projection Alarm Clock
- Power Adapter (USB-A to DC barrel jack cable with EU plug)
- User Manual (Multilingual)

Image: Contents of the LIORQUE Projection Alarm Clock package, displaying the clock, its power cable with an EU plug, and the included user manual.

PRODUCT OVERVIEW

Familiarize yourself with the various parts and functions of your alarm clock.

Doppelwecker

Die Wecklautstärke ändert sich alle 20 Sekunden um eine Stufe
Es gibt 3 Lautstärkestufen, von niedrig bis hoch

⏰ 8:30
Werktag

⏰ 10:00
Wochenende

Image: A close-up view of the LIORQUE Projection Alarm Clock, highlighting its large digital time display and the integrated projection lens.

Key Features:

- Digital Time Display (Adjustable Brightness)
- 180° Rotatable Time Projection
- FM Radio with 15 Preset Stations
- Dual Alarm Function with Snooze

- USB Charging Port for External Devices
- Temperature Display
- Sleep Timer

S<small>ETUP</small>

1. Power Connection

1. Connect the provided power adapter cable to the DC input port on the back of the alarm clock.
2. Plug the power adapter into a standard wall outlet.
3. The display will light up, indicating the device is powered on.

12/24 Stunden   Einstellbare Helligkeit   FM-Radio   Schlummer-funktion

Doppelwecker   Zeitprojektion   Integrierter Akku   Timer

Image: The LIORQUE Projection Alarm Clock with its power adapter plugged into a wall socket, demonstrating the power connection.

2. Setting the Time

Refer to the buttons on the top of the device for time setting. Specific button names are usually indicated on the device itself or in the included paper manual.

- Press and hold the **TIME SET** button (or similar) to enter time setting mode.

- Use the **+/-** buttons to adjust hours and minutes.

- Press **TIME SET** again to confirm each setting (e.g., hour, then minute).

- Select 12-hour or 24-hour format if available.

3. Adjusting Display Brightness

The main display brightness can be adjusted to suit your preference, especially for night use.

- Press the **DIMMER** button (or similar) repeatedly to cycle through brightness levels (e.g., High, Medium, Low, Off).

Image: The LIORQUE Projection Alarm Clock demonstrating four different levels of screen brightness, from off to maximum illumination, allowing users to choose their preferred setting.

OPERATING INSTRUCTIONS

1. Setting Alarms (Dual Alarm)

The alarm clock supports two independent alarms (Alarm 1 and Alarm 2).

1. Press and hold the **ALARM 1** or **ALARM 2** button to enter alarm setting mode.
2. Use the **+/-** buttons to set the desired alarm time (hour and minute).
3. Press the respective alarm button again to confirm the time.
4. Select the alarm source (Buzzer or FM Radio) and volume using the **+/-** buttons.
5. Press the alarm button one more time to save and activate the alarm. An alarm icon will appear on the display.

Image: The LIORQUE Projection Alarm Clock displaying two different alarm times, one for a weekday (8:30) and one for the weekend (10:00), illustrating its dual alarm capability.

2. Snooze Function

When the alarm sounds, press the **SNOOZE** button (usually a large button on top) to temporarily silence the alarm for 9 minutes. The alarm will sound again after the snooze period.

9 Minuten Schlummerzeit

Schlaf-Timer von 5 bis 90 Minuten

Image: The LIORQUE Projection Alarm Clock showing the time 8:30 with a snooze icon, indicating the snooze function is active. A hand reaching for the snooze button is also depicted.

3. FM Radio Operation

1. Press the **FM** button to turn on the radio.
2. Press the **SCAN** button to automatically scan and save available stations.

3. Use the **+/-** buttons to manually tune to a specific frequency or cycle through saved presets.

4. Adjust the volume using the **VOLUME +/-** buttons.

5. Press the **FM** button again to turn off the radio.

Image: The LIORQUE Projection Alarm Clock showing an FM radio frequency (78.4) on its display, with graphical representations of radio waves indicating its FM radio capability and preset stations.

4. Time Projection

The alarm clock can project the time onto a wall or ceiling.

- Adjust the projection angle by rotating the projector lens on the side of the unit (up to 180°).
- Press the **PROJECTION** button (or similar) to turn the projection on/off.
- Repeatedly press the **PROJECTION** button to cycle through projection brightness levels (e.g., High, Medium, Low, Off).
- If the projected time is upside down, press the **180° FLIP** button (or similar) to invert the display.

Image: The LIORQUE Projection Alarm Clock projecting the time onto a ceiling in a bedroom setting, demonstrating its 180° high-resolution digital projection feature and three levels of projection brightness.

5. USB Charging Port

A USB port is available on the back of the unit to charge your smartphone or other small electronic devices. Connect your device's USB charging cable to this port.

6. Sleep Timer

The sleep timer allows the radio to play for a set duration before automatically turning off.

- While the radio is playing, press the **SLEEP** button (or similar) repeatedly to select the desired sleep timer duration (e.g., 5, 10, 15, 30, 60, 90 minutes).
- The radio will automatically turn off after the selected time.

Image: The LIORQUE Projection Alarm Clock illustrating its sleep timer function, showing the clock display and a person sleeping, with radio waves indicating the radio playing before automatically turning off.

MAINTENANCE

- **Cleaning:** Wipe the surface of the alarm clock with a soft, dry cloth. Do not use abrasive cleaners or solvents.

- **Storage:** If not in use for an extended period, unplug the device and store it in a cool, dry place.
- **Power:** Always use the provided power adapter. Do not expose the device to water or excessive humidity.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Display is off or dim.	Not powered on; brightness set to off/low.	Ensure power adapter is securely plugged in. Press the **DIMMER** button to adjust brightness.
Alarm does not sound.	Alarm not set or activated; volume too low.	Verify alarm time is set and activated (icon visible). Increase alarm volume.
Poor FM radio reception.	Antenna not extended; weak signal.	Fully extend the FM antenna. Try repositioning the alarm clock for better reception.
Projected time is blurry or unclear.	Focus not adjusted; too far from surface.	Adjust the focus ring on the projector lens. Ensure the projection distance is optimal (typically 1-3 meters).
USB charging not working.	Device not compatible; cable faulty; power insufficient.	Ensure your device is compatible with 5V USB charging. Try a different USB cable. Note that the charging output may be limited.

SPECIFICATIONS

Feature	Detail
Brand	LIORQUE
Model Number	S7509
Color	Blue
Product Dimensions	10.5 x 3.81 x 6.2 cm
Item Weight	340 g
Material	Plastic
Display Type	Digital
Power Source	AC Powered (with backup battery for settings)
Special Features	Time Projection, Radio, Dual Alarm, Adjustable Brightness

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the contact details provided in the original product packaging or visit the official LIORQUE website. Keep your purchase receipt as proof of purchase for warranty claims.
Email Support: support@liorque.net