

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Goobay](#) /
- › [Goobay 41074 USB-C Sync & Charge Cable Instruction Manual](#)

Goobay 41074

Goobay 41074 USB-C Sync & Charge Cable Instruction Manual

Model: 41074

1. INTRODUCTION

This manual provides instructions for the Goobay 41074 USB-C Sync & Charge Cable. This cable is designed for high-speed data transfer, fast charging, and video/audio transmission between compatible USB-C enabled devices.






Image 1.1: The Goobay 41074 USB-C Sync & Charge Cable, featuring a USB-A connector on one end and a USB-C connector on the other. The image also highlights key specifications such as USB-C compatibility, 1-meter length, 60W power delivery, and 20x faster speed than USB 2.0.

2. PRODUCT FEATURES

- **Fast Charging:** Supports power delivery up to 60 W (20 V / 3 A) for rapid charging of compatible USB-C devices.
- **SuperSpeed+ Data Transfer:** Achieves data transfer rates up to 10 Gbit/s, which is 20 times faster than USB 2.0.
- **USB 3.2 Gen 2 Standard:** Utilizes the latest USB 3.2 Gen 2x2 standard for efficient data handling.
- **Reversible USB-C Connector:** The USB-C plug can be inserted in either orientation.
- **Video & Audio Transmission:** Capable of transmitting video and audio content to external displays with a USB-C input.
- **Versatile Use:** Suitable for transferring movies, music, videos, and various files.



Image 2.1: A detailed view of the Goobay USB-C cable, highlighting its USB-A and USB-C connectors and indicating its 1-meter length, 60W power delivery, and 10 Gbps data transfer speed.

3. PACKAGE CONTENTS

The package contains the following item:

- 1x Goobay 41074 USB-C Sync & Charge Cable (1 meter)

4. SETUP

To set up your Goobay 41074 USB-C cable, follow these general steps:

1. **Identify Ports:** Locate the appropriate USB-A and USB-C ports on your devices (e.g., computer, charger, smartphone, monitor).
2. **Connect Devices:** Insert the USB-A end of the cable into a compatible USB-A port on your host device (e.g., computer, wall charger).

3. **Connect USB-C Device:** Insert the USB-C end of the cable into the USB-C port of your target device (e.g., smartphone, tablet, laptop, monitor). The USB-C connector is reversible, allowing for easy connection in either direction.



Image 4.1: A Goobay USB-C cable connected to a laptop, demonstrating the reversible nature of the USB-C connector and its ease of use. A close-up of the USB-C port is also shown.

5. OPERATING INSTRUCTIONS

5.1. Charging Devices

To charge a USB-C enabled device:

1. Connect the USB-A end of the cable to a compatible USB wall charger or power adapter.
2. Connect the USB-C end of the cable to your USB-C device (e.g., smartphone, tablet, laptop).
3. Ensure the power adapter is plugged into a working power outlet. Your device should begin charging.

5.2. Data Transfer

To transfer data between a computer and a USB-C device:

1. Connect the USB-A end of the cable to an available USB-A port on your computer.
2. Connect the USB-C end of the cable to your USB-C device.
3. Your computer should recognize the connected device. Follow the on-screen prompts on your computer and device to manage data transfer (e.g., select 'File Transfer' mode on your smartphone).



Image 5.1: A Goobay USB-C cable connecting a smartphone to a laptop, illustrating its use for data transfer between devices.

5.3. Video and Audio Output

To transmit video and audio to an external display:

1. Connect the USB-A end of the cable to your source device (e.g., laptop with a USB-A port that supports video output via an adapter, or a docking station).
2. Connect the USB-C end of the cable to a compatible monitor or television with a USB-C input that supports video.
3. Ensure your source device and display are configured correctly for video output.

6. MAINTENANCE

- **Storage:** Store the cable in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly coiling or bending the cable at sharp angles to prevent internal damage.
- **Cleaning:** Disconnect the cable from all devices and power sources before cleaning. Use a soft, dry, lint-free cloth to gently wipe the cable and connectors. Avoid using liquid cleaners or abrasive materials.
- **Handling:** Always grasp the connector head when plugging or unplugging the cable. Avoid pulling on the cable itself, as this can damage the internal wires or the connector.
- **Inspection:** Periodically inspect the cable and connectors for any signs of wear, fraying, or damage. If damage is observed, discontinue use and replace the cable.



Image 6.1: A close-up view of the USB-C connector, showing its internal pins. Regular inspection of connectors helps ensure proper function and longevity.

7. TROUBLESHOOTING

7.1. Device Not Charging

- **Check Connections:** Ensure both ends of the cable are securely plugged into the device and the power source.
- **Verify Power Source:** Confirm that the wall outlet or power adapter is functioning correctly. Try another power source if available.
- **Device Compatibility:** Ensure your device supports charging via USB-C and that the power adapter provides sufficient wattage.
- **Try Another Cable/Port:** If possible, test with a different USB-C cable or a different port on your power source/device to isolate the issue.

7.2. No Data Transfer

- **Check Connections:** Ensure the cable is firmly connected to both the computer and the USB-C device.
- **Device Settings:** On your USB-C device (e.g., smartphone), check if it's set to 'File Transfer' or 'MTP' mode after connecting to the computer.
- **Computer Recognition:** Verify that your computer's operating system recognizes the connected device. You may need to install specific drivers for your device.
- **Port Functionality:** Test the USB-A port on your computer with another known working device/cable.

7.3. No Video/Audio Output

- **Compatibility:** Ensure both your source device (e.g., laptop) and the external display support video output over USB-C. Not all USB-C ports support this feature.
- **Display Input:** Select the correct input source on your monitor or television.
- **System Settings:** Check your computer's display settings to ensure the external monitor is detected and configured correctly (e.g., extended display, duplicate display).

8. SPECIFICATIONS

Feature	Specification
Brand	Goobay
Model Number	41074
Connector Type 1	USB Type-A (Male)

Connector Type 2	USB Type-C (Male)
Cable Type	USB
USB Standard	USB 3.2 Gen 2 (SuperSpeed+)
Data Transfer Rate	Up to 10 Gbit/s
Power Delivery	Up to 60 W (20 V / 3 A)
Cable Length	1 Meter
Color	Black
Compatible Devices	Monitors, Televisions, USB-C enabled devices
Special Feature	Fast Charging, Video & Audio Transmission

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or visit the official Goobay website. Keep your proof of purchase for warranty claims.

