#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- Logitech /
- > Logitech MX Brio 705 for Business 4K Webcam User Manual

#### **Logitech MX Brio 705**

### Logitech MX Brio 705 for Business 4K Webcam User Manual

Model: MX Brio 705 (960-001529)

Brand: Logitech

#### Introduction

The Logitech MX Brio 705 for Business is a high-performance 4K webcam designed for professional use. It features advanced imaging technology, intelligent video capabilities, and robust audio capture to enhance virtual meetings and presentations. This manual provides instructions for setting up, operating, maintaining, and troubleshooting your webcam.



Image: Logitech MX Brio 705 for Business 4K Webcam, showcasing the device and its retail packaging.

#### WHAT'S IN THE BOX

Verify that all components are present in the packaging:

- MX Brio 705 for Business webcam
- USB-C 3.0 cable (1.5 meters)
- Mount clip with removable mount adapter
- User documentation

# IN THE BOX ULTRA-WIDE 4K S. SMP SENSOR Cable Length: 1.5 m Responsible Packaging

Image: An illustration showing the MX Brio 705 webcam, its USB-C cable, and the monitor mount, representing the items included in the product box.

#### **S**ETUP

#### 1. Mounting the Webcam:

Attach the webcam to your monitor or laptop screen using the integrated mount clip. Ensure the clip is securely fastened and the webcam is stable. The mount adapter is removable if you prefer to use a tripod (not included) with the standard 1/4-inch thread.



Image: A detailed diagram highlighting the various components of the MX Brio 705 webcam, such as the privacy shutter, 4K Ultra HD lens, LED activity light, USB-C connectivity, dual beamforming mics, and magnetic mount.

#### 2. Connecting to Your Computer:

Connect the provided USB-C 3.0 cable to the USB-C port on the webcam and then to an available USB-C port on your computer. If your computer only has USB-A ports, a USB-C to USB-A adapter (not included) may be required.

#### 3. Initial Recognition:

Your computer should automatically detect the webcam. For optimal performance and access to advanced features, download and install the Logitech Logi Options+ software from the official Logitech website.

#### **OPERATING INSTRUCTIONS**

#### **Basic Usage**

- Power On/Off: The webcam powers on automatically when connected to your computer and recognized by an application.
- Activity Light: An LED activity light on the webcam illuminates when the camera is active and in use.
- Compatibility: The MX Brio 705 is certified for Microsoft Teams, Zoom, and Google Meet, and works with



Image: The MX Brio 705 webcam positioned on a monitor in an office environment, with logos indicating its certification for Microsoft Teams, Zoom, Google Meet, and compatibility with Chromebook.

#### **Advanced Features**

- 4K Ultra HD Video Quality: The webcam features an advanced image sensor and custom-designed lens for crystal-clear 4K video resolution.
- Auto Light Correction: Al-powered image enhancement automatically adjusts lighting conditions to ensure
  you appear natural and well-lit, even in challenging environments. This feature provides accurate skin tones
  and facial tracking.
- Auto-Framing: This intelligent feature keeps you centered in the frame, even if you move slightly during a call, ensuring you remain the focus of the video.
- **Show Mode:** Easily present physical objects or documents on your desk by tilting the webcam downwards. This mode optimizes the view for sharing content directly from your workspace.




Image: A user's hand interacting with a notebook on a desk, illustrating the webcam's Show Mode and auto-framing capabilities, designed to keep the subject and presented items in focus.

- Integrated Privacy Shutter: For privacy and security, the webcam includes an integrated physical privacy shutter. Rotate the lens ring to open or close the shutter, providing a clear visual indication of its status.
- **Dual Beamforming Microphones:** The built-in dual beamforming microphones are designed to reduce background noise and enhance your voice, ensuring clear audio transmission during calls.



Image: The MX Brio 705 webcam with graphic overlays depicting sound waves, emphasizing the functionality of its dual beamforming microphones for superior audio clarity.

#### **Logitech Sync for Remote Management**

For IT professionals, the MX Brio 705 for Business can be remotely updated and managed using Logitech Sync software. This platform allows for secure boot design and prevents unauthorized actions, streamlining device management across an organization.

#### **M**AINTENANCE

- Cleaning: Use a soft, dry cloth to clean the webcam lens and body. Avoid abrasive cleaners or solvents that could damage the surfaces.
- **Storage:** When not in use, store the webcam in a clean, dry environment. Utilize the integrated privacy shutter to protect the lens from dust and scratches.
- Cable Care: Avoid bending or crimping the USB-C cable excessively to prevent internal damage.

#### **TROUBLESHOOTING**

#### · Webcam Not Detected:

- Ensure the USB-C cable is securely connected to both the webcam and your computer.
- Try connecting the webcam to a different USB port on your computer.
- Restart your computer.
- Check your operating system's privacy settings to ensure camera access is enabled for applications.

#### • Poor Video Quality:

- Ensure the lens is clean and free of smudges.
- Check your internet connection speed, as low bandwidth can affect video quality in calls.
- Verify that your video conferencing software is set to use the MX Brio 705 and that its video resolution settings are appropriate (e.g., 1080p or 4K if supported by the platform).
- Ensure adequate lighting in your environment.

#### • No Audio/Poor Audio:

- Confirm that the MX Brio 705 is selected as the microphone input device in your computer's sound settings and your video conferencing application.
- Check the volume levels on your computer and in the application.
- Ensure the webcam's microphones are not obstructed.

#### **S**PECIFICATIONS

Feature	Specification
Model Number	960-001529
Max Screen Resolution	UHD (Ultra High Definition)
Video Capture Resolution	4K
Rear Webcam Resolution	8 MP
Connectivity Technology	USB-C
Special Feature	Microphone Input, Auto Light Correction, Auto-Framing, Show Mode, Privacy Shutter
Item Weight	6.1 ounces
Product Dimensions (LxWxH)	2.1 x 3.9 x 2.4 inches
Color	Graphite
Manufacturer	Logitech

#### **ENVIRONMENTAL INFORMATION**

The Logitech MX Brio 705 for Business is designed with sustainability in mind:

- Recycled Plastic: Plastic components contain a minimum of 82% post-consumer recycled plastic.
- Low-Carbon Aluminum: The camera housing is constructed from solid milled, low-carbon aluminum.
- Responsible Packaging: Packaging is designed to be responsible and minimize environmental impact.

• Certified Carbon Neutral: The product is certified carbon neutral, reflecting efforts to reduce its carbon footprint.

## DESIGNED FOR A POSITIVE FUTURE



MADE WITH RECYCLED PLASTIC



LOW CARBON ALUMINIUM



RESPONSIBLE PACKAGING



CERTIFIED CARBON NEUTRAL



Image: The MX Brio 705 webcam accompanied by icons symbolizing its sustainable design, including the use of recycled plastic, low-carbon aluminum, responsible packaging, and carbon neutrality.

#### WARRANTY AND SUPPORT

For warranty information, technical support, and additional resources, please visit the official Logitech support website. User documentation is also available online for further assistance.

You can find more information and support at:Logitech Support

Related Documents - MX Brio 705

