

BoxWave AccuPoint Active Stylus

BoxWave AccuPoint Active Stylus User Manual

Model: AccuPoint Active Stylus | Brand: BoxWave

1. SETUP AND INITIAL USE

The BoxWave AccuPoint Active Stylus is designed for immediate use without complex setup. Follow these steps to begin using your stylus:

1.1 Charging the Stylus

Before first use, ensure the stylus is fully charged. A MicroUSB cable is included for charging.

- Locate the built-in charging port on the stylus.
- Connect the MicroUSB cable to the stylus and a standard USB power source (e.g., computer USB port, wall adapter).
- The indicator light will show charging status. A full charge provides approximately 12 hours of use.



Image: The AccuPoint Active Stylus connected via its MicroUSB port for charging, showing the indicator light.

1.2 Powering On/Off

To power on the stylus, simply press the button located on the barrel. The stylus will emit quick electronic pulses to interact with your device's screen. Press the button again to power off the stylus when not in use to conserve battery.

1.3 No Pairing Required

The AccuPoint Active Stylus does not require Bluetooth pairing or any special software installation. It is ready to use immediately after powering on.

2. OPERATING INSTRUCTIONS

The AccuPoint Active Stylus provides a natural writing and drawing experience on your compatible touchscreen device.

2.1 Using the Stylus

Hold the stylus like a traditional pen. The ultra-fine 2mm tip allows for precise interaction with your screen. You can tap, swipe, and draw accurately for various tasks, from navigation to note-taking and artistic creation.



Image: The stylus being used on a tablet screen, demonstrating its precision for various applications.

2.2 Compatibility

This stylus is compatible with the Oppo Find N3 and other capacitive touchscreen smartphones and tablets.

2.3 Important Considerations

- **No Palm Rejection:** The stylus does not support palm rejection. Avoid resting your palm on the screen while using the stylus to prevent unintended input.
- **No Pressure Sensitivity:** The stylus provides consistent line thickness and does not detect varying pressure levels.

3. MAINTENANCE

Proper care and maintenance will extend the lifespan of your AccuPoint Active Stylus.

3.1 Charging

Recharge the stylus when the indicator light signals low battery or when performance diminishes. Use the provided MicroUSB cable and a compatible USB power source.

3.2 Cleaning

To clean the stylus, gently wipe the barrel with a soft, dry, lint-free cloth. For the tip, use a slightly damp cloth if necessary, ensuring no moisture enters the charging port or internal components. Do not use harsh chemicals or abrasive materials.

3.3 Storage

Store the stylus in a cool, dry place away from direct sunlight and extreme temperatures. Avoid dropping the stylus or subjecting it to excessive force, which could damage the internal components or the fine tip.

4. TROUBLESHOOTING

If you encounter issues with your AccuPoint Active Stylus, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Stylus not responding	Stylus is off or battery is low.	Press the power button to turn on. Charge the stylus if the indicator light shows low battery.
Inaccurate input or skipping	Screen is dirty or stylus tip is worn.	Clean your device's screen. Ensure the stylus tip is clean and intact.
Stylus not charging	Charging cable or power source issue.	Ensure the MicroUSB cable is securely connected. Try a different USB port or power adapter.
Stylus turns off unexpectedly	Low battery.	Recharge the stylus fully.

5. SPECIFICATIONS

Key technical specifications for the BoxWave AccuPoint Active Stylus:

- **Item Weight:** 1.3 ounces
- **Batteries:** 1 Product Specific battery (included)
- **Battery Average Life Standby:** 12 Hours
- **Compatible Devices:** Smartphone (e.g., Oppo Find N3)
- **Color:** Metallic Silver
- **Material:** Aluminum, Plastic, Metal

- **Manufacturer:** BoxWave
- **Country of Origin:** China



Image: A detailed view of the AccuPoint Active Stylus, showcasing its design and metallic silver color.

6. WARRANTY AND SUPPORT

For technical assistance, BoxWave offers limited 3rd party tech support for your device (up to 3 inquiries via messaging). Please note that this support is not affiliated with or endorsed by Oppo.

Specific warranty details for this product are not provided in this manual. Please refer to the product packaging or the

manufacturer's official website for warranty information.