

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Cygnett](#) /
- › [Cygnett Chargeup Pocket 10,000mAh Power Bank User Manual](#)

Cygnett BSA-MPA-CY4406PBCHE

Cygnett Chargeup Pocket 10,000mAh Power Bank User Manual

Model: BSA-MPA-CY4406PBCHE

[Overview](#)

[Package Contents](#)

[Features](#)

[Setup](#)

[Operating](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty](#)

[Support](#)

1. OVERVIEW

The Cygnett Chargeup Pocket 10,000mAh Power Bank is a portable charging solution designed for convenience and efficiency. It features integrated charging cables, including one Lightning cable for Apple devices and one USB-C cable for Android and other USB-C compatible devices. This power bank is pre-charged and ready for use out of the box, providing up to 2.6 phone charges.



Image: The Cygnett Chargeup Pocket 10,000mAh Power Bank shown with its integrated Lightning and USB-C charging cables extended from the sides.

2. PACKAGE CONTENTS

Please check the package for the following items:

- Cygnett Chargeup Pocket 10,000mAh Power Bank (Model: BSA-MPA-CY4406PBCHE)
- User Manual (this document)

3. KEY FEATURES

- **Integrated Charging Cables:** Avoid the hassle of carrying separate cables. The power bank features discreetly built-in Lightning and USB-C charging cables.
- **Pocket-Size Portability:** Its compact design allows for easy transport, fitting conveniently into pockets, handbags, or backpacks.
- **Apple MFi Certified Lightning Cable:** The integrated Lightning cable is Apple certified (MFi), ensuring safe and efficient charging for your iPhone, iPad, and AirPods.
- **Versatile USB-C Charging:** The integrated USB-C cable quickly charges popular USB-C devices such as Android phones, tablets, and earbuds. This same integrated USB-C cable can then be used to recharge the Power Bank by plugging directly into a USB-C power source like a wall charger.





Image: The Cygnett Chargeup Pocket 10,000mAh Power Bank with its integrated Lightning and USB-C cables neatly stored within the device's casing.



Image: The Cygnett Chargeup Pocket 10,000mAh Power Bank is shown charging two smartphones (one iPhone, one Samsung) while resting on a suitcase, demonstrating its portability and multi-device charging capability.

4. SETUP AND INITIAL USE

The Cygnett Chargeup Pocket Power Bank comes pre-charged and is ready for immediate use. However, for optimal performance and battery longevity, it is recommended to fully charge the power bank before its first extensive use.

4.1 Identifying Components

- **Integrated Lightning Cable:** Located on one side, designed for Apple devices.
- **Integrated USB-C Cable:** Located on the opposite side, designed for USB-C devices and for recharging the power bank itself.
- **LED Indicator Lights:** Typically located on the top surface, these lights indicate the remaining battery charge.



Image: A top-down view of the Cygnett Chargeup Pocket 10,000mAh Power Bank, clearly showing the four LED indicator lights and both integrated charging cables extended.

4.2 Initial Charging of the Power Bank

1. Locate the integrated USB-C cable on the side of the power bank.
2. Extend the USB-C cable from its storage slot.
3. Plug the USB-C connector into a compatible USB-C wall charger or a USB-C port on a computer.
4. The LED indicator lights will illuminate to show the charging progress. All four lights will be solid when fully charged.
5. Once fully charged, disconnect the power bank and neatly tuck the USB-C cable back into its slot.

5. OPERATING INSTRUCTIONS

5.1 Charging Your Devices

1. Identify the correct integrated cable for your device:
 - For Apple devices (iPhone, iPad, AirPods): Use the Lightning cable.
 - For Android phones, tablets, or other USB-C devices: Use the USB-C cable.

2. Gently pull out the appropriate integrated cable from its storage slot.
3. Connect the cable's connector firmly into your device's charging port.
4. The power bank will automatically begin charging your device. The LED indicator lights on the power bank will show its remaining charge level.
5. Once your device is charged, disconnect the cable and neatly tuck it back into the power bank's slot.

5.2 Recharging the Power Bank

To recharge the Cygnett Chargeup Pocket Power Bank:

1. Extend the integrated USB-C cable from the power bank.
2. Plug the USB-C connector into a USB-C power source (e.g., a wall adapter, computer USB-C port).
3. The LED indicator lights will flash to indicate charging. When all four lights are solid, the power bank is fully charged.
4. Disconnect the power bank from the power source and store the USB-C cable.

5.3 LED Indicator Lights

The four LED lights on the power bank indicate the remaining battery capacity:

- **4 Lights Solid:** 75% - 100% charge remaining
- **3 Lights Solid:** 50% - 75% charge remaining
- **2 Lights Solid:** 25% - 50% charge remaining
- **1 Light Solid:** 0% - 25% charge remaining (recharge soon)
- **Flashing Lights:** Indicates the power bank is currently being charged.

6. CARE AND MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surface of the power bank. Do not use liquid cleaners or aerosols.
- **Storage:** Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Longevity:** To prolong battery life, avoid fully discharging the power bank frequently. It is best to recharge it when it reaches 25% charge. If storing for extended periods, charge it to about 50-70% every few months.
- **Avoid Damage:** Do not drop, puncture, or disassemble the power bank. Keep it away from water and high humidity.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Power bank not charging device.	Cable not properly connected; device not compatible; power bank is depleted.	Ensure cables are firmly connected. Verify device compatibility. Recharge the power bank.
Power bank not recharging.	USB-C cable not connected properly; power source issue; faulty cable.	Ensure USB-C cable is fully inserted into a working USB-C power source. Try a different wall adapter or USB-C port.
Slow charging.	Device drawing high power; cable issue; power bank low on charge.	Ensure your device is not running power-intensive applications. Fully charge the power bank.
LED indicators not lighting up.	Power bank is fully depleted or damaged.	Attempt to recharge the power bank for an extended period. If still unresponsive, contact support.

8. PRODUCT SPECIFICATIONS

Feature	Detail
Model Name	BSA-MPA-CY4406PBCHE
Battery Capacity	10,000 Milliamp Hours (mAh)
Battery Cell Composition	Lithium Polymer
Integrated Connectors	Lightning, USB Type C
Special Features	Built-In Cables
Color	Black
Item Weight	240 Grams
Package Dimensions	15 x 9 x 4 cm
Recommended Use	Phone charging

9. WARRANTY INFORMATION

Cygnett products are manufactured to high quality standards and are covered by a limited warranty against defects in materials and workmanship. The specific warranty period and terms may vary by region and product. For detailed warranty information, including terms, conditions, and how to make a claim, please refer to the official Cygnett website or the warranty card included with your purchase.

10. CUSTOMER SUPPORT

Should you encounter any issues or have questions regarding your Cygnett Chargeup Pocket 10,000mAh Power Bank that are not covered in this manual, please contact Cygnett customer support.

You can find further assistance, FAQs, and contact details on the official Cygnett website:

Visit the Cygnett Store on
Amazon

Note: For the most up-to-date support information, always refer to the manufacturer's official website.