

[manuals.plus](#) /› [Genius](#) /› [Genius NX-8006S Type-C Silent Wireless Mouse User Manual](#)

Genius NX-8006S

Genius NX-8006S Type-C Silent Wireless Mouse User Manual

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Genius NX-8006S Type-C Silent Wireless Mouse. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

PACKAGE CONTENTS

- Genius NX-8006S Type-C Silent Wireless Mouse
- Type-C USB Receiver
- AA Battery (may be pre-installed or included separately)
- User Manual (this document)

SETUP GUIDE

1. Battery Installation

Locate the battery compartment on the underside of the mouse. Open the cover and insert one AA battery, ensuring the polarity (+/-) matches the diagram inside the compartment. Close the battery cover securely.

2. Connect the Type-C USB Receiver

Plug the Type-C USB receiver into an available Type-C port on your computer (PC, laptop, or compatible device). The operating system should automatically detect and install the necessary drivers.



Image: The Genius NX-8006S Type-C Silent Wireless Mouse shown alongside its compact Type-C USB receiver. The mouse is black with a scroll wheel and two main buttons, and the receiver is also black with the Genius logo.

3. Power On the Mouse

Locate the power switch on the underside of the mouse. Slide the switch to the "ON" position. The mouse is now ready for use.

OPERATING INSTRUCTIONS

Basic Functions

- **Left Button:** Primary click function, used for selecting items, opening files, and executing commands.
- **Right Button:** Secondary click function, typically used to open context menus.
- **Scroll Wheel:** Used for scrolling through documents and web pages. It can also function as a middle button when pressed.

Silent Click Feature

The Genius NX-8006S features silent click buttons, designed to reduce clicking noise for a quieter working environment.

MAINTENANCE

Cleaning

To clean your mouse, gently wipe the surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners. Ensure no liquid enters the mouse's internal components.

Battery Replacement

When the mouse performance degrades or it stops responding, it may be time to replace the AA battery. Follow the battery installation steps outlined in the Setup Guide.

Storage

When not in use for extended periods, it is recommended to turn off the mouse using the power switch to

conserve battery life. Store the mouse and receiver in a dry, cool place.

TROUBLESHOOTING

Mouse Not Responding

- Ensure the mouse is powered on.
- Check if the battery is correctly installed and has sufficient charge. Replace if necessary.
- Verify that the Type-C USB receiver is securely plugged into a working port on your computer.
- Try plugging the receiver into a different Type-C port.
- Restart your computer.

Erratic Cursor Movement

- Ensure the mouse is used on a clean, non-reflective surface.
- Clean the optical sensor on the underside of the mouse if it appears obstructed.
- Check for any strong electromagnetic interference nearby.

Connection Issues

If the mouse loses connection frequently, ensure the receiver is not too far from the mouse and there are no large metallic objects obstructing the wireless signal.

SPECIFICATIONS

Model	NX-8006S
Brand	Genius
Connectivity	Wireless (Type-C USB Receiver)
Movement Detection	Optical
Number of Buttons	3 (Left, Right, Scroll Wheel Click)
Special Feature	Silent Click, LED Lights
Color	Black
Power Source	Battery Powered (1x AA)
Operating System Compatibility	Linux, Windows 7, Windows XP (and generally newer Windows versions)
Product Dimensions (LxWxH)	2.48 x 3.94 x 1.57 inches
Item Weight	4.2 ounces

SAFETY INFORMATION

- Do not expose the mouse to extreme temperatures or humidity.
- Avoid dropping or subjecting the mouse to strong impacts.

- Keep out of reach of children.
- Dispose of batteries according to local regulations.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or visit the official Genius website. Contact details for customer service can typically be found on the manufacturer's website.

© 2024 Genius. All rights reserved.