

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Eeese air care](#) /
- › [Eeese Hugo 13 L Electric Dehumidifier User Manual](#)

Eeese air care Parent_EESEE

Eeese Hugo 13 L Electric Dehumidifier User Manual

Model: Parent_EESEE | Brand: Eeese air care

1. INTRODUCTION

Thank you for choosing the Eeese Hugo 13 L Electric Dehumidifier. This appliance is designed to efficiently remove excess moisture from the air, creating a more comfortable and healthier indoor environment. It is suitable for rooms up to 60 m² and features quiet operation, an automatic mode, and a dedicated laundry drying function. Please read this manual thoroughly before operating the unit to ensure safe and optimal performance.

2. SAFETY INSTRUCTIONS

Always observe the following basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- **Electrical Safety:** Ensure the power supply matches the rating label on the unit. Do not operate with a damaged cord or plug.
- **Placement:** Place the unit on a stable, level surface. Maintain a minimum clearance of 40 cm around the unit for proper airflow. Do not block air inlets or outlets.
- **Water Tank:** Always empty the water tank before moving the unit. Do not drink the collected water.
- **IPX4 Rating:** This unit has an IPX4 rating, meaning it is protected against splashing water from any direction. It is suitable for use in bathrooms or kitchens, but do not submerge the unit in water.
- **Child Safety:** The Eeese Hugo 13 L is equipped with child safety features. Keep children and pets away from the unit during operation. Do not allow children to play with the appliance.
- **Maintenance:** Unplug the unit before cleaning or performing any maintenance.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Eeese Hugo 13 L Dehumidifier.



Figure 3.1: Front view of the Eeese Hugo 13 L electric dehumidifier, highlighting its sleek white design and the Eeese logo.



Figure 3.2: A view from the top-front, showcasing the dehumidifier's control panel and air outlet grille. The digital display is visible.



Figure 3.3: This close-up image details the control panel of the Eeese Hugo 13 L dehumidifier, including the digital display showing "35" (likely humidity level) and various control buttons. The air outlet grille is prominent.



Figure 3.4: The rear view of the dehumidifier, illustrating the air intake grille and the transparent water level indicator for the collection tank.

4. SETUP

Follow these steps to set up your dehumidifier for first use.

1. **Unpacking:** Carefully remove the dehumidifier from its packaging. Retain the packaging for future storage or transport.
2. **Placement:** Choose a suitable location for the dehumidifier. For optimal performance, place it in the center of the room or the area with the highest humidity. Ensure there is a minimum clearance of 40 cm (15.7 inches) around all sides of the unit to allow for proper air circulation. The unit has a projection distance of 20 cm (7.9

inches).

3. **Power Connection:** Plug the power cord into a grounded electrical outlet. Ensure the voltage matches the specifications of the unit.



Figure 4.1: The dehumidifier is shown in a modern living room, demonstrating its compact size and how it blends into a home environment.




Figure 4.2: This image displays the dehumidifier in a bathroom, emphasizing its suitability for humid areas and its IPX4 splash protection.

5. OPERATING INSTRUCTIONS

Learn how to operate your Eeese Hugo 13 L Dehumidifier effectively.

5.1 Control Panel

Refer to Figure 3.3 for a detailed view of the control panel. The digital display shows the current humidity level or other settings. Buttons typically include Power, Mode Selection, Timer, and Humidity Setting.

5.2 Operating Modes

- **Automatic Mode:** The dehumidifier will automatically adjust its operation based on the ambient humidity to maintain a comfortable level. This is the recommended mode for general use.
- **Laundry Drying Mode:** This mode is designed to quickly dry clothes indoors by continuously operating at a high fan speed and dehumidification setting. Place the unit near the laundry for best results.

5.3 Water Tank Management

The unit will automatically shut off when the water tank is full. Empty the tank by carefully pulling it out from the unit,

discarding the collected water, and then reinserting it firmly until it clicks into place. Ensure the tank is properly seated to resume operation.

6. MAINTENANCE

Regular maintenance ensures the longevity and efficiency of your dehumidifier.

6.1 Cleaning the Unit

- Always unplug the dehumidifier before cleaning.
- Wipe the exterior with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Clean the air inlet and outlet grilles with a soft brush or vacuum cleaner to remove dust accumulation.

6.2 Filter Cleaning

The air filter should be cleaned regularly (e.g., every two weeks or as needed) to maintain optimal performance.

1. Turn off and unplug the unit.
2. Locate and remove the air filter (typically at the back or side of the unit).
3. Clean the filter with a vacuum cleaner or wash it gently with warm, soapy water.
4. Rinse thoroughly and allow the filter to air dry completely before reinserting it into the unit.

6.3 Water Tank Cleaning

Clean the water tank periodically to prevent mold and mildew growth.

- Remove the water tank from the unit.
- Wash the tank with mild detergent and water.
- Rinse thoroughly and dry before placing it back into the dehumidifier.

7. TROUBLESHOOTING

If you encounter issues with your dehumidifier, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Unit does not turn on	No power supply Water tank full or not properly inserted	Check power cord and outlet Empty and reinsert water tank correctly
No dehumidification	Air filter clogged Room temperature too low Air inlets/outlets blocked	Clean the air filter Ensure room temperature is above 5°C (41°F) Clear any obstructions
Unit is noisy	Unit not on a level surface Loose parts	Place on a flat, stable surface Contact customer support if noise persists
Water leaks	Water tank not properly seated Drain hose (if used) is kinked or blocked	Reinsert water tank firmly Check and clear drain hose

8. SPECIFICATIONS

Detailed technical specifications for the Eeese Hugo 13 L Dehumidifier.

Specification	Value
Model Number	Parent_EEERE
Product Dimensions (W x D x H)	20 x 38 x 44 cm (7.9 x 15 x 17.3 inches)
Dehumidification Capacity	13 L/day (at 30°C, 80% RH)
Recommended Room Size	Up to 60 m ²
Operating Mode	Automatic, Laundry Drying
Color	White
Minimum Clearance Required	40 cm (15.7 inches)
Projection Distance	20 cm (7.9 inches)
IP Rating	IPX4 (Splash-proof)



Figure 8.1: A side profile of the Eeese Hugo 13 L dehumidifier, showing its slim design and integrated handle for portability.



Figure 8.2: A detailed rear view showing the product's rating label with technical specifications and compliance marks (CE, RoHS).

9. WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your product or visit the official Eeese air care website. If you require technical assistance or have questions not covered in this manual, please contact Eeese air care customer support.



Figure 9.1: The dehumidifier is visible in a room where an adult is playing with a child, subtly illustrating the product's child safety features and quiet operation.