

[manuals.plus](#) /

› [Nexus](#) /

› [Nexus 87910 Thrust Prostate Edition Massager User Manual](#)

Nexus 87910

Nexus 87910 Thrust Prostate Edition Massager User Manual

Model: 87910

1. PRODUCT OVERVIEW

The Nexus 87910 Thrust Prostate Edition is a sophisticated device designed for prostate and perineum massage. It features both thrusting and vibrating functions, controlled by a slimline remote. Constructed from 100% body-safe silicone, this device is also waterproof and rechargeable, offering versatile use.





Image 1: The Nexus 87910 Thrust Prostate Edition massager, showcasing its ergonomic design and control buttons on the base.

Key Features:

- Thrusting and vibrating functions for comprehensive massage.
- 3 distinct thrusting speeds.
- 6 varied vibrating modes.
- Waterproof and submersible design (IPX7 standard: up to 1 meter for 30 minutes).
- USB rechargeable for convenience.
- Ergonomically contoured shaft for comfortable use.
- Constructed from 100% body-safe silicone.
- Includes a slimline remote control with an 8-meter range.

2. SAFETY INFORMATION

Please read all safety instructions before using the Nexus 87910 device. Failure to follow these instructions may result in injury or damage to the product.

- **For Adult Use Only:** This product is intended for adult use only.
- **Material Safety:** The device is made from 100% body-safe silicone. If you experience any irritation, discontinue use immediately.
- **Lubrication:** Always use a water-based lubricant with silicone products. Oil-based lubricants can damage silicone.
- **Cleaning:** Clean the device thoroughly before and after each use with warm water and a mild, toy-safe soap or specialized toy cleaner.
- **Water Resistance:** The device and remote are waterproof to IPX7 standards, meaning they can be submerged up to 1 meter (3 feet) for 30 minutes. Do not exceed these limits.
- **Charging:** Use only the provided USB charging cable. Do not use the device while it is charging.
- **Storage:** Store the device in a clean, dry place, away from direct sunlight and extreme temperatures. Keep out of reach of children.
- **Medical Conditions:** Consult a healthcare professional before use if you have any medical conditions or concerns.

3. SETUP AND CHARGING

3.1 Initial Charge

Before first use, fully charge the Nexus 87910 device and its remote control.

1. Locate the charging port on the device and the remote. These are typically small, discreet ports.
2. Connect the provided USB charging cable to the device/remote and then to a USB power source (e.g., computer, USB wall adapter).
3. The indicator light will illuminate during charging. Refer to the product packaging or quick start guide for specific light behaviors (e.g., solid light for charging, blinking for low battery, off for full charge).
4. A full charge takes approximately 3 hours and provides up to 1 hour of play time.
5. Once fully charged, disconnect the cable and ensure the charging port is sealed (if applicable) to maintain waterproofing.



Image 2: The slimline remote control for the Nexus 87910, showing the power button and function controls.

4. OPERATING INSTRUCTIONS

4.1 Powering On/Off

- **Device:** Press and hold the power button on the device's base for a few seconds to turn it on or off.
- **Remote:** Press and hold the power button on the remote control for a few seconds to turn it on or off. The remote will automatically pair with the device when both are powered on and within range.

4.2 Using Thrusting Modes

- Once the device is powered on, press the thrusting control button (often indicated by an arrow icon) on the remote to activate the thrusting function.
- Press the button repeatedly to cycle through the 3 available thrusting speeds.
- To turn off the thrusting function, continue cycling through the speeds until it deactivates, or power off the device.

4.3 Using Vibrating Modes

- Press the vibrating control button (often indicated by a wave icon) on the remote to activate the vibrating function.
- Press the button repeatedly to cycle through the 6 available vibrating modes.
- To turn off the vibrating function, continue cycling through the modes until it deactivates, or power off the device.

4.4 Combined Use

The thrusting and vibrating functions can be used independently or simultaneously to customize your experience. Experiment with different combinations to find your preferred settings.



Image 3: An angled view of the Nexus 87910 massager, highlighting its textured shaft and base.

5. MAINTENANCE AND CARE

5.1 Cleaning

Proper cleaning ensures hygiene and extends the product's lifespan.

- Always clean the device thoroughly before and after each use.
- Wash with warm water and a mild, antibacterial soap or a specialized toy cleaner.
- Rinse thoroughly to remove all soap residue.
- Pat dry with a lint-free cloth or allow to air dry completely before storing.
- Do not use harsh chemicals, alcohol, or petroleum-based cleaners, as these can damage the silicone.

5.2 Storage

- Store the device in a cool, dry, and dark place.
- Keep it away from other silicone products to prevent material degradation or sticking.
- Ensure the device is fully charged before long-term storage to maintain battery health.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Low battery.	Charge the device for at least 3 hours.
Remote not controlling device.	Remote battery low or out of range.	Charge the remote. Ensure remote is within 8 meters of the device. Power cycle both device and remote.
Thrusting/Vibrating function weak or inconsistent.	Low battery.	Recharge the device.
Charging indicator light not working.	Cable not properly connected or faulty charger.	Ensure cable is securely connected. Try a different USB power source or cable.

7. SPECIFICATIONS

Feature	Detail
Model Number	87910
Brand	Nexus
Material	100% Body-Safe Silicone
Color	Black
Thrusting Modes	3 Speeds
Vibrating Modes	6 Modes
Water Resistance	IPX7 (Submersible up to 1m for 30 mins)
Charging	USB Rechargeable
Charge Time	Approx. 3 hours
Play Time	Approx. 1 hour
Remote Control Range	Up to 8 meters

Feature	Detail
Total Height x Base Width	5.43 x 4.30 Inches (138 x 109mm)
Shaft Insertable Length	3.94 Inches (100mm)
Shaft Diameter (widest point)	1.50 Inches (38mm)
Product Dimensions (L x W x H)	7.24 x 7.09 x 1.97 inches
Product Weight	8.82 ounces






Image 4: Detailed diagram illustrating the dimensions of the Nexus 87910 Thrust Prostate Edition massager.


8. WARRANTY AND SUPPORT

For information regarding warranty coverage, product support, or to report any issues, please refer to the contact information provided with your purchase or visit the official Nexus website. Keep your proof of purchase for warranty claims.

Legal Disclaimer: Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. This product is not a dietary supplement.

Related Documents - 87910

	<p>Nexus Duo Plug User Manual: Features, Operation, and Care</p> <p>Comprehensive user manual for the Nexus Duo Plug, a remote-controlled vibrating anal plug. Learn about charging, operation modes, cleaning, storage, and safety guidelines.</p>
	<p>Nexus Ride User Manual: Features, Operation, and Care</p> <p>Explore the Nexus Ride personal massager with this comprehensive user manual. Learn about its features, charging, modes, usage tips, cleaning, and safety guidelines for an optimal experience.</p>
	<p>Nexus Bendz Probe Edition User Manual</p> <p>User manual for the Nexus Bendz Probe Edition, detailing its features, usage, charging, cleaning, storage, and safety precautions. Includes information on vibration modes and tips for use.</p>
	<p>Nexus 7 (1st Generation) Battery Replacement Guide</p> <p>Step-by-step instructions for replacing the battery in your Nexus 7 (1st Generation) tablet. Learn how to safely open the device and swap out the old battery.</p>
	<p>Nexus NX1000 Handheld VHF Radio User Manual</p> <p>Comprehensive user manual for the Nexus NX1000 Handheld VHF Radio, covering installation, operation, features, specifications, troubleshooting, and warranty information. This guide provides essential details for safe and effective use of the marine VHF transceiver.</p>
	<p>WS 6832 Weather Station User Manual and Instructions</p> <p>Comprehensive user manual for the Nexus WS 6832 weather station, detailing setup, features like time synchronization, temperature monitoring, weather forecasting, alarm functions, and troubleshooting.</p>



[\[pdf\] User Manual](#)

Sony Icf Sw100 Manual Pdf RadioManual eu NASWA 1994 06 worldradiohistory Archive DX 90s |||
INA--V1 the JOURNAL NORTH AMERICAN SHORT WAVE ASSOCIATION VolJ me
XXXIV. Nu mber 6 June. 1994 ... r Bill Crawford 282 pages 13.95 Limelight Editions
18 East 30th Street New York, NY 10016 ISBN 0-87910-142-3 The early days of
broadcast radio were really wild. Folks were just discovering the pote...
lang:en **score:12** filesize: 2.71 M page_count: 60 document date: 2019-10-08