

Hama 00205321

Hama Bluetooth Audio Adapter Link.it solo (Model 00205321) Instruction Manual

1. INTRODUCTION

The Hama Bluetooth Audio Adapter Link.it solo (Model 00205321) allows you to upgrade your existing stereo system or active speakers with Bluetooth connectivity. Enjoy high-quality audio content from your mobile phone, tablet, or other Bluetooth-enabled devices. This versatile adapter features a 3.5 mm jack for universal connection, a USB-C port for power, and a microSD slot for direct playback of audio files.

This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and keep it for future reference.

2. WHAT'S IN THE BOX

Please check the contents of your package to ensure all items are present:

- 1x Hama Bluetooth Audio Adapter "Link.it solo"
- 1x USB Power Cable (USB-A to USB-C, 0.24 m)
- 1x Audio Cable (3.5 mm jack to 3.5 mm jack, 0.42 m)
- 1x User Manual



Image: The Hama Bluetooth Audio Adapter Link.it solo shown alongside its included USB-A to USB-C power cable and 3.5mm jack to 3.5mm jack audio cable.

3. PRODUCT FEATURES

- **Bluetooth Connectivity:** Seamlessly stream audio from your smartphone, tablet, or other Bluetooth devices to your stereo system or active speakers.
- **Universal Audio Output:** Connects to audio systems via a standard 3.5 mm AUX jack.
- **MicroSD Slot:** Play playlists and audiobooks directly from a microSD card (up to 64 GB) in excellent sound quality.
- **USB-C Power Supply:** Conveniently powered via USB-C, allowing connection to a USB port on a power strip, stereo system, or an external power supply.
- **Multi-Device Pairing:** Supports connection of two mobile phones simultaneously, with automatic reconnection to previously paired devices.



USB C

microSD



Image: A top-down view of the Hama Bluetooth Audio Adapter Link.it solo, highlighting its key features: Bluetooth connectivity, USB-C power input, and a microSD card slot. The central play/pause button is also visible.

4. SAFETY INFORMATION

Please observe the following safety guidelines:

- This device uses radio frequency and may interfere with other wireless devices.
- Do not expose the device to extreme temperatures or moisture.
- Do not use the device if operating instructions are not fully understood.
- Dispose of plastic responsibly.
- To avoid data loss, only use microSD cards that are formatted and supported by your device.

5. SETUP

5.1 Connecting to Power

1. Connect the supplied USB-A to USB-C cable to the Type-C port on the adapter.
2. Plug the USB-A end of the cable into a suitable USB power source (e.g., a USB port on your stereo system, a USB wall adapter, or a power strip with USB ports). The adapter requires 5 Volts (DC).

5.2 Connecting to an Audio System

1. Connect one end of the supplied 3.5 mm jack audio cable to the AUX port on the Bluetooth adapter.
2. Connect the other end of the 3.5 mm jack audio cable to the AUX input (or similar audio input) on your stereo system or active speakers.
3. Ensure your stereo system or speakers are set to the correct input source (e.g., AUX, Line In).



Image: A user connecting the 3.5mm audio cable from the Hama Bluetooth adapter to the AUX input of a stereo receiver, demonstrating the audio connection setup.

5.3 Bluetooth Pairing

1. Once powered on, the adapter will automatically enter Bluetooth pairing mode, indicated by a blinking light on the device.
2. On your mobile phone, tablet, or other Bluetooth device, go to the Bluetooth settings and enable Bluetooth.
3. Search for available devices. The Hama Bluetooth adapter should appear in the list (e.g., as "Link.it solo").

4. Select the adapter to pair. Once paired, the indicator light on the adapter will become solid.
5. The adapter supports connecting two mobile phones simultaneously. Pair the second device following the same steps.




Image: A visual representation of how various devices like smartphones, tablets, and laptops can connect wirelessly via Bluetooth to the Hama adapter, which then transmits audio to a stereo system via a wired connection.

5.4 Inserting a MicroSD Card

1. Locate the TF (microSD) slot on the side of the adapter.
2. Gently insert a formatted microSD card (up to 64 GB) into the slot until it clicks into place.



Image: A close-up of a hand inserting a microSD card into the designated TF slot on the side of the Hama Bluetooth Audio Adapter.

6. OPERATING

6.1 Bluetooth Audio Playback

1. Ensure the adapter is powered on and successfully paired with your Bluetooth device.
2. Start playing audio on your connected device (e.g., music app, streaming service).
3. The audio will be transmitted wirelessly to the adapter and then played through your connected stereo system or speakers.
4. Use the controls on your connected device to manage playback (play, pause, skip tracks, volume). The large central button on the adapter can also be used for play/pause functionality.



Image: A setup showing both a smartphone and a tablet simultaneously connected to the Hama Bluetooth adapter, which is then linked to a stereo system, illustrating the multi-device playback capability.

6.2 microSD Card Playback

1. Insert a microSD card with audio files into the TF slot (refer to Section 5.4).
2. The adapter will automatically detect the microSD card and begin playing audio files.
3. Use the central button on the adapter for play/pause control.

7. MAINTENANCE

To ensure the longevity and optimal performance of your Hama Bluetooth Audio Adapter, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the device. Do not use abrasive cleaners, solvents, or strong detergents.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid dropping the device or subjecting it to strong impacts.
- **Moisture:** Keep the device away from water and high humidity.

8. TROUBLESHOOTING

If you encounter issues with your Hama Bluetooth Audio Adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power/Device not turning on	USB power cable not connected properly or power source is faulty.	Ensure the USB-C cable is securely connected to both the adapter and a working USB power source. Try a different USB port or power adapter.
Cannot pair via Bluetooth	Adapter not in pairing mode; Bluetooth off on source device; device too far.	Ensure the adapter's indicator light is blinking (pairing mode). Turn Bluetooth off and on again on your source device. Move the source device closer to the adapter.
No sound output	Audio cable not connected; incorrect input selected on stereo; volume too low.	Verify the 3.5 mm audio cable is securely connected to both the adapter and your stereo system. Select the correct AUX/Line In input on your stereo. Increase volume on both the source device and the stereo system.
MicroSD card not playing	Card not inserted correctly; unsupported format; card capacity too large.	Reinsert the microSD card firmly. Ensure the card is formatted correctly and contains supported audio file types. Use a microSD card up to 64 GB.
Intermittent Bluetooth connection	Interference; device too far; low battery on source device.	Move the adapter and source device away from other wireless devices. Ensure the source device is within range (typically up to 10 meters). Charge your source device if its battery is low.

9. SPECIFICATIONS

Feature	Detail
Model Name	00205321
Brand	Hama
Connectivity Technology	Bluetooth
Power Source	Corded Electric (USB-C)
Voltage	5 Volts (DC)
Material	Plastic
Color	Black
Supported Media Type	Bluetooth, MicroSD
Audio Input	3.5mm AUX

Feature	Detail
Audio Output Mode	Stereo
Number of Channels	2
Compatible Devices	Speaker, HiFi System, Smartphone, Tablet, TV
Control Method	Push Button
Item Weight	84.26 Grams



Image: The Hama Bluetooth Audio Adapter Link.it solo displaying its physical dimensions: 7.5 cm in length, 6.4 cm in width, and 2 cm in height.

10. WARRANTY AND SUPPORT

Warranty information for your Hama Bluetooth Audio Adapter Link.it solo is typically provided with your purchase documentation or can be found on the official Hama website. For technical support, troubleshooting assistance beyond this manual, or warranty claims, please refer to the contact information provided by Hama or your retailer.

Please retain your proof of purchase for warranty purposes.