

Enerwow P400

Enerwow P400 Portable Power Bank User Manual

Model: P400

1. INTRODUCTION

Thank you for choosing the Enerwow P400 Portable Power Bank. This high-capacity power bank is designed to provide reliable and fast charging for your electronic devices on the go. With its 40000mAh capacity, PD 30W, and QC 4.0 fast charging capabilities, it ensures your devices stay powered throughout the day. Please read this manual carefully before use to ensure optimal performance and safety.

2. SAFETY INFORMATION

To prevent injury or damage to your device, please observe the following safety precautions:

- Do not expose the power bank to extreme temperatures (above 60°C/140°F) or direct sunlight.
- Do not immerse the power bank in water or other liquids.
- Do not disassemble, open, or attempt to repair the power bank yourself.
- Keep out of reach of children.
- Avoid dropping or subjecting the power bank to strong impacts.
- Use only certified cables and chargers for optimal performance and safety.
- Dispose of the power bank according to local regulations. Do not dispose of it with household waste.

Safety for Your Outdoor Electricity Use



This image illustrates the multi-protection system of the Enerwow Power Bank, including over-voltage, over-charge, over-discharge, high temperature, short circuit, and over-power protection, ensuring safe operation.

3. PRODUCT OVERVIEW

The Enerwow P400 Portable Power Bank features a sleek design with multiple ports and an intuitive LED display.



A front-angle view of the Enerwow P400 Portable Power Bank, showcasing its compact black design and the digital LED display.

Components:

- **Digital LED Display:** Shows the remaining battery percentage.
- **USB-C Port (Input/Output):** For charging the power bank and fast charging compatible devices.
- **USB-A Ports (Output):** Two ports for charging various USB-powered devices.
- **Power Button:** To check battery level or initiate charging.

Large Capacity 40000mAh Power Bank



This image depicts the multiple output ports (USB-C and two USB-A) and input ports (USB-C and Micro-USB), highlighting the ability to charge three devices simultaneously.

Accurate Digital LED Display



A close-up view of the digital LED display on the Enerwow Power Bank, clearly showing the battery percentage for accurate tracking of electricity usage.

4. SETUP

Initial Charging:

Before first use, it is recommended to fully charge your Enerwow P400 Power Bank. This ensures the battery is calibrated and ready for optimal performance.

1. Connect the power bank to a wall charger using a USB-C cable. The USB-C port supports input charging.
2. The digital LED display will show the charging progress, indicating the battery percentage

increasing.

3. The power bank is fully charged when the display shows "100%".

Charge New Devices with Your Cables Directly



This image illustrates the versatile USB-C port on the Enerwow Power Bank, functioning as both an input for charging the power bank itself and an output for charging external devices.

5. OPERATING INSTRUCTIONS

Charging Your Devices:

The Enerwow P400 Power Bank can charge up to three devices simultaneously using its USB-C and two USB-A output ports.

1. Connect your device to one of the power bank's output ports (USB-C or USB-A) using a compatible charging cable.
2. The power bank will automatically begin charging your device. The LED display will show the remaining battery percentage.
3. For optimal fast charging, use the USB-C port with a PD (Power Delivery) compatible cable and device.



This image illustrates the PD 30W fast charging capability of the Enerwow Power Bank, showing a smartphone charging rapidly from the power bank, reaching 55% in 30 minutes.

2024 USB-C Input&Output for All the New Devices



**Enerwow USB-C
Input&Output**



**Other USB-C Input only
Fail to charge**



A visual representation of the 40000mAh capacity of the Enerwow Power Bank, indicating the approximate number of charges it provides for various devices such as iPhone 15 (8 charges), Google Pixel 6a (6 charges), and Samsung Galaxy S23 (5 charges).

Recharging the Power Bank:

When the power bank's battery level is low, recharge it using either the USB-C or Micro-USB input port.

1. Connect the power bank to a wall charger or computer USB port using a compatible cable (USB-C or Micro-USB).
2. The LED display will show the charging status.
3. Disconnect the power bank once it reaches 100% to prolong battery life.

6. MAINTENANCE

- Clean the power bank with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, charge the power bank to approximately 50-70% every three months to maintain battery health.

7. TROUBLESHOOTING

- **Power bank not charging:** Ensure the charging cable is securely connected to both the power bank and the power source. Try a different cable or wall adapter.
- **Device not charging from power bank:** Check if the power bank has sufficient charge. Ensure the charging cable is securely connected to both the power bank and your device. Try a different cable or output port.
- **Slow charging:** Ensure you are using a fast-charging compatible cable and your device supports fast charging protocols (PD/QC). Some devices may charge slower if multiple devices are connected simultaneously.
- **LED display not working:** Press the power button briefly to activate the display. If it remains off, the power bank might be fully discharged or require service.

8. SPECIFICATIONS

Feature	Detail
Model Number	P400
Battery Capacity	40000 Milliamp Hours
Product Dimensions	6.8 x 2.95 x 1.4 inches
Item Weight	14.4 ounces
Batteries	2 Lithium Ion batteries (included)
Connector Type	USB Type C
Manufacturer	Shenzhen MiMan Technology Co., Ltd
Date First Available	March 14, 2024

9. WARRANTY AND SUPPORT

Enerwow is committed to providing high-quality products and customer satisfaction.

- **Return Service:** Enjoy a 365-day return service for your peace of mind.
- **Online Response:** Our customer support team is available for 24-hour online response to assist with any inquiries or issues.

For further assistance, please visit the official Enerwow store or contact customer support through your purchase platform.

© 2024 Enerwow. All rights reserved.

Related Documents - P400

	<p>Mota P400 Spray Gun: Manual, Specifications, and Parts List</p> <p>Comprehensive guide for the Mota P400 spray gun, including safety precautions, technical specifications, usage instructions, maintenance, and a detailed parts list. Covers models P413, P415, P418, and variations.</p>
	<p>MAST P400 Tattoo Power Supply User Guide</p> <p>A comprehensive guide to the MAST P400 tattoo power supply, detailing its features, functions, and operation for both tattoo and permanent makeup.</p>
	<p>KSM Communication Protocol v3.0 - Koolance</p> <p>Technical documentation detailing the Koolance KSM Communication Protocol v3.0, including USB-serial driver information, protocol overview, example commands, and comprehensive byte-level specifications for various Koolance device variants.</p>
	<p>Honeywell Suono P400 Bluetooth Speaker Owner's Manual</p> <p>Comprehensive owner's manual for the Honeywell Suono P400 Bluetooth Speaker, covering setup, operation, features, specifications, safety precautions, and troubleshooting.</p>
	<p>BONECO P400 Air Purifier User Manual and Instructions</p> <p>Official user manual for the BONECO P400 air purifier. Provides detailed instructions for setup, operation, technical specifications, cleaning, maintenance, and troubleshooting. Learn how to maximize the performance of your BONECO P400 for cleaner, healthier air.</p>
	<p>Adesso Xtream P400 Bluetooth Multimedia Headset with Charging Dock - Quick Start Guide</p> <p>Comprehensive guide for the Adesso Xtream P400 Bluetooth Multimedia Headset, covering features, setup, troubleshooting, and warranty information. Learn how to pair your headset and resolve common issues.</p>

