

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [CristalRecord](#) /

> [CRISTALRECORD Moss LED Ceiling Fan with Retractable Blades User Manual](#)

CristalRecord 8435197439647

CRISTALRECORD Moss LED Ceiling Fan with Retractable Blades User Manual

Model: 8435197439647

Brand: CristalRecord

INTRODUCTION

Thank you for choosing the CRISTALRECORD Moss LED Ceiling Fan. This modern white ceiling fan features retractable blades, providing both efficient ventilation and integrated LED lighting for your space. It is designed for ease of use and energy efficiency, making it a perfect addition to any home or office.

This manual provides detailed instructions for installation, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your fan.

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before installation and use. Failure to follow these instructions may result in electric shock, fire, or serious personal injury.

- Always disconnect power at the main circuit breaker before installing, cleaning, or servicing the fan.
- Installation must be performed by a qualified electrician in accordance with all local and national electrical codes.
- Ensure the installation site can support the weight of the fan (approximately 6 kg).
- Do not operate the fan with damaged wiring or if the fan is visibly damaged.
- Keep hands, hair, and clothing away from the fan blades when the fan is operating.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

PACKAGE CONTENTS

Before beginning installation, ensure all components are present and undamaged. If any parts are missing or damaged, contact your retailer.

- CRISTALRECORD Moss LED Ceiling Fan Unit
- Remote Control
- Receiver
- Mounting Hardware (screws, brackets, etc.)
- Instruction Manual (this document)

SETUP AND INSTALLATION

Installation of this ceiling fan requires electrical wiring knowledge. It is highly recommended that installation be performed by a certified electrician to ensure safety and compliance with electrical codes.

Pre-Installation Checklist:

1. Turn off power at the circuit breaker.
2. Ensure the mounting box is securely fastened to the building structure and can support the fan's weight (6 kg).
3. Unpack all components and verify against the package contents list.

Installation Steps (General Guide - Consult Electrician):

1. Attach the mounting bracket to the ceiling junction box.
2. Connect the fan's electrical wires to the household wiring (Live, Neutral, Ground) according to the wiring diagram provided by the manufacturer (not included in this general manual).
3. Install the receiver for the remote control, ensuring it is properly connected to the fan and power supply.
4. Secure the fan motor assembly to the mounting bracket.
5. Attach the LED light panel and cover.
6. Ensure all connections are secure and the fan is firmly mounted before restoring power.



Image: The CRISTALRECORD Moss LED Ceiling Fan with its retractable blades in a compact state, showcasing its modern white design and integrated LED light panel.

OPERATING INSTRUCTIONS

Your CRISTALRECORD Moss LED Ceiling Fan is controlled via the included remote control. Ensure the receiver is properly installed and paired with the remote.

Remote Control Functions:

- **Power On/Off:** Press to turn the fan and light on or off.
- **Fan Speed Control:** Select from six available speeds. The DC motor ensures ultra-silent operation.
- **Light On/Off:** Independently control the LED light.
- **CCT (Correlated Color Temperature) Adjustment:** Cycle through three color temperatures: 3000K (Warm White), 4000K (Neutral White), and 6000K (Cool White).
- **Dimming:** Adjust the brightness (lumen intensity) of the LED light.
- **Breeze Function:** Activates a mode that simulates a natural breeze by varying fan speed.
- **Night Light Mode:** Sets the light to a very low brightness, suitable for ambient lighting at night.
- **Timer Function:** Set the fan to automatically turn off after 2 or 4 hours.
- **Reverse Function (Winter/Summer Mode):** Changes the direction of blade rotation.
 - **Summer Mode (Counter-clockwise):** Creates a downward airflow, producing a cooling effect.
 - **Winter Mode (Clockwise):** Creates an upward airflow, circulating warm air trapped near the ceiling.



Image: The CRISTALRECORD Moss LED Ceiling Fan highlighting its key features such as DC motor, suitable room size (13-20 m²), 5 LED light settings, 8 motor settings (likely referring to speeds and modes), and various control icons for light, fan, and timer functions.



Image: The CRISTALRECORD Moss LED Ceiling Fan installed in a bedroom setting, demonstrating its aesthetic integration and how the retractable blades appear when extended.

MAINTENANCE

Regular maintenance will help prolong the life and efficiency of your ceiling fan.

Cleaning:

- Always turn off the power at the circuit breaker before cleaning.
- Use a soft, damp cloth to clean the fan housing and blades. Do not use abrasive cleaners or solvents, as these may damage the finish.
- For the LED light panel, gently wipe with a dry or slightly damp cloth.

- Ensure the fan is completely dry before restoring power.

Bulb Recycling and Disposal:

This fan features integrated LED lighting, which is designed for long life and is not user-replaceable. For information on recycling and proper disposal of LED components or the entire unit at the end of its life, please consult local regulations and recycling centers. Do not dispose of electrical appliances with general household waste.

TROUBLESHOOTING

If you experience issues with your fan, please refer to the following common problems and solutions before contacting customer support.

Problem	Possible Cause	Solution
Fan does not operate.	No power supply. Remote control battery low/dead. Receiver not paired or faulty.	Check circuit breaker. Replace remote control batteries. Refer to pairing instructions (if applicable) or contact support.
Light does not turn on.	No power supply. Remote control battery low/dead. Light function not activated.	Check circuit breaker. Replace remote control batteries. Ensure light button on remote is pressed.
Fan makes unusual noise.	Loose screws or mounting. Blades unbalanced. Internal motor issue.	Check all mounting screws and tighten. Ensure blades are clean and free of obstructions. If noise persists, contact a qualified technician.
Remote control not working.	Batteries dead/incorrectly inserted. Obstruction between remote and receiver. Remote not paired with receiver.	Replace batteries, ensure correct polarity. Remove obstructions. Refer to pairing instructions (if applicable).

If the problem persists after attempting these solutions, please contact CristalRecord customer support.

SPECIFICATIONS

Feature	Detail
Brand	CristalRecord
Model Number	8435197439647
Product Type	LED Ceiling Fan with Retractable Blades

Feature	Detail
Color	White
Material	Steel and Glass
Voltage	220 Volts (DC)
Power Consumption (LED)	72W
Luminous Flux	7920 Lumen
Color Temperature (CCT)	3000K (Warm), 4000K (Neutral), 6000K (Cool)
Motor Type	DC (Ultra-silent)
Fan Speeds	6 Speeds
Features	Dimmable LED, Remote Control, Breeze Function, Night Light Mode, Timer (2/4 hours), Reverse Function (Winter/Summer)
Product Weight	6 kg
Installation Type	Ceiling Mount / Semi-flush Mount
Recommended Room Size	13-20 m ²

WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. CristalRecord products are manufactured to high-quality standards.

If you require technical assistance or have questions not covered in this manual, please contact CristalRecord customer support through their official website or your point of purchase.

For more information, you may visit the official CristalRecord website or contact their customer service department.