

Lovskoo mini projector hdmi

Lovskoo Mini Projector Instruction Manual

MODEL: MINI PROJECTOR HDMI

Brand: Lovskoo

Introduction

This manual provides essential information for the safe and effective use of your Lovskoo Mini Projector. Please read it thoroughly before operating the device and retain it for future reference. The projector is designed for home cinema and educational purposes, offering a portable solution for displaying content on a large screen.

What's in the Box

Upon unpacking, please verify that all the following items are included:

- 1x Portable Projector
- 1x Power Adaptor
- 1x AV cable
- 1x Remote Control
- 1x Bracket (Mini Tripod)
- 1x Manual Book

PRODUCT ACCESSORIES



Figure 1: Lovskoo Mini Projector and included accessories.

Product Overview

The Lovskoo Mini Projector is a compact and portable device designed for versatile media projection. Key features include:

- **Bright & Vibrant Display:** Offers 600 lumens brightness and an 800:1 contrast ratio.
- **Compact & Portable:** Measures approximately 5.2 x 3.4 x 2.3 inches and weighs 1.33 pounds.
- **Long Lamp Life:** Features a light source lamp bead with up to 30,000 hours of life.
- **Integrated Audio:** Includes a built-in speaker; external speakers can also be connected.
- **Multiple Connectivity Options:** Supports HDMI, USB, AV cord, and 3.5mm audio connections.



Figure 2: Top-down view of the Lovskoo Mini Projector.

MINI CONVENIENT BODY

Portable projector weighing less than 0.5kg



Figure 3: The compact size of the projector, held in a hand.



Figure 4: Projector dimensions for reference.

WE ALL HAVE WHAT YOU WANT

PROJECTOR MINI TRIPOD

Multi angle adjustment, easy to carry

Application of multiple equipment with strong applicability



Figure 5: Projector with mini tripod for multi-angle adjustment.

Your browser does not support the video tag.

Video 1: This video demonstrates the compact size and portability of the Lovskoo Mini Projector, showing it projecting various content in different home environments.

Setup

1. **Placement:** Position the projector on a stable, flat surface. Ensure there is adequate ventilation around the device. For optimal viewing, place the projector perpendicular to the projection surface.
2. **Power Connection:** Connect the power adapter to the projector's DC IN port and then plug it into a power outlet.
3. **Input Source Connection:**
 - **HDMI:** Connect an HDMI cable from your source device (e.g., laptop, game console) to the projector's HDMI port.
 - **USB:** Insert a USB drive into the USB port for direct media playback.
 - **AV:** Use the provided AV cable to connect to devices with AV output.

- **Audio Out:** For external speakers, connect a 3.5mm audio cable to the projector's audio output jack.
4. **Power On:** Press the power button on the projector or the remote control to turn on the device.
 5. **Focus Adjustment:** Rotate the focus ring near the lens until the projected image is clear and sharp.
 6. **Keystone Correction:** If the image appears trapezoidal, use the keystone correction feature (if available, typically a manual slider or digital adjustment in settings) to square the image.

Operating Instructions

1. **Selecting Input Source:** Use the 'Source' button on the remote or projector to cycle through available input options (HDMI, USB, AV).
2. **Navigation:** Use the arrow keys on the remote or projector to navigate menus and select options. The 'OK' button confirms selections.
3. **Volume Control:** Adjust the volume using the dedicated volume buttons on the remote control.
4. **Menu Settings:** Access the projector's settings menu to adjust picture mode, aspect ratio, sound settings, and other preferences.
5. **Power Off:** Press the power button once to initiate shutdown. Confirm shutdown if prompted.

SMALL BODY, BIG PICTURE

HD video, giant screen cinema

Blockbusters can also be experienced at home



Figure 6: Example of the projector displaying a large image in a home environment.

Maintenance

- **Lens Cleaning:** Use a soft, lint-free cloth specifically designed for optical lenses to gently wipe the projector lens. Avoid abrasive materials or harsh chemicals.
- **Ventilation:** Ensure the projector's ventilation ports are clear of dust and obstructions to prevent overheating. Periodically clean vents with compressed air.
- **Storage:** When not in use, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures.

DESIGN OF CONSTANT TEMPERATURE FAN

Ensure the stable operation of the system



Figure 7: Illustration of the projector's internal cooling system.

Troubleshooting

Problem	Possible Cause	Solution
No image projected	Power not connected; incorrect input source; lens cap on.	Check power connection; select correct input source; remove lens cap.
Image is blurry	Out of focus; incorrect projection distance.	Adjust the focus ring; ensure projector is within optimal projection distance (0.8-2M).
No sound	Volume too low; external speakers not connected properly; audio source issue.	Increase volume; check external speaker connection; verify audio output from source device.
Image is trapezoidal	Projector not perpendicular to screen.	Adjust keystone correction or reposition the projector.

Specifications

- **Brand:** Lovskoo
- **Model Number:** mini projector hdmi





- **Item Weight:** 1.33 pounds
- **Product Dimensions:** 5.2 x 3.4 x 2.3 inches
- **Display Resolution:** 1920 x 1080 (Full HD)
- **Brightness:** 600 lumens
- **Contrast Ratio:** 800:1
- **Projection Distance:** 0.8-2 meters (optimal performance)
- **Lamp Life:** 30,000 hours
- **Connectivity Technology:** HDMI, USB, AV
- **Special Features:** Built-in Speaker, HDMI Interface
- **Recommended Uses:** Education, Home Cinema



Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or contact the retailer. Specific warranty terms may vary.

© 2023 Lovskoo. All rights reserved.

Related Documents - mini projector hdmi

	<p>Acrojoy WiFi Projector: Frequently Asked Questions and Support</p> <p>This document provides frequently asked questions and troubleshooting tips for the Acrojoy WiFi projector. Learn how to screen mirror from iOS and Android devices, connect to various sources, adjust settings, and resolve common issues like no sound or image problems. Features include HD 1080P support, 9000 lumens, and compatibility with a wide range of devices.</p>
	<p>Pyle PRJTPOTS101 100-inch Outdoor Projector Screen User Guide</p> <p>User guide for the Pyle PRJTPOTS101 100-inch outdoor portable projector screen. Features, specifications, and assembly instructions for this HD 16:9 display with frame stand.</p>
	<p>AKASO FOCUS Mini Video Projector: Quick Reference Guide</p> <p>This guide provides essential information for operating the AKASO FOCUS Mini Video Projector. It covers projector buttons, remote control functions, power management, screen sharing methods (EZWire, EZCast, HDMI), media library access, settings configuration, and security precautions. Includes contact information for support.</p>
	<p>Fixed Frame Projector Screen Installation and Assembly Manual</p> <p>Comprehensive guide for installing and assembling your fixed frame projector screen. Includes parts list, precautions, and step-by-step instructions for a perfect setup.</p>

	<p>YZQ WiFi Video Projector User Manual - Setup, Features, and Troubleshooting</p> <p>Comprehensive user manual for the YZQ WiFi Video Projector (Model P3/Y5). Includes setup guide, interface details, technical specifications, connection instructions for iOS and Android, and troubleshooting tips.</p>
	<p>Yoton Projector Y3 Frequently Asked Questions and Solutions</p> <p>Find solutions to common issues with the Yoton Projector Y3, including no signal, no sound, phone mirroring problems, black dots, overheating, remote control malfunctions, and blurry images. Contact Yoton support for further assistance.</p>