### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- > ELEPHAS /
- > ELEPHAS Mini Projector BL108 User Manual

### **ELEPHAS BL108**

# **ELEPHAS Mini Projector BL108 User Manual**

Model: BL108

# INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your ELEPHAS Mini Projector, model BL108. Please read this manual thoroughly before using the projector to ensure proper function and to maximize your viewing experience.



Figure 1: ELEPHAS Mini Projector BL108. This image displays the front of the white projector, highlighting the main projection lens on the left and a smaller sensor on the right, likely for auto-focus or keystone correction.

# PACKAGE CONTENTS

Verify that all items are present in the package:

- ELEPHAS Mini Projector BL108
- HDMI Cable
- Power Adapter
- · Remote Control
- User Manual (this document)
- Lens Cleaning Tool (if included)

### **SPECIFICATIONS**

Feature	Detail
Model	BL108
Display Technology	DLP
Native Resolution	720P (1280 x 720)
Brightness	500 ANSI Lumens
Projection Size	Up to 200 inches
Battery Capacity	3500MAH*2 (approx. 2.5 hours playback)
Wireless Connectivity	2.4G/5G WiFi, Bluetooth
Keystone Correction	40° Auto Correction
Charging Port	Type-C (Fast Charging, approx. 2 hours for full charge)
Input Ports	USB, HDMI, 3.5mm AUX
Product Dimensions	9.06 x 6.89 x 3.82 inches
Item Weight	2.11 pounds

# **SETUP**

# 1. Powering On

- 1. Connect the power adapter to the projector's Type-C port and then to a power outlet.
- 2. Press the power button located on the top of the projector or on the remote control to turn it on.
- 3. The projector will automatically perform keystone correction and focus adjustment.

# 2. Placement and Screen Adjustment

- Place the projector on a stable, flat surface.
- Ensure the projection path is clear of obstructions.
- The projector features 40° auto keystone correction. For optimal results, position the projector as directly as possible in front of the screen or wall.
- Adjust the distance to achieve your desired screen size (up to 200 inches).

# 3. Initial Network Configuration

- 1. Navigate to the "Settings" menu on the projector's interface.
- 2. Select "Network" or "Wi-Fi Settings".
- 3. Choose your desired 2.4G or 5G Wi-Fi network from the list.
- 4. Enter the Wi-Fi password using the on-screen keyboard and remote control.
- 5. Confirm the connection.

### **OPERATING INSTRUCTIONS**

# 1. Connecting Devices

The projector supports various input methods:

- **HDMI:** Connect laptops, gaming consoles (e.g., PS4), TV sticks, or other HDMI-enabled devices using the provided HDMI cable. Select the HDMI input source from the projector's menu.
- USB: Insert a USB drive into the USB port to play media files directly. Navigate to the "Media" or "File Browser" section to access content.
- 3.5mm AUX: Connect external audio devices or headphones using a 3.5mm audio cable.
- Wireless Screen Mirroring (iOS/Android):
  - a. Ensure your smartphone/tablet and the projector are connected to the same Wi-Fi network.
  - b. On the projector, select the "Screen Mirroring" or "Wireless Projection" option.
  - c. On your iOS device, open Control Center and tap "Screen Mirroring" or "AirPlay Mirroring", then select the projector from the list.
  - d. On your Android device, use the "Smart View", "Cast", "Wireless Display", or similar function in your device's settings or quick panel, then select the projector.

### • Bluetooth Audio:

- a. Go to the projector's "Settings" menu and select "Bluetooth".
- b. Enable Bluetooth and search for available devices.
- c. Select your Bluetooth speaker or headphones from the list to pair.

# 2. Battery Operation

- The built-in battery provides approximately 2.5 hours of operation on a full charge.
- To charge the projector, connect it to the power adapter via the Type-C port. A full charge takes approximately 2
  hours.
- The projector can also be charged using a compatible power bank for extended use.

# 3. Image and Audio Settings

- Focus: The projector features automatic focus adjustment. If manual adjustment is needed, use the focus ring or remote control options.
- **Keystone Correction:** The 40° auto keystone correction automatically adjusts the image shape. Manual adjustments may be available in the settings menu if required.
- **Volume:** Adjust the volume using the remote control or the projector's onboard controls.
- **Picture Mode:** Access picture settings (e.g., brightness, contrast, color temperature) through the projector's menu to optimize the display for your environment.

# **M**AINTENANCE

- Lens Cleaning: Use the provided lens cleaning tool or a soft, lint-free cloth to gently clean the projector lens. Avoid abrasive materials or harsh chemicals.
- **Dust Removal:** Periodically clean the projector's exterior with a soft, dry cloth. Ensure ventilation ports are clear of dust to prevent overheating.
- Storage: When not in use for extended periods, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Care:** For optimal battery life, avoid fully discharging the battery frequently. If storing for a long time, charge the battery to about 50-70%.

# **Troubleshooting**

Problem	Possible Solution
No image projected	<ul> <li>Ensure the projector is powered on.</li> <li>Check all cable connections (HDMI, power).</li> <li>Verify the correct input source is selected on the projector.</li> <li>Adjust focus and keystone correction.</li> </ul>
Image is blurry or out of focus	<ul> <li>Allow auto-focus to complete.</li> <li>Manually adjust the focus if available.</li> <li>Ensure the projection surface is flat and the projector is stable.</li> </ul>
No sound	<ul> <li>Increase the volume on the projector and the connected device.</li> <li>Check if external speakers are connected via Bluetooth or AUX and ensure they are powered on and paired correctly.</li> <li>Verify audio output settings on the connected device.</li> </ul>
Cannot connect to Wi- Fi	<ul> <li>Ensure the Wi-Fi password is entered correctly.</li> <li>Restart the projector and your Wi-Fi router.</li> <li>Ensure the projector is within range of the Wi-Fi signal.</li> </ul>
Screen mirroring issues	<ul> <li>Confirm both devices are on the same Wi-Fi network.</li> <li>Restart both the projector and the mobile device.</li> <li>Ensure your device supports screen mirroring to external displays.</li> </ul>

# WARRANTY AND SUPPORT

ELEPHAS provides a **3-year warranty service** for the BL108 Mini Projector. This warranty covers manufacturing defects and ensures product reliability.

For technical support, warranty claims, or any questions regarding your ELEPHAS Mini Projector, please contact ELEPHAS customer service. Contact information can typically be found on the official ELEPHAS website or through your

purchase platform.

Please have your model number (BL108) and purchase details ready when contacting support.

© 2025 ELEPHAS. All rights reserved.

#### Related Documents - BL108



### ELEPHAS BL128 Portable Full HD LED LCD Projector - Specifications & Features

Discover the ELEPHAS BL128 portable LED LCD projector, offering Full HD 1080P resolution, 320 ANSI lumens, 6000:1 contrast, and integrated media player with Miracast and Airplay. Ideal for home entertainment.



### ELEPHAS BL128 Game-Portable LED LCD Projector Specifications

Discover the ELEPHAS BL128, a game-portable LED LCD projector featuring 320 Ansi-Lumen, 6000:1 contrast, and HDTV 1920x1080 resolution. With a 60,000-hour lamp life and integrated media player, it supports Airplay, Miracast, and various media formats for versatile entertainment.



### ELEPHAS W1K Portable LCD LED Projector - Specifications and Features

Detailed overview of the ELEPHAS W1K portable LCD LED projector, featuring HDTV 1920x1080 resolution, 10000:1 contrast, 30,000-hour LED lifespan, keystone correction, and 4K compatibility. Includes technical specifications and key features.



### Elephas W13 Portable LCD LED Projector - Full HD 1080p

Detailed specifications and features of the Elephas W13 portable LCD LED projector, including its Full HD 1080p resolution, integrated media player, Wi-Fi connectivity, and quiet operation.



### ELEPHAS BL128 Portable Full HD LED LCD Projector - Specifications & Features

Discover the ELEPHAS BL128 portable LED LCD projector, offering Full HD 1080P resolution, 320 ANSI lumens, 6000:1 contrast, and integrated media player with Miracast and Airplay. Ideal for home entertainment.



# CiBest BL108 Projector User Manual: Setup, Screen Mirroring, and Safety

Comprehensive user manual for the CiBest BL108 projector. Learn how to set up your projector, perform wireless and USB screen mirroring for iOS and Android devices, understand technical specifications, and follow important safety guidelines. Includes troubleshooting tips and contact information.