

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [ELECTROPRIME](#) /
- › [ELECTROPRIME HOCO AC7 Storm Power Strip User Manual](#)

ELECTROPRIME HOCO AC7 Storm

ELECTROPRIME HOCO AC7 Storm Power Strip User Manual

3-Position Socket with USB-C and 3 USB Ports

1. INTRODUCTION

This manual provides instructions for the safe and efficient use of your ELECTROPRIME HOCO AC7 Storm Power Strip. This device features three AC outlets, one USB-C port, and three USB-A ports, designed for convenient power distribution and charging of multiple electronic devices. Please read this manual thoroughly before operation and retain it for future reference.

2. SAFETY INSTRUCTIONS

To prevent injury or damage to the device, always follow these basic safety precautions:

- Do not exceed the maximum power rating of 2500W (10A / 250V).
- This product is designed for indoor use only. Do not expose to moisture or extreme temperatures.
- Do not disassemble, modify, or attempt to repair the device. Refer all servicing to qualified personnel.
- Keep out of reach of children.
- Ensure the power cord is fully extended and not coiled or covered when in use to prevent overheating.
- Insert plugs fully into the outlets. Loose connections can cause overheating.
- Do not use with appliances that draw more power than the strip's maximum capacity.

3. PRODUCT OVERVIEW

The ELECTROPRIME HOCO AC7 Storm power strip provides multiple power and charging options. It features a durable, flame-retardant PC material construction for enhanced safety.



Image 1: Overview of the ELECTROPRIME HOCO AC7 Storm Power Strip, illustrating both white and black color variants with their respective AC and USB ports, power button, and attached power cable with a US plug.

4. SETUP

1. **Unpack:** Carefully remove the power strip from its packaging.
2. **Placement:** Place the power strip on a stable, dry surface, away from heat sources, water, and direct sunlight. Ensure adequate ventilation around the unit.
3. **Connect to Wall Outlet:** Plug the power strip's US plug into a standard 250V wall outlet.
4. **Power On:** Press the power button located on the unit to turn on the power strip. An indicator light will illuminate when the unit is powered on.



Image 2: Angled view of the white power strip, highlighting the arrangement of AC and USB ports.

5. OPERATING INSTRUCTIONS

5.1 Using AC Outlets

The power strip features three universal AC outlets. To use, simply plug your appliances into the available sockets. Ensure the total power consumption of all connected devices does not exceed 2500W.

5.2 Using USB Charging Ports

The power strip includes one USB-C port and three USB-A ports for charging mobile devices, tablets, and other USB-powered electronics. The total USB output is 5V/3.4A.

- Connect your device's USB charging cable to the appropriate USB-C or USB-A port on the power strip.
- Ensure your device begins charging.



Image 3: Top-down view of the white power strip, illustrating the layout of the AC outlets and USB ports, along with the attached power cable.

6. MAINTENANCE

- **Cleaning:** Disconnect the power strip from the wall outlet before cleaning. Use a dry, soft cloth to wipe the surface. Do not use liquid cleaners or aerosols.
- **Storage:** When not in use for extended periods, unplug the power strip and store it in a cool, dry place.
- **Inspection:** Periodically inspect the power cord and plug for any signs of damage. If damaged, discontinue use and contact customer support.

7. TROUBLESHOOTING

- **No Power:**
 - Ensure the power strip is securely plugged into a working wall outlet.
 - Check if the power button on the strip is pressed to the "ON" position.
 - Verify that the wall outlet itself is functioning by plugging in another device.
- **Devices Not Charging via USB:**
 - Ensure the power strip is powered on.

- Check the USB cable for damage and ensure it is properly connected to both the power strip and your device.
- Verify that your device is compatible with 5V/3.4A USB charging.
- **Overload Protection:** If the power strip stops providing power, it may have triggered its overload protection. Unplug all devices, wait a few minutes, and then press the power button to reset. Reduce the number of high-power devices connected.

8. SPECIFICATIONS

| Feature | Specification |
|------------------------|----------------------|
| Material | Flame retardant PC |
| AC Output | 10A / 250V |
| Max Power | 2500W |
| USB Output | 5V / 3.4A (Total) |
| Power Cord Length | 1.5m |
| Power Cord Type | 0.75 square PVC wire |
| Dimensions (L x W x H) | 198 x 110 x 107 mm |
| Weight | 340g |
| Plug Type | US Plug |

9. WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For detailed warranty information, technical support, or service inquiries, please contact ELECTROPRIME customer service through your purchase platform or the contact information provided with your product packaging.