

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [FUNTOK](#) /

› [FUNTOK 24V 2-Seater Ride-On Toy \(Model R06S\) Instruction Manual](#)

## FUNTOK R06S

# FUNTOK 24V 2-Seater Ride-On Toy (Model R06S) Instruction Manual

Model: R06S | Brand: FUNTOK

## 1. SAFETY INFORMATION

This product is certified by CPSC & ASTM, prioritizing safety for children aged 3-8 years. Always ensure children are supervised during use.

- Always wear safety harnesses.
- Ensure double-locking safety doors are secured.
- Do not use on wet or slippery surfaces.
- Adult supervision is required at all times.
- Keep hands and feet away from moving parts.
- Inspect the toy for any damages before use.



**Image Description:** This image illustrates the safety features of the FUNTOK 24V Ride-On Toy, including adjustable safety belts, four wear-resistant wheels, and a graph comparing soft start functionality. The vehicle is shown in a blue color.

## 2. SETUP & ASSEMBLY

Follow these steps for initial setup and assembly of your FUNTOK 24V Ride-On Toy. It is recommended to charge the battery for at least 6 hours before first use.

### 2.1. Assembly Steps

1. **Unboxing:** Carefully remove all components from the packaging.
2. **Front Axle Assembly:** Take out the flat iron, remove nuts and washers, place the flat iron on the bracket fixed shaft, connect the steering bracket, install washers, and tighten nuts.
3. **Front Bumper Assembly:** Assemble the two plastic parts of the bumper, fix the metal frame to the base, and install the entire bumper to the front of the car with screws.
4. **Rear Axle Installation:** Remove screws from the body, take off the seats, install the body bracket to the body position, and fix it with 8 screws.
5. **Motor Gearbox Installation:** Install the motor gearbox on both sides and insert it into the round hole.

Connect the motor plug.

6. **Wheel Installation:** Install the wheels onto the axles, then tighten the washers and nuts to fix the wheels.
7. **Power Cable Connection:** Open the front cover of the car, connect the power plug, and fix the front cover with 1 screw.
8. **Steering Wheel Assembly:** Connect the steering wheel plug, align the steering wheel to the locked position, and press down.
9. **Windshield and Rearview Mirrors Installation:** Align the windshield with the body fixing slots and press down. Install 2 rearview mirrors.
10. **Seat Installation:** Connect the motor cable, put the backplate into the car body and fix it with 6 screws, then install the 2 seats and fix with screws.
11. **Rear Windshield Assembly:** Open the rear cover of the lamp holder and insert 2 AAA batteries (not included). Connect the rest of the rear windshield parts, then place the rear windshield into the car body and press it down.

## 2.2. Assembly Video Guide

Your browser does not support the video tag.

**Video Description:** This video provides a detailed, step-by-step installation tutorial for the FUNTOK 24V 2-Seater Ride-On Car. It visually guides users through assembling the front and rear axles, attaching bumpers, installing motors, wheels, connecting power cables, and fitting the steering wheel, windshield, and seats. This visual guide is helpful for understanding the assembly process.

## 3. OPERATING INSTRUCTIONS

The FUNTOK 24V Ride-On Toy offers dual control modes for varied driving experiences.

### 3.1. Driving Modes

- **Manual Mode:** Children can drive independently using the steering wheel and pedal. This mode offers 2 speeds (2 or 5 MPH).
- **Remote Control Mode:** Parents can safely guide beginners using the 2.4GHz Remote Control. This mode features 3 speeds (2, 3, 5 MPH) and an emergency stop function for enhanced safety.

# Dual Modes, Join Kid's Fun



Self Driving Mode 2 Speeds:  
2.67 - 5 MPH



Remote Control Mode 3 Speeds:  
2 - 5 MPH

**Image Description:** This image highlights the dual control modes of the ride-on toy, showing a child driving the blue vehicle in a grassy area, while a remote control is also visible, indicating parental control options. Speed ranges for both modes are displayed.

## 3.2. Controls and Features

- **Power Switch:** Located on the dashboard.
- **Speed Selection:** Buttons for fast and slow speeds.
- **Drive Mode Selection:** Switch between 2WD and 4WD for optimal traction on different terrains.
- **Forward/Backward:** Lever to select driving direction.
- **Lights:** Headlights and searchlights can be turned on/off.
- **Audio System:**
  - Built-in music player.
  - Volume adjustment knob.
  - Bluetooth connectivity for external music playback.
  - Horn button on the steering wheel.
- **Battery Indicator:** Displays current battery level.
- **Charging Port:** Located on the dashboard for convenient charging.

### 3.3. Operational Video Guide

Your browser does not support the video tag.

**Video Description:** This video demonstrates the FUNTOK 24V 2-Seater Ride-On Car in action, showcasing its features like 4WD capability, remote control operation, and driving on various terrains including grass and asphalt. It also highlights the dashboard controls, music player, and horn, providing a comprehensive overview of the vehicle's functionality.

## 4. MAINTENANCE

Proper maintenance ensures the longevity and safe operation of your ride-on toy.

- **Charging:** Charge the battery for at least 6 hours before first use, and after each subsequent use. Store the battery at room temperature.
- **Cleaning:** Wipe the vehicle with a damp cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the toy in a cool, dry place when not in use. Protect it from direct sunlight and moisture.
- **Inspection:** Regularly inspect the toy for any loose parts, damaged wires, or worn-out components. Tighten screws as needed.
- **Battery Care:** Do not overcharge the battery. If the toy will not be used for an extended period, charge the battery every 30 days to maintain its life.

## 5. TROUBLESHOOTING

If you encounter issues with your ride-on toy, refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Vehicle does not move	Low battery; Loose power connection; Motor issue; Remote control override.	Charge battery; Check all power connections; Consult customer support if motor is faulty; Ensure remote control is not in "Park" mode or interfering.
Vehicle moves slowly	Low battery; Overload (too much weight); Driving on rough terrain; Speed setting.	Charge battery fully; Reduce load; Switch to 4WD mode or smoother surface; Check speed setting (ensure it's not on "Slow").
Remote control not working	Batteries in remote are dead; Remote not paired; Interference.	Replace remote batteries (2*AAA); Re-pair remote control with the vehicle (press "▲" & "▼" keys for 3 seconds); Move away from other electronic devices.
Unusual noises	Loose parts; Debris in wheels/motors; Worn gears.	Inspect and tighten all screws; Clear any debris; Contact customer support if gears are worn.

## 6. SPECIFICATIONS

- **Product Dimensions:** 49.21 x 32.68 x 30.31 inches
- **Item Weight:** 58.1 pounds

- **Model Number:** R06S
- **Manufacturer Recommended Age:** 3 - 8 years
- **Motors:** 4x200W
- **Max Speed:** 5 MPH
- **Seat Capacity:** 2-Seater (20-inch seat)
- **Weight Capacity:** 140 lbs
- **Battery:** 24V 7AH
- **Play Time:** Up to 2 hours on a single charge
- **Safety Certifications:** CPSC & ASTM
- **Features:** 4WD/2WD switchable, Soft-Start System, 4-Wheel Spring Suspension, Adjustable Safety Harnesses, Double-Locking Safety Doors, Bluetooth, Built-in Music, LED Headlights, LED Searchlights, Truck Bed Storage.

## Roomy Space, More Joys



Seats

**2 Seaters**



Max Load

**140 lbs**



Age

**3 to 8 Years**



**Image Description:** This image highlights the spacious interior of the FUNTOK 24V Ride-On Toy, specifically showcasing the 20-inch wide seat designed to comfortably accommodate two children. Key specifications like 2-seater capacity, 140 lbs max load, and age range of 3-8 years are also indicated.

## 7. WARRANTY AND SUPPORT

Information regarding specific warranty details and customer support contact methods is not provided within this manual. Please refer to the product packaging or the retailer's website for warranty claims and support inquiries.