

[Manuals.plus](#) /

> [Nobleza](#) /

> Nobleza Automatic Pet Feeder and Water Dispenser (3.8L Water, 1.9kg Food) - Transparent & Grey Instruction Manual

Nobleza B0D2L5ZPLC

Nobleza Automatic Pet Feeder and Water Dispenser Instruction Manual

Model: B0D2L5ZPLC

1. PRODUCT OVERVIEW

Thank you for choosing the Nobleza Automatic Pet Feeder and Water Dispenser. This gravity-fed system is designed to provide a continuous supply of food and water for your small to medium-sized cats and dogs, ensuring they stay fed and hydrated even when you are away. The transparent design allows for easy monitoring of food and water levels.



Image 1.1: The Nobleza Automatic Pet Feeder and Water Dispenser set.

Package Contents:

- 1 x Automatic Pet Food Dispenser (approx. 1.9 kg capacity)
- 1 x Automatic Pet Water Dispenser (3.8 L capacity)



Image 1.2: Product dimensions for both units.

Key Features:

- **Natural Gravity Supply:** No electricity required, ensuring continuous availability.
- **Large Capacity:** Water dispenser holds 3.8 liters, food dispenser holds approximately 1.9 kg of dry kibble.
- **Transparent Containers:** Easily monitor food and water levels at a glance.
- **Safe Materials:** Made from BPA-free PP+PET for your pet's health.
- **Easy to Clean:** Simple disassembly for thorough hand washing.
- **Non-Slip Base:** Equipped with a rubber non-slip base for stability.

Your browser does not support the video tag.

Video 1.1: Overview of the Nobleza Automatic Pet Feeder and Water Dispenser, demonstrating its features, setup, and use.

2. SETUP INSTRUCTIONS

Follow these steps to set up your Nobleza Automatic Pet Feeder and Water Dispenser.

2.1 Unpacking and Initial Inspection

- Carefully remove all components from the packaging.
- Inspect both the food and water dispensers for any signs of damage.
- Ensure all parts listed in the "Package Contents" are present.

2.2 Assembling the Food Dispenser

1. Place the base of the food dispenser on a flat, stable surface.
2. Align the transparent food reservoir with the grooves on the base and gently push down until it clicks securely into place.
3. Remove the lid from the top of the food reservoir.

2.3 Assembling the Water Dispenser

1. Place the base of the water dispenser on a flat, stable surface.
2. Align the transparent water reservoir with the grooves on the base and gently push down until it clicks securely into place.
3. Ensure the water valve mechanism at the bottom of the reservoir is properly seated in the base.

2.4 Placement

Choose a suitable indoor location for the dispensers, away from direct sunlight and heat sources. Ensure the surface is level to prevent spills and ensure proper gravity flow.

3. OPERATING INSTRUCTIONS

3.1 Filling the Food Dispenser

1. Remove the top lid of the food reservoir.
2. Pour dry pet kibble into the reservoir. The transparent design allows you to see the fill level.
3. Replace the lid securely. Food will automatically dispense into the bowl as your pet consumes it.



OPEN THE LID TO ADD FOOD

Super Convenient For Replenishment



WIDEN THE FOOD OUTLET ADD FOOD

Smooth Food Discharge Without Food Jam

Image 3.1: Adding dry food to the dispenser.

Note: The food outlet is designed to accommodate various dry food particle sizes. For optimal flow and to prevent blockages, ensure the kibble size is appropriate for gravity dispensing.

REDUCE FOOD BLOCKAGE

The Food Outlet Is Suitable For Cat And Dog Food Of Various Sizes









6*6mm	10*10mm	12*12mm	15*15mm	Dry Food	Mixed Food 5-18mm	Air-Dried Food	Freeze-Dried Food
							

Image 3.2: Recommended food particle sizes for smooth dispensing.

3.2 Filling the Water Dispenser

1. Remove the transparent water reservoir from its base.
2. Unscrew the cap at the bottom of the reservoir.
3. Fill the reservoir with clean, fresh water.
4. Securely screw the cap back on.
5. Invert the filled reservoir and place it back onto its base, ensuring the valve engages properly. Water will flow into the bowl until it reaches a certain level, then stop due to the siphon principle.



Image 3.3: The water dispenser operates on a siphon principle for automatic replenishment.

3.3 Monitoring and Refilling

The transparent design of both dispensers allows for easy visual monitoring of food and water levels. Refill as needed to ensure your pet always has access to fresh supplies. The 3.8L water capacity can last up to 7 days for small pets and 3 days for larger pets, while the 1.9kg food capacity provides ample supply.

4. MAINTENANCE AND CLEANING

Regular cleaning is essential to maintain hygiene and ensure the longevity of your pet dispensers.

4.1 Disassembly for Cleaning

1. Empty any remaining food or water from the dispensers.
2. Gently lift the transparent reservoirs from their bases. They are designed for quick release and easy separation without tools.
3. For the water dispenser, unscrew the cap at the bottom of the reservoir.



Image 4.1: Easy disassembly for cleaning.

4.2 Cleaning Instructions

- Wash all disassembled parts by hand using cold water and a mild, pet-safe detergent.
- Use a soft sponge or brush to clean all surfaces, paying attention to corners and crevices where food or water residue might accumulate.
- Rinse thoroughly to remove all soap residue.
- Allow all parts to air dry completely before reassembling to prevent mold or bacterial growth.
- **Important: These dispensers are NOT dishwasher safe. Hand wash only.**

5. TROUBLESHOOTING

If you encounter any issues with your Nobleza Automatic Pet Feeder and Water Dispenser, please refer to the following common problems and solutions:

5.1 Food Not Dispensing

- **Check for Clogs:** Ensure there are no large pieces of kibble or debris blocking the food outlet. Gently shake the dispenser or use a clean utensil to clear any obstructions.
- **Kibble Size:** Verify that the size of your pet's kibble is suitable for gravity dispensing. Very large or unusually shaped kibble may get stuck. Refer to Image 3.2 for guidance.
- **Reservoir Alignment:** Ensure the food reservoir is correctly seated and aligned with the base.

5.2 Water Overflowing or Not Dispensing

- **Proper Assembly:** Ensure the water reservoir's cap is securely tightened and the reservoir is correctly inverted and seated onto its base, allowing the valve to engage properly.
- **Siphon Mechanism:** The water dispenser relies on a siphon principle. If water is not flowing, check for air bubbles trapped in the reservoir or ensure the cap is not too loose or too tight, affecting the vacuum seal.
- **Base Stability:** Ensure the dispenser is on a flat, stable surface. Uneven surfaces can affect the water level and cause spills.

5.3 Unpleasant Odor

- **Thorough Cleaning:** Odors usually indicate a need for more thorough cleaning. Disassemble all parts and wash them by hand with cold water and mild detergent, ensuring all residue is removed.
- **Air Dry:** Always allow parts to air dry completely before reassembly to prevent mold or mildew.

6. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Nobleza
Model Number	B0D2L5ZPLC
Food Dispenser Capacity	Approx. 1.9 kg (dry kibble)
Water Dispenser Capacity	3.8 Liters
Material	BPA-free PP+PET
Color	Transparent and Grey
Power Source	Gravity
Product Dimensions (each unit)	28.5 cm (L) x 15.5 cm (W) x 30.5 cm (H)
Product Care	Hand wash only (Not dishwasher safe)
Target Species	Small to medium cats and dogs

7. WARRANTY AND CUSTOMER SUPPORT

Nobleza is committed to providing high-quality products. While specific warranty details are not included in this manual, please retain your proof of purchase for any warranty claims.

For any questions, concerns, or technical support regarding your Nobleza Automatic Pet Feeder and Water Dispenser, please contact Nobleza customer service through the retailer where you purchased the product

or visit the official Nobleza website for contact information.

We are dedicated to ensuring your satisfaction and the well-being of your pets.