

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [GRAM PRES](#) /
- › [GRAM PRES Digital Kitchen Scale User Manual](#)

GRAM PRES GP-K1905-10KG

GRAM PRES Digital Kitchen Scale User Manual

Model: GP-K1905-10KG

Brand: GRAM PRES

1. INTRODUCTION

Thank you for choosing the GRAM PRES Digital Kitchen Scale. This precision instrument is designed to provide accurate weight measurements for various culinary and dietary needs. With its sleek stainless steel platform and clear LCD display, it offers both functionality and ease of use for everyday cooking, baking, and portion control.

This manual provides essential information on setting up, operating, maintaining, and troubleshooting your new kitchen scale. Please read it thoroughly before first use to ensure optimal performance and longevity of your device.

2. PRODUCT OVERVIEW



Image 2.1: Front view of the GRAM PRES Digital Kitchen Scale, showing the stainless steel weighing platform, LCD display, and 'UNIT' and '←/T' buttons.

The GRAM PRES Digital Kitchen Scale features a single sensor weighing platform, capable of measuring up to 10kg (22lb) with an accuracy of 1g increments. It is equipped with a backlit LCD display for easy reading and offers multiple weighing units.

Key Features:

- **Accurate Measurement:** 1g incremental readability, up to 10kg/22lb capacity.
- **Multiple Units:** Switch between g, oz, lb:oz, fl.oz, and ml.
- **Tare Function:** Easily zero out the weight of containers or additional ingredients.
- **Backlit LCD Display:** Provides clear readings in various lighting conditions.
- **Auto Power-Off:** Conserves battery life with a 3-minute automatic shut-off.
- **Durable Design:** Stainless steel weighing platform for easy cleaning and longevity.

3. SETUP

3.1 Battery Installation

Your GRAM PRES Digital Kitchen Scale requires 2 x AAA batteries (included). Follow these steps to install

them:

1. Locate the battery compartment on the underside of the scale.
2. Open the battery compartment cover.
3. Insert the 2 AAA batteries, ensuring the correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment cover securely.

3.2 Placement

For accurate readings, place the scale on a hard, flat, and stable surface. Avoid placing it on soft, uneven, or vibrating surfaces, as this can affect measurement accuracy.

4. OPERATING INSTRUCTIONS

4.1 Powering On/Off

- To turn on the scale, press the '←/T' button. The display will light up and show '0g' (or the last used unit).
- To turn off the scale, press and hold the '←/T' button for a few seconds. The scale will also automatically power off after 3 minutes of inactivity to conserve battery life.

4.2 Unit Conversion

The scale supports 5 weighing units: grams (g), ounces (oz), pounds and ounces (lb:oz), fluid ounces (fl.oz), and milliliters (ml).

- To change the unit, press the 'UNIT' button repeatedly until your desired unit is displayed. The scale will remember your last selected unit for future use.

4.3 Tare Function

The Tare function allows you to zero out the weight of a container or to measure multiple ingredients in the same bowl.



Image 4.1: Illustrates the use of the tare function, showing a bowl being placed on the scale and then the display being reset to zero before adding ingredients.

- Place an empty container on the weighing platform. The display will show its weight.
- Press the '←/T' button. The display will reset to '0'.
- Now, add your ingredients to the container. The display will show only the net weight of the ingredients.
- You can repeat this process to measure multiple ingredients consecutively.

4.4 Weighing Items

Accurate Results

Accurately weight objects from 1g to 10000g

Increment 1g



Image 4.2: The scale displaying an accurate weight for a bowl of strawberries, demonstrating its precision for food items.

- Ensure the scale is on and displaying '0'.
- Place the item(s) directly onto the stainless steel weighing platform, or in a container if using the Tare function.
- Read the weight displayed on the backlit LCD screen.

5. MAINTENANCE

5.1 Cleaning

Stainless steel weighing platform makes

cleaning easier than
ever before



Image 5.1: A hand cleaning the stainless steel weighing platform, highlighting its ease of maintenance.

- Wipe the scale with a soft, damp cloth. For stubborn stains, use a mild detergent.
- Do not immerse the scale in water or use abrasive cleaners, as this can damage the electronic components.
- Ensure the scale is completely dry before storage or next use.

5.2 Storage

- Store the scale in a cool, dry place.
- Avoid storing the scale with heavy objects placed on the platform, as this can affect calibration over time.
- If the scale will not be used for an extended period, it is recommended to remove the batteries to prevent leakage.

6. TROUBLESHOOTING

If you encounter issues with your GRAM PRES Digital Kitchen Scale, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Scale does not turn on.	Low or dead batteries; incorrect battery installation.	Replace batteries with new AAA batteries, ensuring correct polarity.
Inaccurate readings.	Scale on an uneven surface; overloaded; internal sensor issue.	Place scale on a flat, stable surface. Ensure weight does not exceed 10kg. If problem persists, contact customer support.
Display shows 'Lo' or 'Err'.	Low battery ('Lo'); overload ('Err').	Replace batteries ('Lo'). Remove excess weight from the platform ('Err').
Scale turns off unexpectedly.	Auto power-off activated; low battery.	This is normal if inactive for 3 minutes. If it happens during use, replace batteries.

7. SPECIFICATIONS

Feature	Detail
Model Number	GP-K1905-10KG
Capacity	10kg / 22lb
Accuracy	1g increments
Weighing Units	g, oz, lb:oz, fl.oz, ml
Display Type	Backlit LCD
Power Source	2 x AAA batteries (included)
Auto Shut-Off	3 minutes
Platform Material	Stainless Steel
Dimensions (Package)	8.62 x 7.05 x 1.54 inches
Item Weight	12.7 ounces
Manufacturer	GRAM PRES

8. WARRANTY AND SUPPORT

GRAM PRES stands by the quality of its products. Your Digital Kitchen Scale comes with the following:

- **2 Months Money Back Guarantee:** If you are not satisfied with your purchase within 2 months, you may be eligible for a refund.
- **12 Months Warranty:** We offer a 12-month warranty covering manufacturing defects from the date of purchase.

For any questions, concerns, or warranty claims, please contact the seller or GRAM PRES customer support. Please have your model number (GP-K1905-10KG) and purchase details ready when contacting support.

