



Manuals.plus /

› onerbl /

› 15V AC-DC Adapter Replacement for Belkin Boost Charge Pro WIZ016 WIZ017 WIZ017TT WH BK 3-in-1 Wireless Charging Pad MagSafe 2ACR040G NJ 2ACR040GNJ 40W 15VDC 2.67A Power Supply Charger User Manual

onerbl WIZ016, WIZ017, WIZ017TT, 2ACR040G, 2ACR040GNJ

15V AC-DC Adapter User Manual

Model: WIZ016, WIZ017, WIZ017TT, 2ACR040G, 2ACR040GNJ

1. INTRODUCTION

This user manual provides essential information for the safe and efficient use of your onerbl AC-DC Adapter. Please read this manual thoroughly before using the product and retain it for future reference.

2. PRODUCT OVERVIEW

The onerbl AC-DC Adapter is designed as a high-quality replacement power supply for specific Belkin Boost Charge Pro wireless charging pads. It delivers stable 15V DC power at 2.67A, providing 40W of power for reliable operation.



Figure 2.1: The AC-DC adapter unit with its attached DC output cable and a detachable AC input power cord.

This image shows the main adapter unit, which is a black rectangular box with a blue indicator light. An integrated cable extends from one end, terminating in a barrel connector. A separate AC power cord with a two-prong plug on one end and a figure-8 connector on the other is also visible, coiled next to the adapter.



Figure 2.2: Detachable AC Power Cord.

This image focuses on the detachable AC power cord. It features a standard US two-prong plug on one end and a figure-8 (C7) connector on the other, designed to connect to the adapter unit.

3. WHAT'S IN THE BOX

Upon opening the package, please verify that all components are present and undamaged:

- 1 x Power Adapter (Main unit with integrated DC cable)
- 1 x AC Power Cord (for connecting to wall outlet)

Note: The product description mentions "2 x Cables". This refers to the integrated DC output cable and the detachable AC input cable.

4. SPECIFICATIONS

Key technical specifications for the AC-DC Adapter:

Feature	Detail
Input Voltage	100-240V AC, 50/60Hz (Global Compatibility)
Output Voltage	15V DC
Output Current	2.67A
Output Power	40W
Compatibility	Belkin Boost Charge Pro WIZ016, WIZ017, WIZ017TT, 2ACR040G NJ, 2ACR040GNJ
Cable Length (Total)	Approximately 127.8 inches (324.6 cm)
Dimensions (Adapter Unit)	Approx. 4.2 x 1.8 x 1.2 inches (10.7 x 4.6 x 3.0 cm)

Cable Length: 127.8 inch




Figure 4.1: Adapter and Cable Dimensions.

This diagram illustrates the physical dimensions of the adapter unit and the lengths of its integrated DC cable and the detachable AC power cord. Key measurements are provided in inches.

5. SETUP INSTRUCTIONS

Follow these steps to set up your AC-DC Adapter:

1. **Unpack Components:** Carefully remove the power adapter and AC power cord from their packaging.
2. **Connect AC Power Cord:** Insert the figure-8 connector of the AC power cord firmly into the corresponding port on the AC-DC adapter unit.
3. **Connect to Wall Outlet:** Plug the two-prong end of the AC power cord into a standard wall electrical outlet (100-240V AC).
4. **Connect to Device:** Plug the barrel connector of the adapter's integrated DC output cable into the power input port of your compatible Belkin Boost Charge Pro wireless charging pad.
5. **Verify Connection:** Ensure all connections are secure. The adapter may have an indicator light (often blue) that illuminates when power is supplied.



Figure 5.1: Adapter in Use.

This image demonstrates the adapter connected to a wall outlet and placed on a surface, ready to power a compatible device (not fully visible, but implied by the setup).

6. OPERATING INSTRUCTIONS

Once properly set up, the AC-DC Adapter operates automatically to provide power to your connected device. There are no user-adjustable settings on the adapter itself.

- **Power Indicator:** A blue LED light on the adapter unit indicates that it is receiving AC power and is ready to supply DC power to the connected device.
- **Continuous Operation:** The adapter is designed for continuous operation when connected to a power source and a compatible device.

7. MAINTENANCE

To ensure the longevity and optimal performance of your AC-DC Adapter, follow these simple maintenance guidelines:

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or aerosols.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cables to prevent damage.
- **Handling:** Avoid dropping the adapter or subjecting it to strong impacts. Do not pull on the cables to disconnect the adapter from the wall or device; always grasp the plug or connector.
- **Ventilation:** Ensure the adapter is placed in a well-ventilated area during operation to prevent overheating. Do not cover the adapter.

8. TROUBLESHOOTING

If you encounter issues with your AC-DC Adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Adapter not powering on (no blue LED)	<ul style="list-style-type: none"> ◦ No power from wall outlet. ◦ AC power cord not securely connected. ◦ Faulty adapter. 	<ul style="list-style-type: none"> ◦ Test the wall outlet with another device. ◦ Ensure the AC power cord is fully inserted into both the adapter and the wall outlet. ◦ If issues persist, contact customer support.
Device not charging/powering on	<ul style="list-style-type: none"> ◦ DC output cable not securely connected to device. ◦ Device incompatibility. ◦ Faulty adapter or device. 	<ul style="list-style-type: none"> ◦ Ensure the barrel connector is fully inserted into your Belkin charging pad. ◦ Verify that your device model is listed as compatible with this adapter. ◦ If the adapter's LED is on but the device isn't powering, the device or adapter may be faulty.
Adapter feels hot during operation	<ul style="list-style-type: none"> ◦ Normal operation (slight warmth). ◦ Poor ventilation. ◦ Overload or internal fault. 	<ul style="list-style-type: none"> ◦ A slight warmth is normal. ◦ Ensure the adapter is in a well-ventilated area and not covered. ◦ If it's excessively hot or emitting smoke/smell, immediately unplug it and discontinue use.

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the seller's policy or contact the manufacturer directly. The product is typically covered by a standard limited warranty against defects in materials and workmanship.

Seller: GreatComputerParts

Manufacturer: Shenzhen Waweis Technology Co., Ltd

For further assistance, you may visit the seller's page on Amazon or contact them through the Amazon platform.