

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [iWALK](#) /

› [iWALK Portable Charger \(Model: LPS001C\) Instruction Manual](#)

## iWALK LPS001C

# iWALK Portable Charger (Model: LPS001C) Instruction Manual

**20W PD FAST CHARGING USB-C POWER BANK WITH LED DISPLAY AND BUILT-IN FOLDABLE METAL STAND**

## 1. Product Overview

The iWALK Portable Charger, Model LPS001C, is a compact and efficient power bank designed to provide fast charging for your compatible devices. Featuring a 5000mAh battery capacity, 20W Power Delivery (PD) fast charging, an integrated USB-C connector, and a convenient LED digital display, this device ensures your electronics remain powered on the go. Its built-in foldable metal stand offers hands-free viewing while charging.



*Image: The iWALK Portable Charger in white, connected to a smartphone, demonstrating its compact size and integrated stand.*

## 2. Key Features

- **Built-in Foldable Metal Stand:** Provides stable support for your device, allowing for hands-free use during charging.
- **Two-Way 20W PD Fast Charging:** Delivers rapid power to your devices and recharges the power bank quickly. Supports simultaneous charging and recharging.
- **Integrated USB-C Connector:** Directly connects to compatible devices without the need for additional cables.
- **LED Digital Display:** Clearly indicates the remaining battery percentage of the power bank.
- **5000mAh Battery Capacity:** Offers sufficient power to extend your device's usage time.
- **Compact and Portable Design:** Lightweight and pocket-sized for easy transport.

# 20W PD Fast Charging

**30** mins  
iPhone 16 Pro

LinkPod 20W PD

**50%**

Others 5V/1A

**20%**



\*Data is sourced from lab testing, actual results may vary.

*Image: Illustration highlighting the 20W PD fast charging capability, showing an iPhone 16 Pro reaching 50% charge in 30 minutes.*

## 3. Setup

### 3.1 Charging the Power Bank

1. Locate the USB-C input port on the side of the iWALK Portable Charger.
2. Connect the provided USB-C to USB-C cable to the input port of the power bank.
3. Plug the other end of the USB-C cable into a compatible 20W Power Delivery (PD) wall adapter (not included).
4. The LED digital display will illuminate, showing the current charge level. The numbers will increase as the power bank charges.
5. Once the display shows "100", the power bank is fully charged and ready for use.

*It is recommended to fully charge the power bank before its first use to optimize battery performance.*

## Two-Way Fast Recharging By USB-C



*Image: The iWALK Portable Charger being recharged from a wall outlet using a USB-C cable.*

## 4. Operating Instructions

### 4.1 Charging Your Device

1. Ensure the iWALK Portable Charger is adequately charged.
2. Carefully align the integrated USB-C connector of the power bank with the USB-C port on your compatible device.
3. Gently push the power bank onto your device's port until it is securely connected. The LED display on the power bank will show its remaining charge, and your device should indicate that it is charging.
4. To disconnect, gently pull the power bank straight out from your device's port.

### 4.2 Using the Foldable Stand

- Locate the foldable metal stand on the back of the power bank.
- Gently pull out the stand until it clicks into an open position.
- Place your device (with the connected power bank) onto the stand for hands-free viewing. The stand is adjustable to various angles.
- To close, fold the stand back into its recessed position until it is flush with the power bank's body.

### 4.3 LED Digital Display

- The LED display provides a real-time percentage of the power bank's remaining battery life.
- When charging a device or being recharged, the display will show the current battery percentage.

1

No cable needed  
and direct charge



2

Mini size for  
easy carry



3

Just plug and  
charge anywhere



*Image: The iWALK Portable Charger with its built-in metal stand supporting a smartphone for hands-free use.*

## 5. Compatibility

The iWALK Portable Charger is designed with a USB-C plug, supporting Power Delivery (PD) specification for broad compatibility.

### 5.1 Compatible Devices:

- **iPhone 15 Series:** iPhone 15, iPhone 15 Plus, iPhone 15 Pro, iPhone 15 Pro Max
- **iPhone 16 Series:** iPhone 16, iPhone 16 Plus, iPhone 16 Pro, iPhone 16 Pro Max
- **Upcoming iPhone 17 Series:** Including iPhone Air, iPhone 17, iPhone 17 Pro, iPhone 17 Pro Max
- **USB-C Equipped iPads:** iPad Pro, iPad Air, and other models with USB-C ports.
- **AirPods:** USB-C compatible AirPods models.
- **Other USB-C Devices:** Various Android smartphones (e.g., Samsung S23/S22/Note series, Google Pixel) and other small USB-C gadgets.

## 5.2 Not Applicable / Not Compatible:

- iPhone 14 / iPhone 13 / iPhone 12 / iPhone 11 / iPhone XS / iPhone XR / iPhone X / iPhone 8, 7, 6, SE (and older models with Lightning ports).

## Built-In USB-C Connector

iPhone 16/15 Series



Type-C / USB-C

### Compatible Devices



iPhone 16 Pro Max / iPhone 16 Pro  
iPhone 16 Plus / iPhone 16



iPhone 15 Pro Max / iPhone 15 Pro  
iPhone 15 Plus / iPhone 15



S23 Ultra/  
S23+/S23



S22 Ultra/  
S22+/S22



Note 10/9



ZFlip/Fold

### Reminder Not Applicable

\*iPhone 14 / iPhone 13 / iPhone 12 /  
iPhone 11 / iPhone XS / iPhone XR  
/ iPhone X / iPhone 8,7,6,SE

*Image: Visual representation of the USB-C connector and a comprehensive list of compatible and incompatible devices.*

## 6. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the power bank. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures.
- **Protection:** Keep the USB-C connector covered when not in use to prevent dust and debris accumulation.
- **Battery Care:** For optimal battery longevity, avoid fully discharging the power bank frequently. Recharge it when the battery level is low.

## 7. Troubleshooting

- **Device not charging:**
  - Ensure the power bank is sufficiently charged (check LED display).
  - Verify that the power bank's USB-C connector is securely and correctly inserted into your device's port.
  - Confirm your device is compatible with the iWALK Portable Charger (refer to Section 5).
- **Slow charging:**
  - For optimal fast charging, ensure your device supports 20W Power Delivery.
  - When recharging the power bank, use a 20W PD compatible wall adapter.
  - Note that simultaneous charging of a device and recharging the power bank (pass-through charging) may result in slightly slower charging speeds for both.
- **LED display not working:**
  - Try recharging the power bank. If the issue persists, contact customer support.

## 8. Specifications

Feature	Detail
Product Dimensions	3.1 x 2 x 1 inches
Item Weight	6.7 ounces
Item Model Number	LPS001C
Battery Capacity	5000 Milliamp Hours
Special Features	Digital Display, Fast Charging, Lightweight, Over Charging Protection, Pocket Size
Connector Type	USB Type C
Color	White
Manufacturer	U2O GLOBAL CO.,LTD

## 9. Warranty and Support

For warranty information, product support, or any inquiries regarding your iWALK Portable Charger, please refer to the warranty card included in your product packaging or visit the official iWALK website.

Keep your purchase receipt as proof of purchase for any warranty claims.

© 2026 iWALK. All rights reserved.