

## LIGE BW1845B-CC

# LIGE 1.32" Diamond Smartwatch User Manual

Model: BW1845B-CC

## 1. INTRODUCTION

This user manual provides comprehensive instructions for the LIGE 1.32" Diamond Smartwatch, Model BW1845B-CC. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance and user experience. Please read this manual carefully before using your smartwatch.



Figure 1: LIGE 1.32" Diamond Smartwatch (Silver Mesh and White Band versions)

## 2. PRODUCT FEATURES

- **Elegant Design:** Features a 1.32-inch HD touchscreen with a diamond-studded bezel and comes with two interchangeable straps (silver mesh and white silicone).
- **Customizable Watch Faces:** Over 200 watch faces available via the FitCloudPro app, with options to customize with personal photos.
- **Bluetooth Calling:** Equipped with Bluetooth 5.0 chip for making and receiving calls directly from the watch.
- **Message Notifications:** Receive SMS and app notifications (e.g., WeChat, Instagram, Facebook, Twitter, WhatsApp, Line, Skype, LinkedIn) directly on your wrist.
- **Health Monitoring:** Includes sleep monitoring (wake, light, deep sleep), heart rate tracking, blood pressure, blood oxygen (SpO2), and female menstrual cycle tracking.
- **Multiple Sports Modes:** Supports over 20 sports modes including running, walking, cycling, rope skipping, badminton, yoga, tennis, and crunches, accurately recording steps, calories, and distance.
- **Smart Assistant Functions:** Features AI voice assistant, weather forecasts, stopwatch, timer, calculator, calendar, phone finder, camera remote control, and music playback control.

- **Long Battery Life & IP67 Waterproof:** Offers 3-5 days of typical use and up to 7-15 days standby on a 2-hour charge. IP67 water resistance for daily use (hand washing, showering, swimming; avoid prolonged immersion).
- **Wide Compatibility:** Compatible with most smartphones running iOS 8.4 / Android 4.4 or above, and Bluetooth 4.2 or higher.

## 3. SETUP GUIDE

### 3.1 Initial Charging

Before first use, fully charge the smartwatch. Connect the magnetic charging cable to the charging points on the back of the watch and plug the USB end into a power adapter (not included) or a computer USB port. A full charge typically takes about 2 hours.

### 3.2 App Installation and Pairing (FitCloudPro)

To unlock the full features of your smartwatch, you need to download and install the "FitCloudPro" app on your smartphone.

1. **Enable Bluetooth:** Ensure Bluetooth is enabled on your smartphone.
2. **Download App:** Scan the QR code below or search for "FitCloudPro" in your phone's app store (App Store for iOS, Google Play Store for Android).



Figure 2: App Installation and Pairing Steps

You can also download the app directly from: [FitCloudPro Download Link](#)

3. **Grant Permissions:** Open the FitCloudPro app and grant all necessary permissions (e.g., Bluetooth, notifications, location) when prompted.
4. **Add Device:** In the app, navigate to the "Device" section and select "Add Device" or "Search for Device". The app will scan for available smartwatches. Select "BW1845B-CC" or the detected LIGE smartwatch from the list to connect.

### 3.3 Bluetooth Call Function Pairing

For the Bluetooth call function, a second Bluetooth connection is required.

1. **Enable Call Audio on Watch:** On your smartwatch, swipe down from the main screen to access the quick settings. Tap the Bluetooth call icon (usually a phone icon with a Bluetooth symbol) to enable it.
2. **Phone Bluetooth Settings:** Go to your smartphone's Bluetooth settings.
3. **Connect to "Watch Call":** In the list of available devices, find and select "Watch Call" (or a similar name like "BW1845B-CC\_CALL") to pair.
4. **Confirmation:** Once connected, you will be able to make and receive calls directly from your smartwatch.



Figure 3: Bluetooth Call Interface

## 4. OPERATING INSTRUCTIONS

### 4.1 Basic Navigation



- **Swipe Down:** Access quick settings (brightness, battery, Bluetooth status, DND mode).
- **Swipe Up:** View notifications.
- **Swipe Left/Right:** Navigate through main functions (activity data, heart rate, weather, music control, etc.).
- **Press Side Button:** Wake/sleep screen, return to home screen, or access app menu.

## 4.2 Customizing Watch Faces

You can change the watch face directly on the watch or through the FitCloudPro app.

- **On Watch:** Long-press the current watch face, then swipe left or right to browse available faces. Tap to select.
- **Via App:** Open FitCloudPro, go to "Device" -> "Dial Market" (or "Watch Faces"). Browse and download new watch faces. You can also select "Custom Dial" to upload a personal photo as your watch background.

# 200+ Watch Face for Your Choice




Figure 4: Watch Face Customization

### 4.3 Health Monitoring

The smartwatch continuously monitors various health metrics. View detailed data in the FitCloudPro app.

- **Heart Rate:** Access the heart rate function on the watch to measure your current heart rate.
- **Sleep Monitoring:** Wear the watch to bed for automatic sleep tracking. Data on sleep stages (deep, light, awake) will be available in the app.
- **Blood Oxygen (SpO2) / Blood Pressure:** Initiate measurements from the watch. Ensure the watch is snug on your wrist for accurate readings.
- **Female Health:** Set up menstrual cycle tracking in the FitCloudPro app for reminders and predictions.

### 4.4 Sports Modes

Select a sports mode before starting your activity to track specific metrics.

- Navigate to the "Sports" menu on the watch.
- Choose your desired activity (e.g., Running, Cycling, Yoga).
- The watch will begin tracking duration, calories burned, distance, and steps.
- End the activity by pressing the side button or swiping on the screen.



Figure 5: Sports Tracking

#### 4.5 Smart Notifications and Reminders

- **Message Reminders:** Ensure app notifications are enabled in the FitCloudPro app and your phone's settings.
- **Daily Reminders:** Set up reminders for drinking water, sedentary alerts, and schedule notifications within the FitCloudPro app.
- **Weather Forecast:** Syncs with your phone's weather data. Ensure location services are enabled for the app.



# Keep Connected



Figure 6: Connectivity and Reminders

## 5. MAINTENANCE

- **Cleaning:** Regularly clean the watch screen and straps with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth and mild soap, then dry thoroughly.
- **Water Resistance:** The watch is IP67 waterproof, meaning it can withstand splashes, rain, and brief immersion. However, avoid hot water, steam, or prolonged submersion. Do not operate buttons underwater.
- **Charging:** Use only the provided magnetic charging cable. Ensure the charging contacts are clean and dry before charging.
- **Storage:** Store the watch in a cool, dry place when not in use. Avoid extreme temperatures.
- **Strap Replacement:** The watch comes with two interchangeable straps. To replace, locate the quick-release pins on the back of the strap and gently slide them to detach. Align the new strap and secure



the pins.

## 6. TROUBLESHOOTING

Problem	Possible Solution
Watch does not turn on.	Ensure the watch is fully charged. Connect to the charger for at least 10 minutes before attempting to turn it on.
Cannot pair with smartphone.	<ol style="list-style-type: none"><li>1. Ensure Bluetooth is enabled on both the watch and phone.</li><li>2. Make sure the FitCloudPro app has all necessary permissions.</li><li>3. Restart both the watch and phone.</li><li>4. Forget the device in your phone's Bluetooth settings and try pairing again.</li><li>5. Ensure the watch is within Bluetooth range of the phone.</li></ol>
Bluetooth call function not working.	<ol style="list-style-type: none"><li>1. Ensure the "Watch Call" Bluetooth connection is established in your phone's Bluetooth settings (separate from the app connection).</li><li>2. Check if the Bluetooth call feature is enabled on the watch itself.</li></ol>
Notifications not received.	<ol style="list-style-type: none"><li>1. Verify that app notifications are enabled in the FitCloudPro app.</li><li>2. Check your phone's system notification settings to ensure FitCloudPro has access.</li><li>3. Ensure the watch is connected to the phone via Bluetooth.</li></ol>
Inaccurate health data.	Ensure the watch is worn snugly on your wrist, about one finger's width from the wrist bone. Avoid excessive movement during measurements. Note that this device is not a medical device.

## 7. SPECIFICATIONS

Feature	Detail
Brand	LIGE
Model Number	BW1845B-CC
Screen Size	1.32 Inches
Operating System	Wear OS (Note: This might be a generic classification, actual OS is proprietary for FitCloudPro)
Connectivity	Bluetooth 5.0
Battery Type	Lithium-polymer
Battery Life (Typical Use)	3-5 days

Feature	Detail
Standby Time	7-15 days
Charging Time	Approx. 2 hours
Water Resistance	IP67
Compatible Devices	iOS 8.4+ / Android 4.4+ with Bluetooth 4.2+
Special Features	Bluetooth Call, 20+ Sports Modes, Health Monitoring (HR, Sleep, SpO2, BP, Female Cycle), Message Notifications, AI Voice Assistant, Weather, Music Control, Camera Remote, Find Phone.

## 8. WARRANTY AND SUPPORT

LIGE provides customer support for its products. If you encounter any issues or have questions not covered in this manual, please refer to the contact information provided with your product packaging or visit the official LIGE website for support.

Please note that the warranty typically covers manufacturing defects. Damage caused by misuse, accidents, or unauthorized modifications may not be covered. Always retain your proof of purchase for warranty claims.

As stated in the product features, LIGE offers 7\*24 hour service. For assistance, please contact the seller directly through the platform where you purchased the product or refer to the contact details provided in the product's original packaging.