



Manuals.plus /

› Geeni /

› Geeni Smart Water Alarm Leak Detector with Siren - User Manual

Geeni B0D47W56TY

Geeni Smart Water Alarm Leak Detector with Siren - User Manual

Model: B0D47W56TY

INTRODUCTION

The Geeni Smart Water Alarm Leak Detector with Siren is designed to provide early warning of water leaks in your home. This device helps prevent potential water damage by detecting leaks and alerting you through its built-in siren and mobile application. It integrates with your home Wi-Fi network for remote monitoring and smart home automation.

Key Features

- **Instant Leak Detection:** Rapidly identifies the presence of water.
- **Real-Time Alerts:** Sends immediate notifications to your smartphone.
- **Built-in 80dB Alarm:** Emits a loud siren to alert occupants.
- **Monitor from Anywhere:** Access device status and alerts remotely via the Geeni app.
- **Smart Home Integration:** Compatible with other Geeni smart home products for automated responses.
- **Low Battery Alert:** Notifies you when batteries need replacement.
- **Easy Setup:** Designed for quick and straightforward installation.
- **24/7 Peace of Mind:** Continuous monitoring for enhanced home safety.

Multi-Use

This multi-use water sensor acts as your early warning system for leaks.




Figure 1: Key features of the Geeni Smart Water Alarm Leak Detector.

PACKAGE CONTENTS

Verify that all items are present in the package:

- 1x Geeni Smart Water Sensor
- 1x Siren Mounting Adhesive
- 1x User Manual
- 2x AAA Batteries



Figure 2: Contents included in the product package.

PRODUCT OVERVIEW

Familiarize yourself with the components of your Geeni Smart Water Alarm Leak Detector:

- **LED Light:** Indicates device status (e.g., pairing mode, leak detected).
- **Set Key:** Used for pairing and resetting the device.
- **Speaker:** Emits the 80dB siren alarm.
- **Sensor Probe:** The part that detects water. Must be placed flat on the surface where leaks may occur.
- **Battery Compartment:** Holds 2x AAA batteries.
- **Cable Length:** The sensor probe is connected to the main unit by a 3.28 ft (1 m) cable.

Package Includes




Figure 3: Front and back view of the device with labeled components and dimensions.

SETUP

1. Install Batteries

1. Open the battery compartment on the back of the main unit.
2. Insert 2x AAA batteries, ensuring correct polarity.
3. Close the battery compartment securely.

2. Download and Install the Geeni App

- Search for "Geeni" in the Apple App Store or Google Play Store.
- Download and install the app.
- Register for a new account or log in if you already have one.

3. Pair the Device with Wi-Fi

1. Ensure your smartphone is connected to a 2.4 GHz Wi-Fi network. The device does not support 5 GHz networks.

2. Open the Geeni app and tap the "+" icon to add a new device.
3. Follow the on-screen instructions in the app to put the water sensor into pairing mode and connect it to your Wi-Fi network. The LED light on the device will indicate its pairing status.

4. Device Placement

Strategically place the water sensor in areas prone to leaks:

- Under sinks (kitchen, bathroom)
- In basements
- Near water heaters
- In laundry rooms
- Behind dishwashers or refrigerators

Use the provided mounting adhesive to secure the main unit. Ensure the sensor probe lies flat on the surface where water might accumulate first.



Figure 4: Examples of multi-use placement for the water sensor.

Leak Detection and Alerts

Once installed and connected, the Geeni Smart Water Alarm continuously monitors for water. When the sensor probe detects water:

- The device will emit a loud 80-decibel siren.
- You will receive an immediate notification on your smartphone via the Geeni app.




Figure 5: Real-time leak detection and app notification.

Adjusting Alarm Settings

You can customize the alarm settings through the Geeni app:

- **Siren Volume:** Adjust the volume from mute (0dB) up to 80dB.
- **Alarm Duration:** Set the duration of the siren from 30 seconds to 180 seconds.

Detect Leaks Instantly

Get real-time notifications to your phone so you can act fast, even when you're not home.




Figure 6: Alarm volume and duration adjustment options.

MAINTENANCE

Battery Replacement

The device is powered by 2x AAA batteries with an expected lifespan of 3-4 months. The Geeni app will send a low battery alert when replacement is needed.

1. When a low battery alert is received, open the battery compartment.
2. Remove the old batteries and insert two new AAA batteries, observing correct polarity.
3. Close the battery compartment.

Testing the Device

It is recommended to periodically test the water sensor to ensure it is functioning correctly:

1. Place a small amount of water (e.g., a few drops) onto the sensor probe.
2. Verify that the siren sounds and you receive a notification on your smartphone.
3. Dry the sensor probe thoroughly after testing.

TROUBLESHOOTING

- Device not connecting to Wi-Fi:**
 Ensure your Wi-Fi network is 2.4 GHz. The device does not support 5 GHz. Try moving the device closer to your Wi-Fi router. If issues persist, try deleting the device from the Geeni app and re-pairing it following the setup instructions.
- No app notifications:**
 Check your smartphone's notification settings for the Geeni app to ensure notifications are enabled. Also, verify that the device is properly connected to Wi-Fi and has sufficient battery power.
- Siren not sounding or too quiet:**
 Check the battery level. Ensure the siren volume is not set to mute in the Geeni app settings.
- Sensor not detecting water:**
 Ensure the sensor probe is lying flat and making good contact with the surface where water might collect. Clean the sensor contacts if they appear dirty.
- Device appears offline in app:**
 Check your Wi-Fi connection. If the Wi-Fi network is down or unstable, the device may appear offline. Replace batteries if they are low.

For further assistance, refer to the support section within the Geeni app or visitsupport.mygeeni.com.

SPECIFICATIONS

Brand	Geeni
Model	B0D47W56TY
Power Source	Battery Powered (2x AAA)
Battery Life	Approximately 3-4 months
Compatible Devices	Android, iOS (Smartphone, Tablet)
Product Dimensions (Main Unit)	3.54"L x 1.97"W x 5.12"H (90mm L x 50mm W x 130mm H)
Control Method	Geeni App
Audible Noise	80 Decibels
Mounting Type	Adhesive (for main unit), Sensor probe placed on surface
Sensor Technology	Contact Sensor
Cable Length (Sensor)	3.28 ft (1 m)
Wi-Fi Connectivity	2.4 GHz only
IP Rating	IP44

WARRANTY AND SUPPORT

Warranty Information

This Geeni product comes with a **1-year limited warranty** from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers defects in materials and workmanship under normal use.

Customer Support

If you encounter any issues or have questions regarding your Geeni Smart Water Alarm Leak Detector, please contact Geeni customer support:

- **Online Support:** Visit support.mygeeni.com
- **In-App Support:** Access support directly through the Geeni mobile application.