



[Manuals.plus](#) /

› [Life360](#) /

› Life360 Tile Bluetooth Tracker (Model T1801A) User Manual

Life360 T1801A

Life360 Tile Bluetooth Tracker (Model T1801A) User Manual

Model: T1801A | Brand: Life360

INTRODUCTION

The Life360 Tile is a versatile Bluetooth tracker designed to help you locate important items such as keys, bags, and other personal belongings. It integrates with the Life360 app to provide location tracking, ringing capabilities, and an SOS alert feature for enhanced safety. This manual provides detailed instructions for setting up, operating, and maintaining your Life360 Tile.



Image: The Life360 Tile, a compact white square device with a central button and a small loop for attaching to items.

SETUP INSTRUCTIONS

1. **Download the Life360 App:** The Life360 Tile requires the Life360 app for full functionality. Download the free Life360 app from the Apple App Store (for iOS devices) or Google Play Store (for Android devices).
2. **Create/Log In to Life360 Account:** Open the app and either create a new account or log in to an existing one.
3. **Enable Location Services:** Ensure that location services are enabled on your smartphone for the Life360 app to accurately track your Tile.
4. **Add Your Tile:**
 - In the Life360 app, navigate to the section for adding new devices or items.
 - Follow the on-screen prompts to pair your Tile. This typically involves pressing the button on your Tile once to begin activation. The Tile will play a tune to confirm activation.
 - Hold your Tile device next to your phone during the pairing process.

5. **Attach Your Tile:** Attach the Tile to the item you wish to track (e.g., keys, bag, backpack). The Tile Mate includes a small hole for attaching to keyrings or carabiners.



Image: A Life360 Tile attached to a backpack, demonstrating how to secure the device to personal items.

OPERATING YOUR LIFE360 TILE

Your browser does not support the video tag.

Video: An official demonstration of the Tile Mate (2024) Bluetooth Tracker, showcasing its use for finding keys, bags, and other items.

Finding Your Items

To locate an item with your Life360 Tile:

1. Open the Life360 app on your smartphone.
2. Select the Tile associated with the item you wish to find.

3. Tap the "Find" button in the app. Your Tile will ring loudly, helping you pinpoint its location.
4. If the item is out of Bluetooth range, the app will display its last known location on a map.




Image: A smartphone screen displaying the Life360 app with a map indicating the location of a Tile, along with a prominent 'Find' button.

Finding Your Phone

If you misplace your phone, you can use your Life360 Tile to find it:

- Double-press the button on your Life360 Tile.
- Your phone will ring, even if it is set to silent mode, allowing you to quickly locate it.



Image: A hand double-pressing the central button on a Life360 Tile, illustrating the feature to make a paired smartphone ring.

SOS Alert Feature

The Life360 Tile can also function as an SOS button:

- In unsafe situations, discreetly trigger an SOS alert to your Life360 Circle.
- This feature requires the Life360 app and Life360 account registration.



Image: A Life360 Tile with red concentric circles emanating from it, symbolizing the activation of an SOS alert.

Tracking on a Map

View the location of your Tile and other members of your Life360 Circle on a unified map within the app.




Image: A smartphone displaying the Life360 app interface, showing a map with various tracked items and family members' locations.

MAINTENANCE

Battery Life

The Life360 Tile features a non-replaceable battery with an average life of up to 3 years. When the battery is depleted, the Tile will need to be replaced.

Water Resistance

The Life360 Tile is water-resistant with an IP68 rating, meaning it can withstand submersion in water up to 1.5 meters for up to 30 minutes. However, it is not recommended for prolonged underwater use.

Cleaning

To clean your Tile, gently wipe it with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.

TROUBLESHOOTING

- **Tile Not Connecting:**

- Ensure your phone's Bluetooth is enabled.
- Make sure the Tile is within Bluetooth range (up to 350 feet / 105m).
- Check if the Tile's battery is still active (indicated by a sound when pressed).
- Restart the Life360 app or your smartphone.

- **Tile Not Ringing:**

- Verify that the volume on your Tile is not muted within the app settings.
- Ensure the Tile is within Bluetooth range.

- **Phone Not Ringing When Tile is Pressed:**

- Confirm that your phone is within Bluetooth range of the Tile.
- Check the Life360 app settings to ensure the "Find Your Phone" feature is enabled and has necessary permissions.

- **Inaccurate Location:**

- Ensure location services are always enabled for the Life360 app on your phone.
- The accuracy of the last known location depends on the Tile's connection to your phone or other Tile network devices.

SPECIFICATIONS

Brand	Life360
Model Number	T1801A (RE-60021)
Material	Plastic
Product Dimensions	1.49"L x 1.49"W x 0.28"Th
Item Weight	8 Grams
Connectivity Technology	Bluetooth
Bluetooth Range	Up to 350 feet / 105m
Battery Type	1 Lithium Metal battery (included, non-replaceable)
Battery Average Life	Up to 3 years
Water Resistance	IP68 Rated
Compatible Devices	Smartphone, Tablet (iOS and Android)
Control Method	App
Smart Home Compatibility	Smart Home Compatible
UPC	819039025027

WARRANTY AND SUPPORT

Warranty Information

The Life360 Tile comes with a 1-Year Limited Warranty. For details regarding warranty claims and coverage, please refer to the official Life360 website or contact customer support.

Customer Support

For further assistance, technical support, or to access additional resources, please visit the official Life360 support website or contact their customer service team. You can find more information at tile.com.