

EKO EK9380MT-10L

EKO Small Bathroom Trash Can User Manual

Model: EK9380MT-10L | Brand: EKO

1. INTRODUCTION

Thank you for choosing the EKO Small Bathroom Trash Can. This manual provides essential information for the proper setup, operation, and maintenance of your new 10 Liter / 2.6 Gallon Stainless Steel trash can. Designed for efficiency and aesthetics, this product features a soft-close lid, step pedal, removable inner bucket, and an anti-fingerprint finish.



Image 1.1: The EKO Small Bathroom Trash Can in Silver Stainless Steel.

2. PRODUCT OVERVIEW

Key Features:

- **Fingerprint-Resistant Finish:** Maintains a clean appearance with minimal effort.
- **Soft-Close Lid:** Ensures quiet and smooth operation.
- **Space-Saving Design:** Compact dimensions (11.2"L×6.2"W×12.4"H) ideal for small spaces.
- **Manual Stay-Open Function:** Lid can be held open at 90° for extended tasks.
- **Durable Step-On Pedal:** Engineered for long-lasting, reliable use.

- **Removable Inner Bucket:** Facilitates easy waste disposal and cleaning.

Components:

- Outer Stainless Steel Body
- Lid Assembly (with soft-close mechanism)
- Step Pedal
- Removable Inner Bucket
- Bag Stabilizer (on inner bucket)



Image 2.1: The removable inner bucket for easy cleaning and bag changes.

Space-Saving Elegance

Maximize your bathroom space with EKO's compact design, perfect for tight spots while adding a modern touch.



Image 2.2: The space-saving design of the trash can, fitting into tight spaces.



Image 2.3: Detail of the durable foot pedal and integrated handle for easy movement.

3. SETUP INSTRUCTIONS

1. **Unpack the Product:** Carefully remove all components from the packaging. Ensure all parts listed in the "Components" section are present.
2. **Position the Inner Bucket:** Place the removable inner bucket inside the stainless steel outer body. Ensure it sits securely at the bottom.
3. **Insert Trash Bag:** Line the inner bucket with a suitable trash bag (e.g., EKO Bin Liners size C). Use the bag stabilizer ring on the inner bucket to secure the bag and prevent it from slipping.
4. **Placement:** Position the trash can in your desired location. Its compact design makes it suitable for bathrooms, bedrooms, or home offices.

4. OPERATING INSTRUCTIONS

Opening the Lid:

- **Step Pedal Operation:** Gently press down on the foot pedal to open the lid. Release the pedal, and the lid will close softly and silently.

- **Manual Stay-Open:** For longer tasks or when frequently disposing of waste, lift the lid manually to a 90° angle. The lid will remain open until you gently push it down to close.

Soft-Close & Stay-Open

Silent, gentle closing

Lift the lid to 90° for stay open



Image 4.1: Illustration of the soft-close and manual stay-open lid functions.

Disposing of Waste:

Once the lid is open, place waste into the inner bucket. Ensure not to overfill the bucket to allow the lid to close properly.

5. MAINTENANCE

Cleaning the Outer Body:

- The stainless steel body features an anti-fingerprint finish. To clean, wipe with a soft, damp cloth and a mild, non-abrasive cleaner.
- Avoid using harsh chemicals, abrasive pads, or steel wool, as these can damage the finish.
- Dry thoroughly with a soft cloth to prevent water spots.

Fingerprint Resistant

Enjoy a pristine and sleek appearance that lasts, without the hassle of constant cleaning.



Image 5.1: The fingerprint-resistant surface helps maintain a clean appearance.

Cleaning the Inner Bucket:

- Remove the inner bucket from the outer body.
- Wash the inner bucket with warm, soapy water.
- Rinse thoroughly and ensure it is completely dry before placing it back into the trash can.

6. TROUBLESHOOTING

- **Lid not closing softly:** Check for any obstructions around the lid mechanism or hinges. Ensure the inner bucket is correctly seated.
- **Lid not opening fully:** Verify that the pedal mechanism is free from debris and operates smoothly.
- **Trash bag slipping:** Ensure the trash bag is properly secured under the bag stabilizer ring of the inner bucket.
- **Unpleasant odors:** Regularly clean the inner bucket and consider using odor-absorbing products if necessary. Ensure the lid closes completely to seal in odors.

7. SPECIFICATIONS

Feature	Detail
Brand	EKO
Model Number	EK9380MT-10L
Capacity	10 Liters / 2.6 Gallons
Color	Silver
Material	Stainless Steel
Opening Mechanism	Step-On Pedal
Special Features	Compact, Odor Seal, Portable, Quiet Close, Removable Bucket, Anti-Fingerprint Finish
Product Dimensions (L x W x H)	13.8" x 6.6" x 13.9" (35.05 cm x 16.76 cm x 35.31 cm)
Item Weight	5.25 Pounds (2.38 kg)
Recommended Uses	Indoor (Bathroom, Bedroom, Dormitory, Home Office)



8. WARRANTY AND SUPPORT





EKO products are manufactured with high-quality materials and craftsmanship. For specific warranty details, please refer to the warranty card included with your purchase or visit the official EKO website. If you encounter any issues or require assistance, please contact EKO customer support through their official channels.

For further information or to register your product, please visit:www.eko.com

© 2025 EKO. All rights reserved.

Related Documents - EK9380MT-10L

	<p>EKO Mirage Semi-Round Sensor Bin EK9331 User Manual & Instructions</p> <p>User manual for the EKO Mirage Semi-Round Sensor Bin (Model EK9331). Learn how to set up, operate using sensor or manual modes, change bags, and troubleshoot this automatic trash can.</p>
	<p>EKO BAND User Manual: Features, Setup, and Troubleshooting</p> <p>Comprehensive user manual for the EKO BAND fitness tracker. Learn about setup, features, app integration, charging, and troubleshooting. Compatible with iOS and Android devices.</p>

 <p>The image shows the cover of the 'DUO Quick Start Guide'. It features the 'DUO' title at the top, followed by the 'Eko' logo. Below is a 'Quick Start Guide' section. The first part is '1 SETTING UP THE DUO', which includes 'Charge Your Device' instructions and a diagram of the device being charged. It also lists 'DUO Light Patterns' with six circular icons representing different battery levels and states (e.g., 'DUO is on, waiting in setup mode', 'DUO is on, 20% battery', 'DUO is on, waiting 50% battery', 'DUO is charging, Lights on/intermittent', 'DUO is fully charged'). The second part is '2 INSTALL DUO EARPICES', with 'Hear Audio' instructions and a diagram of the device with earpieces. At the bottom, it says 'Download the Eko App' and lists features: 'Pair DUO with Eko App', 'View Sound & ECG Waveforms', 'Save & Share Recordings', and 'Connect a Pair of Wireless Headphones (limited compatibility)'. There is a QR code and a smartphone displaying the app interface.</p>	<p>Eko DUO Quick Start Guide: Setup, Usage, and App Integration</p> <p>A concise guide to setting up and using the Eko DUO digital stethoscope, including charging, earpiece installation, app connection, and sound/ECG capturing.</p>
 <p>The image shows the cover of the 'Eko Low Ejection Fraction Tool (ELEFT) User Manual'. It features the 'eko' logo at the top, followed by the title 'Eko Low Ejection Fraction Tool (ELEFT) User Manual'. At the bottom, it says 'Version 1.0'.</p>	<p>Eko Low Ejection Fraction Tool (ELEFT) User Manual - Comprehensive Guide</p> <p>User manual for the Eko Low Ejection Fraction Tool (ELEFT), a software designed for decision support in identifying individuals with low ejection fraction. Includes technical specifications, system requirements, and usage guidelines.</p>
 <p>The image shows the cover of the 'EKO Mirage X Sensor Bin EK9260/EK9260R User Manual and Operating Instructions'. It features a grid of small images showing the device and its components.</p>	<p>EKO Mirage X Sensor Bin EK9260/EK9260R User Manual and Operating Instructions</p> <p>Detailed user manual for the EKO Mirage X Sensor Bin (models EK9260 and EK9260R). Learn about product features, power supply options, sensor and manual operation, bin bag changes, accessories, troubleshooting, and warranty information.</p>
 <p>The image shows a blue and black digital watch with a black strap. The watch face is black with blue accents and displays '12:12'. The 'eko' logo is visible on the watch face. Below the watch, it says 'Manuel d'utilisation Modèle : ICE'.</p>	<p>Manuel d'utilisation EKO Modèle ICE : Guide Complet</p> <p>Manuel d'utilisation détaillé pour la montre EKO Modèle ICE. Apprenez à régler l'heure, la date, l'alarme, utiliser le chronomètre et découvrez les caractéristiques du produit.</p>

