

ClokoWe T08

CLOKOWE Mini Projector User Manual

Model: T08

INTRODUCTION

Thank you for purchasing the CLOKOWE Mini Projector. This portable projector is designed to provide a versatile and immersive viewing experience, supporting 4K FHD 1080P resolution, dual-band WiFi 6, Bluetooth 5.2, and featuring 180° rotation with auto keystone correction. This manual will guide you through the setup, operation, and maintenance of your new projector.

WHAT'S IN THE Box

- CLOKOWE Mini Projector
- HDMI Cable
- Power Cord
- Remote Control
- User Manual

PRODUCT OVERVIEW

Familiarize yourself with the components of your CLOKOWE Mini Projector.



Figure 1: Front and side view of the CLOKOWE Mini Projector, showing the lens and cylindrical body with integrated stand.



Dual-Band WiFi6 Connection

Faster wireless speed, wider range and smoother transmission

Figure 2: The projector in use, demonstrating its Dual-Band WiFi 6 connectivity for faster and smoother wireless transmission compared to 5G WiFi.




Figure 3: Visual comparison highlighting the 10000:1 contrast ratio of the CLOKOWE T08 projector versus a 4000:1 ratio, showing improved color brightness and detail.

Brilliant 4K Clarity

Full-format decoding including 4K@30fps
and 1080p/60fps decoding and so on

HEVC
H.265

AVC
H.264

VP9

AV1



Figure 4: Illustration of the projector's internal CPU and its capability for brilliant 4K clarity, supporting full-format decoding including HEVC, AVC, VP9, and AV1.




Figure 5: The projector demonstrating its 180-degree rotation feature, allowing projection onto walls, ceilings, or floors for flexible viewing angles.

$\pm 45^\circ$ Auto Keystone Correction




Figure 6: The projector illustrating its $\pm 45^\circ$ Auto Keystone Correction feature, which automatically adjusts the image to be rectangular even when projected from an angle.

Home Theater



Figure 7: A family enjoying a home theater experience with the CLOKOWE Mini Projector, showcasing its use for entertainment.

SETUP

1. Power Connection

1. Connect the provided power cord to the projector's power input port.
2. Plug the other end of the power cord into a standard electrical outlet.
3. The projector will enter standby mode, indicated by a power indicator light.

2. Placement and Projection Angle

The CLOKOWE Mini Projector features a 180° rotatable design, allowing flexible placement.

- Place the projector on a stable, flat surface.
- Adjust the projector's angle to project onto a wall, ceiling, or screen. The integrated stand allows for easy rotation.
- Ensure there are no obstructions between the projector lens and the projection surface.

3. Focus and Keystone Correction

The projector is equipped with automatic keystone correction for a clear, rectangular image.

- The projector features 45° Auto Keystone Correction, which will automatically adjust the image shape to be rectangular.
- For manual focus adjustment, if available, use the focus ring on the projector lens until the image is sharp. (Note: The product description emphasizes auto keystone, implying focus might also be automatic or less critical).

OPERATING INSTRUCTIONS

1. Power On/Off

- To power on, press the power button on the projector or the remote control.
- To power off, press the power button again. Confirm shutdown if prompted.

2. Connectivity Options

The projector offers multiple ways to connect your devices.

Wi-Fi Connection (Dual-Band WiFi 6)

1. Navigate to the Wi-Fi settings on the projector's main menu.
2. Select your desired 2.4G or 5G Wi-Fi network from the list.
3. Enter the Wi-Fi password using the on-screen keyboard and remote control.
4. Once connected, you can use screen mirroring features.

Bluetooth 5.2 Connection

Connect external audio devices like headphones or speakers.

- Go to the Bluetooth settings in the projector's menu.
- Enable Bluetooth and search for available devices.
- Select your Bluetooth audio device from the list to pair.
- **Note:** Bluetooth can only be used with sound devices, not for smartphones or other input devices.

HDMI Connection

- Connect one end of the HDMI cable to the HDMI port on the projector.
- Connect the other end to the HDMI output port of your source device (e.g., laptop, TV stick, game console).

- Select the HDMI input source from the projector's input menu.

USB Connection

- Insert a USB flash drive into the USB port on the projector.
- The projector should automatically detect the USB drive or allow you to select it from the input menu to browse media files.

3. Screen Mirroring (Wireless Projection)

The projector supports wireless screen mirroring for iOS, Android, and Windows devices via Wi-Fi 6.

- Ensure both the projector and your device are connected to the same Wi-Fi network.
- On the projector, select the "Screen Mirroring" or "Wireless Projection" option from the main menu.
- Follow the on-screen instructions specific to your device's operating system (e.g., AirPlay for iOS, Cast/Smart View for Android, Project to a wireless display for Windows).

4. Adjusting Projection Size

The projector can display an image up to 200 inches diagonally.

- Adjust the distance between the projector and the projection surface to change the image size. Moving the projector further away will increase the image size, and closer will decrease it.
- The auto keystone correction will help maintain image quality regardless of the projection angle.

MAINTENANCE

- **Cleaning the Lens:** Use a soft, lint-free cloth specifically designed for optical lenses. Do not use abrasive cleaners or cloths that could scratch the lens.
- **Cleaning the Projector Body:** Wipe the exterior with a soft, dry cloth. For stubborn marks, a slightly damp cloth can be used, followed by a dry one.
- **Ventilation:** Ensure the projector's ventilation openings are not blocked to prevent overheating. The projector has an advanced heat dissipation system, but proper airflow is still crucial.
- **Storage:** When not in use for extended periods, store the projector in a cool, dry place, away from dust and direct sunlight.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No image projected	Power not connected; Incorrect input source; Source device not outputting signal.	Check power cord connection; Select correct input source (HDMI, USB, Screen Mirroring); Ensure source device is on and configured to output video.
Image is blurry	Out of focus; Incorrect projection distance.	Adjust focus (if manual); Adjust projector distance from screen; Ensure auto keystone is active.
Image is trapezoidal/distorted	Projector not perpendicular to screen.	The projector has 45° Auto Keystone Correction. Ensure it is enabled in settings. Reposition the projector if distortion persists.

Problem	Possible Cause	Solution
No sound	Volume too low; Incorrect audio output selected; Bluetooth device not connected.	Increase volume; Check audio settings on projector and source device; Re-pair Bluetooth audio device.
Cannot connect to Wi-Fi	Incorrect password; Network out of range; Router issues.	Verify Wi-Fi password; Move projector closer to router; Restart router and projector.
Remote control not working	Dead batteries; Obstruction between remote and projector.	Replace batteries; Ensure clear line of sight to the projector's IR receiver.

SPECIFICATIONS

Feature	Detail
Model Number	T08
Product Dimensions	3.58 x 3.58 x 7.6 inches
Item Weight	2.01 pounds
Display Resolution	1024 x 720 (Native), 1920x1080P (Supported)
Video Decoding	HEVC/VP9/AVS2/AVC 4K@30fps, AV1/MPEG1/MPEG2 1080p/60fps
Connectivity Technology	3.5mm Jack, Bluetooth 5.2, HDMI, USB, Wi-Fi 6 (2.4G & 5G)
Projection Rotation	180° Rotatable
Keystone Correction	45° Auto Keystone Correction
Max Display Size	200 inches (508 cm)
Built-in Speaker	1x3W Hi Fi speaker
Manufacturer	ClokoWe
Date First Available	June 11, 2024

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official ClokoWe website or contact their customer service directly. Details can typically be found on the product packaging or the manufacturer's official online presence. You can visit the ClokoWe Store on Amazon for more information:[ClokoWe Store](#)

ClokoWe T08



[ClokoWe T08 Portable LCD LED Projector: Full HD, 4K Compatible, Android](#)

Discover the ClokoWe T08, a portable LCD LED projector offering Full HD 1080P resolution, 4K compatibility, and integrated Android 11.0. Features include Wi-Fi, Bluetooth 5.2, automatic keystone correction, and a 30,000-hour LED lifespan.

lang:en score:36 filesize: 146.28 K page_count: 2 document date: 2024-10-26