

SAFFUN Y-D002-604

SAFFUN 2.4 GHz Wireless N64 Controller User Manual

Model: Y-D002-604

INTRODUCTION

Welcome to your SAFFUN 2.4 GHz Wireless N64 Controller. This manual provides detailed instructions for setting up, operating, and maintaining your controller to ensure optimal performance and an enhanced gaming experience on your Nintendo 64 console.

WHAT'S IN THE BOX

- Wireless Controller
- N64 Receiver
- Charging Cable
- User Manual (this document)

PRODUCT FEATURES

- **2.4 GHz Wireless Connection:** Enjoy seamless gaming up to 10 meters (33 feet) with no delays or dropouts.
- **Plug and Play:** Easy setup with the included N64 receiver.
- **Built-in Vibration Motor:** Provides immersive haptic feedback without an external Rumble Pak.
- **Rechargeable Battery:** Integrated 500mAh battery offers up to 10 hours of usage time after a 2.5-hour charge. Features a battery level indicator.
- **Player Indicator & Low Battery Warning LED:** Clear visual cues for controller status.
- **3D Analog Stick:** Enhances precision and comfort for improved gameplay, designed to eliminate stick drift.
- **Ergonomic Design:** Shaped for comfortable grip during extended play sessions.

Enhanced


2.4 GHz Wireless Controller

For Nintendo N64



- Wireless Connection
- 10 Hours Playing
- Low Battery Reminder
- Ergonomic Design
- Multi-Platform Compatibility
- Precise Control

Image: The SAFFUN N64 Wireless Controller highlighting its built-in vibration motor for enhanced gaming feedback.



- Up to 10 Meters (33 Feet)
- Eliminating Delays
- Eliminating Dropouts
- Eliminating Interference

Wireless Freedom

The enhanced wireless controller frees you from the shackles of cables, so that you can kick back, get comfortable and play from anywhere in the room.

Image: Close-up of the controller's precision 3D Analog Stick, designed to prevent stick drift.



Image: Illustration showing the controller's large capacity 500mAh battery, 2.5 hours charging time, and 10 hours usage time.



Image: Hands holding the SAFFUN N64 Wireless Controller, demonstrating its ergonomic design for comfortable grip.

SETUP INSTRUCTIONS

1. Charging the Controller

Connect the included charging cable to the Type-C port on the controller and to a standard USB power source (e.g., console USB port, USB wall adapter). The LED indicator will show charging status. A full charge takes approximately 2.5 hours. A fully charged controller provides up to 10 hours of gameplay.

2. Connecting the Receiver

Insert the N64 receiver into a controller port on your Nintendo 64 console. Ensure the console is powered off before inserting or removing the receiver.

3. Pairing the Controller

1. Power on your Nintendo 64 console.
2. Press the small black button on the N64 receiver.
3. Immediately press the red button on the wireless controller.
4. The controller and receiver will pair automatically. A successful connection will be indicated by the player indicator LED on the controller. The controller is now ready for use.



Image: Diagram illustrating the button layout of the SAFFUN N64 Wireless Controller, including the Type-C charging port.

100% COMPATIBILITY GUARANTEE

Specially designed for Nintendo N64 System. Perfectly compatible with N64 Console via N64 Receiver Connection



Image: A Nintendo 64 console with the SAFFUN N64 receiver plugged into a controller port, demonstrating compatibility.

OPERATING INSTRUCTIONS

Basic Controls

The controller features a standard N64 button layout, including A, B, C-buttons, Start, 3D Analog Stick, D-Pad, L, R, and ZR buttons. Refer to the button layout diagram in the Setup section for specific button locations.

Power On/Off

To power on the controller, press any button. It will attempt to connect to the last paired receiver. The controller will automatically enter sleep mode after a period of inactivity to conserve battery. To manually power off, press and hold the Home button for a few seconds.

Battery Level Indicator

The controller features an LED indicator to show battery status. A low battery warning LED will illuminate when charging is required.

Rumble Function

The built-in vibration motor provides haptic feedback during gameplay, eliminating the need for a separate

Rumble Pak. This feature is automatically active when supported by the game.

MAINTENANCE

Cleaning

Wipe the controller with a soft, dry cloth. Do not use liquid cleaners or solvents. Avoid getting moisture into any openings.

Storage

Store the controller in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, ensure the battery is partially charged (around 50%) to prolong its lifespan.

Battery Care

Do not attempt to replace the built-in battery. Contact support if battery issues arise. Avoid fully discharging the battery frequently. Charge the controller regularly, even if not in use, to maintain battery health.

TROUBLESHOOTING

Controller Not Connecting

- **Ensure Receiver is Connected:** Verify the N64 receiver is securely plugged into a controller port on the console.
- **Re-pair Controller:** Follow the pairing steps in the "Setup Instructions" section (press receiver button, then controller red button).
- **Check Battery:** Ensure the controller is charged. Connect the charging cable and check the LED indicator.
- **Interference:** Move closer to the console or away from other 2.4 GHz wireless devices that might cause interference.

Lag or Disconnections

- **Distance:** Ensure you are within the 10-meter (33 feet) operating range.
- **Obstructions:** Minimize physical obstructions between the controller and the receiver.
- **Battery Level:** A low battery can affect wireless performance. Recharge the controller.

Buttons or Analog Stick Not Responding

- **Re-pair:** Try re-pairing the controller as described above.
- **Restart Console:** Power off and on your N64 console.
- **Clean:** Ensure no debris is obstructing buttons or the analog stick.

No Vibration Feedback

- **Game Compatibility:** Verify that the game you are playing supports rumble features.
- **Controller Settings:** Some games may have in-game options to enable/disable rumble. Check game settings.

SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Model Number	Y-D002-604
Connectivity	2.4 GHz Wireless
Wireless Range	Up to 10 meters (33 feet)
Battery Capacity	500mAh Lithium Battery
Charging Time	Approx. 2.5 hours
Usage Time	Approx. 10 hours
Power Source	Battery Powered (Rechargeable)
Compatible Devices	Nintendo 64 Console
Built-in Features	Vibration Motor, Player Indicator, Low Battery Warning LED
Analog Stick	3D Analog Stick (Japanese Imported)
Dimensions	8 x 6 x 0.72 inches
Weight	150 Grams

WARRANTY INFORMATION

For warranty details, please refer to the product packaging or contact SAFFUN customer support. Keep your proof of purchase for warranty claims.

CUSTOMER SUPPORT

If you encounter any issues or have questions not covered in this manual, please contact SAFFUN customer support through the retailer's platform or the official SAFFUN website.