

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ANJANK](#) /

› [ANJANK White Noise Sound Machine Alarm Clock User Manual \(Model: B0D8BCSQTH\)](#)

### ANJANK B0D8BCSQTH

# ANJANK White Noise Sound Machine Alarm Clock User Manual

Model: B0D8BCSQTH

[Overview](#) [Safety Information](#) [Package Contents](#) [Setup](#) [Operating Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

## PRODUCT OVERVIEW

The ANJANK White Noise Sound Machine Alarm Clock is a versatile 4-in-1 device designed to enhance your sleep and daily routine. It combines a white noise sound machine, a digital alarm clock, a Bluetooth speaker, and a multi-color night light into a single compact unit. This device offers a range of soothing sounds, customizable alarm options, and convenient features for a restful environment.

# 4-In-1

## White Noise Machine



Sound  
Machine



Alarm  
Clock



Bluetooth  
Speaker



Night  
Light



Image: The ANJANK White Noise Sound Machine Alarm Clock in pink, showcasing its compact design and digital display.

### SAFETY INFORMATION

- Use appropriate batteries as specified in the manual.
- Keep the device out of reach of children.
- Prolonged use of the noise feature at high volumes may cause hearing damage.
- Do not expose the device to water or excessive moisture.
- Avoid disassembling or attempting to repair the device yourself. Contact customer support for assistance.

### PACKAGE CONTENTS

Ensure all items are present upon unboxing:

- ANJANK White Noise Sound Machine Alarm Clock
- Power Adapter/Charging Cable
- User Manual (this document)

## SETUP GUIDE

1. **Power Connection:** Connect the provided power adapter to the DC IN port on the back of the device and plug it into a standard wall outlet. The device will power on automatically.
2. **Setting the Time:**
  - Press and hold the "Time Set" button (usually indicated by a clock icon) until the hour digits begin to flash.
  - Use the "+" or "-" buttons to adjust the hour.
  - Press "Time Set" again to switch to minute adjustment, then use "+" or "-" to set the minutes.
  - Press "Time Set" once more to confirm and exit time setting mode.
  - The device features auto time sync with Daylight Saving Time (DST) for accurate timekeeping.
3. **Display Dimmer:** Use the dedicated "Display Dimmer" slider or button (refer to product diagram) to adjust the brightness of the digital time display from 0% to 100% according to your preference.

## Keep Accurate Time Auto Sync with DST



Image: The ANJANK device showing the digital time display at various brightness levels, from 0% to 100% dimming.

## OPERATING INSTRUCTIONS

### Sound Machine Function

The device offers 21 soothing sounds across various categories to help you relax and sleep.

- **Selecting Sounds:** Press the "Music Note" button to cycle through the available sounds. The display will show a code (e.g., E01, E02) corresponding to the sound.
- **Sound Categories:**
  - 5 White Noise sounds
  - 3 Fan sounds
  - 13 Nature sounds (e.g., sea waves, music box, rain, thunderstorm, bird chirping, wind)
- **Adjusting Volume:** Use the "Volume Up" (+) and "Volume Down" (-) buttons to set the desired sound level (30 levels available).
- **Sleep Timer:** Press the "Timer" button (hourglass icon) to set an auto-off timer for 1 hour, 2 hours, 3 hours, or 4 hours. The device will automatically turn off after the selected duration.

### 0-100% Display Dimmer

Display numbers can be dimmed or brightened to your preference



Image: Visual representation of the 21 soothing sounds available, categorized into white noise, fan sounds, and nature sounds.

Your browser does not support the video tag.

Video: A review demonstrating the ANJANK 4-in-1 White Noise Sound Machine, including sound selection and features.

### Alarm Clock Function

Set alarms to wake up gently with nature sounds or traditional beeps.

- **Setting Alarm:**
  - Press and hold the "Alarm Set" button (bell icon) until the hour digits flash.

- Use the "+" or "-" buttons to adjust the hour.
- Press "Alarm Set" again to switch to minute adjustment, then use "+" or "-" to set the minutes.
- Press "Alarm Set" once more to confirm.

- **Wake-up Sounds:** Choose from 8 delightful wake-up sounds including beep, piano, bird chirp, sea wave, stream, music box, yoga, and meditation. The night light automatically turns on when the alarm rings.
- **Snooze Function:** Press the "Snooze/Light" button when the alarm sounds to activate snooze.
- **Turning Off Alarm:** Press any button other than "Snooze/Light" to turn off the alarm for the day.



Image: The digital alarm clock displaying various wake-up sound options like beep, piano, bird chirp, and more.

## Bluetooth Speaker Function

Enjoy your favorite music or podcasts through the built-in Bluetooth speaker.

- **Pairing:** Press the "BT" button to enter Bluetooth pairing mode. The device will appear as "ANJANK" on your smartphone or tablet's Bluetooth device list. Select it to connect.
- **Playback:** Use the "Play/Pause" button to control media playback. Use the "Previous" and "Next" buttons to skip tracks.
- **Volume:** Adjust volume using the "+" and "-" buttons.



Image: The ANJANK device next to a smartphone, illustrating Bluetooth 5.0 connectivity for crystal clear stereo sound.

## Night Light Function

Add ambiance to your space with customizable night light colors and brightness.

- **Turning On/Off:** Press the "Snooze/Light" button to turn the night light on or off.
- **Changing Colors:** Continue pressing the "Snooze/Light" button to cycle through 7 available colors: red, orange, yellow, green, cyan, blue, and purple.
- **Adjusting Brightness:** Use the dedicated "Light Dimmer" control (refer to product diagram) to adjust the night light brightness from 10% to 100%.



Image: The ANJANK device showcasing its 7 vibrant night light colors, creating different moods.

## MAINTENANCE

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the device in a cool, dry place when not in use for extended periods.

## TROUBLESHOOTING

Problem	Solution

Problem	Solution
Device does not power on.	Ensure the power adapter is securely connected to the device and a working power outlet.
Bluetooth not connecting.	Make sure the device is in Bluetooth pairing mode (BT icon flashing). Check your phone's Bluetooth settings and try re-pairing. Ensure no other device is currently connected.
Alarm not sounding.	Verify the alarm is set correctly and the alarm icon is visible on the display. Check the alarm volume level.
Display is too bright/dim.	Adjust the "Display Dimmer" control on the device.

## PRODUCT SPECIFICATIONS

- **Model:** B0D8BCSQTH
- **Brand:** ANJANK
- **Color:** Pink
- **Material:** Metal, Plastic
- **Power Source:** Battery Powered (with power adapter for continuous use)
- **Package Dimensions:** 5.71 x 5.31 x 3.23 inches
- **Item Weight:** 1.23 pounds
- **Sound Options:** 21 soothing sounds (5 white noise, 3 fan, 13 nature)
- **Alarm Sounds:** 8 wake-up sounds
- **Night Light Colors:** 7 colors (red, orange, yellow, green, cyan, blue, purple)
- **Display Dimmer:** 0-100% adjustable
- **Night Light Brightness:** 10-100% adjustable
- **Sleep Timer:** 1h/2h/3h/4h options
- **Bluetooth:** 5.0 with Hi-Fi Stereo Sound (10W dual speakers)

## WARRANTY & SUPPORT

For warranty information, setup guides, or any further assistance, please refer to the product manual included in your package or contact ANJANK customer support. Keep your purchase receipt for warranty claims.

**Return Policy:** 30-day refund/replacement policy applies as per purchase terms.