



Manuals.plus /

› KOKEBREN /

› KOKEBREN 120Lbs/24H Commercial Ice Maker Machine User Manual

KOKEBREN 120Lbs/24H

KOKEBREN 120Lbs/24H Commercial Ice Maker Machine User Manual

Model: 120Lbs/24H

1. INTRODUCTION

Thank you for choosing the KOKEBREN 120Lbs/24H Commercial Ice Maker Machine. This appliance is designed to produce clear ice cubes efficiently for various commercial and home settings. Please read this manual thoroughly before installation, operation, and maintenance to ensure safe and optimal performance.

2. IMPORTANT SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or injury, follow these basic precautions:

- Read all instructions before using the appliance.
- Ensure the appliance is properly grounded.
- Do not operate the appliance with a damaged cord or plug.
- Keep ventilation openings clear of obstructions.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Only connect to a potable water supply.
- Allow the unit to stand upright for at least 24 hours before initial use.

3. PACKAGE CONTENTS

Verify that all items are included in the package:

- 1 x KOKEBREN Commercial Ice Maker Machine
- 1 x Drain Hose & Adapter

- 1 x Water Filter
- 1 x Ice Scoop
- 1 x Instruction Manual



Figure 3.1: KOKEBREN Ice Maker Machine and Included Accessories.

4. SETUP AND INSTALLATION

4.1 Unpacking and Placement

1. Carefully remove all packaging materials.
2. Place the ice maker on a flat, stable surface. Ensure adequate ventilation around the unit.
3. Allow the unit to stand upright for at least 24 hours before plugging it in. This allows the refrigerant to settle.

4.2 Water Inlet Connection

The KOKEBREN ice maker supports two water inlet modes: direct tap water connection or top-loading with a gallon water bottle.



Figure 4.1: Dual Water Inlet Modes.

4.2.1 Tap Water Connection

1. Connect the provided water filter to your tap water supply line.
2. Attach the water inlet hose from the filter to the designated inlet port on the back of the ice maker.
3. Ensure all connections are secure to prevent leaks.

4.2.2 Top-Loading Water Bottle

1. Place a standard gallon water bottle onto the top-loading dispenser.
2. The machine will automatically draw water as needed.

4.3 Drain Hose Connection

Connect the drain hose to the drain outlet on the ice maker and direct it to a suitable drain or container. Ensure the hose has a downward slope for proper drainage.

4.4 Initial Cleaning

Before first use, it is recommended to run the automatic cleaning function twice to ensure the internal components are clean.

5. OPERATION

5.1 Control Panel Overview

The ice maker features an LED digital display and mechanical buttons for precise control.

Advanced LCD Panel for Smart Operation

Automatic Control Panel is Easy-to-use



Figure 5.1: Control Panel Functions.

- **POWER Indicator:** Illuminates when the compressor is running.
- **ICE FULL Indicator:** Illuminates when the ice storage bin is full.
- **ICE MAKING Indicator:** Illuminates during the ice production cycle.
- **TIMER/CLEAN Indicator:** Illuminates when the timer function is active or during cleaning.
- **ON/OFF Button:** Powers the unit on or off.
- **TIMER Button:** Activates the reservation/timer function.
- **CLEAN Button:** Initiates the automatic cleaning cycle.
- **UP/DOWN Arrows:** Adjust ice-making time (ice thickness) or timer settings.

5.2 Ice Production

1. Ensure the water supply is connected and the unit is plugged in.
2. Press the **ON/OFF** button to start the ice maker.
3. The unit will begin its ice-making cycle, producing 60 clear ice cubes in approximately 8-15 minutes.
4. The **ICE FULL** indicator will illuminate when the storage bin reaches its capacity of 26 lbs.

5.3 Adjusting Ice Thickness

Use the **UP** and **DOWN** arrow buttons to adjust the ice-making time, which directly affects the thickness of the ice cubes.

- **Thin Ice (5-8 minutes):** Suitable for smoothies or seafood.
- **Medium Ice (8-11 minutes):** Ideal for beverages and cocktails.
- **Thick Ice (11-15 minutes):** Recommended for beer buckets or whiskeys.

Adjustable Ice Cube Thickness for Versatile Beverage/Food Needs

Thin (5-8mins)
Smoothies/Seafood
Medium

Medium (8-11mins)
Beverage/
Cocktail Thick

Thick (11-15mins)
Beer Bucket/
Whiskeys

Large Capacity: 24h Ice Yield can supply
1000-3000 drinks per day (according to 8pcs ice per cup) 0.9"x0.9"x0.9"

0.9"x0.9"x0.9"

Figure 5.2: Adjustable Ice Cube Thickness.

5.4 Timer Function

Press the **TIMER** button to set a reservation for the ice maker to start or stop at a specific time.

6. MAINTENANCE AND CLEANING

6.1 Automatic Cleaning

The ice maker features a one-touch automatic cleaning function. Press the **CLEAN** button to initiate this cycle. It is recommended to run this function regularly, especially after initial setup and before extended periods of non-use.

6.2 Manual Cleaning

1. Unplug the appliance from the power outlet.
2. Drain any remaining water from the reservoir.
3. Wipe down the interior and exterior surfaces with a soft cloth and mild detergent. Avoid abrasive cleaners.
4. Clean the ice scoop and storage bin with warm, soapy water.
5. Ensure all parts are dry before reassembling and operating the unit.

6.3 Water Filter Replacement

The included water filter helps ensure clean ice. Replace the filter periodically based on water quality and usage to maintain optimal performance.

7. TROUBLESHOOTING

If you encounter issues with your ice maker, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Ice maker not producing ice.	No water supply; power issue; low refrigerant.	Check water connection/bottle; ensure unit is plugged in; contact support if refrigerant is suspected.
Ice cubes are too small or soft.	Ice-making time too short; ambient temperature too high.	Increase ice-making time using the UP arrow; ensure proper ventilation.
Water leakage.	Loose hose connections; clogged drain.	Tighten all water and drain hose connections; clear any blockages in the drain.
Unit is noisy.	Unit not level; normal compressor operation.	Ensure unit is on a level surface; some noise from compressor is normal.

If the problem persists after attempting these solutions, please contact customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	KOKEBREN
Model Name	120Lbs/24H
Ice Production Capacity	Up to 120 lbs per 24 hours
Ice Storage Bin Capacity	26 lbs
Ice Cycle Time	8-15 minutes per cycle (60 cubes)
Product Dimensions (D x W x H)	17.72" x 19.69" x 32.28" (45 cm x 50 cm x 82 cm)
Weight	62.83 Pounds
Voltage	118V
Material	Stainless Steel
Water Inlet Modes	Tap water connection, Top-loading gallon water bottle



Ice Storage Bin & Stand Feet



Instruction Manual



Water Filter



Drain Hose & Adapter



Ice Scoop

Figure 8.1: Product Dimensions.

9. WARRANTY AND CUSTOMER SUPPORT

9.1 Warranty Information

This KOKEBREN ice maker machine comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package or contact KOKEBREN customer service for specific details regarding warranty coverage and duration.

9.2 Customer Support

For any questions, technical assistance, or service requests, please contact KOKEBREN customer support. Have your model number and purchase date ready when contacting support.

Contact information can typically be found on the manufacturer's website or on the warranty card.

