

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [AFEXOA](#) /

› [AFEXOA ZH083K Digital Sunrise Alarm Clock User Manual](#)

AFEXOA ZH083K

AFEXOA ZH083K Digital Sunrise Alarm Clock User Manual

Model: ZH083K

INTRODUCTION

Thank you for purchasing the AFEXOA ZH083K Digital Sunrise Alarm Clock. This device is designed to enhance your waking and sleeping experience with its natural sunrise simulation, customizable alarm sounds, multi-color night light, and sleep aid features. Please read this manual carefully to ensure proper use and optimal performance of your new alarm clock.

PACKAGE CONTENTS

- AFEXOA ZH083K Digital Sunrise Alarm Clock
- USB Power Cable
- User Manual

PRODUCT OVERVIEW

Familiarize yourself with the components and controls of your AFEXOA ZH083K alarm clock.



Image 1: Front view of the AFEXOA ZH083K Digital Sunrise Alarm Clock, showing the digital time display and control buttons on the top panel. The light dome is visible above the fabric-covered speaker base.

Control Buttons:

- **DIMMER:** Adjusts the brightness of the clock display.
- **TIME:** Used for setting the current time.
- **ALARM:** Used for setting and activating the alarm.
- **ALARM ON/OFF:** Toggles the alarm function.
- **SLEEP TIMER:** Activates and adjusts the sleep timer function.
- **+/-:** Adjusts values (time, brightness, volume) up or down.
- **Light Bulb Icon:** Controls the night light/mood light.
- **Snooze Button:** Located on the bottom, activated by pressing down the clock.

SETUP

1. Power Connection

Connect the provided USB power cable to the alarm clock and plug it into a suitable USB power adapter (not included) or a USB port. The clock display will illuminate.

2. Setting the Current Time

1. Press and hold the **TIME** button until the hour display starts flashing.
2. Use the +/- buttons to adjust the hour.
3. Press the **TIME** button again to confirm the hour and move to minute adjustment.
4. Use the +/- buttons to adjust the minutes.
5. Press the **TIME** button once more to save the time setting.

OPERATING INSTRUCTIONS

1. Setting the Alarm and Sunrise Simulation



Wake Gently with Sunrise Lights

Light & Ringtone or Light Only



Sunrise Duration Option: 10-60 mins

Image 2: Illustration of the sunrise simulation feature, showing the light gradually changing from dim red to bright yellow over a period, with time indications of 6:00, 6:30, and 7:00.

1. Press and hold the **ALARM** button until the alarm time display starts flashing.
2. Use the +/- buttons to set the desired alarm hour.
3. Press the **ALARM** button to confirm the hour and move to minute adjustment.
4. Use the +/- buttons to set the desired alarm minutes.
5. Press the **ALARM** button to confirm the minutes and proceed to sunrise duration setting.
6. Use the +/- buttons to select the sunrise simulation duration (10-60 minutes). This is the period before your set alarm time when the light will gradually brighten.
7. Press the **ALARM** button to confirm the duration and proceed to alarm sound selection.
8. Use the +/- buttons to cycle through the 7 available alarm sounds or select "OFF" for light-only alarm.
9. Press the **ALARM** button to confirm the sound and proceed to volume adjustment.
10. Use the +/- buttons to set the alarm volume (10 levels).
11. Press the **ALARM** button once more to save all alarm settings.

To activate or deactivate the alarm, press the **ALARM ON/OFF** button. An alarm icon will appear on the display when activated.



Image 3: A visual representation of the seven built-in wake-up ringtones, including icons for Beep, Bell, Birds, and four types of Soft Music. It also shows a 10-level volume adjustment bar.

2. Snooze Function

Practical Snooze Feature

Press down to snooze for 9 mins or control lights switch



Press to Snooze
Sunlight and
Sound stop



Snooze Time
9 Mins each time
(unlimited times)



Image 4: A hand pressing down on the top of the alarm clock to activate the snooze function. Text indicates that pressing down snoozes for 9 minutes and can also control the light switch.

When the alarm sounds, gently press down on the top of the alarm clock to activate the snooze function. The alarm will pause for 9 minutes and then sound again. This can be repeated an unlimited number of times.

3. Night Light / Mood Light

Gorgeous Night Lights

7 Solid Color Lights & 2 RGB Mood Lights
10 Levels of Brightness



Image 5: A display of the various solid color and RGB mood light options available on the alarm clock, shown as a spectrum of colors from light blue to purple, with the clock displaying each color.

1. Press the **Light Bulb Icon** button to turn on the night light.
2. Press the **Light Bulb Icon** button repeatedly to cycle through the 7 solid colors and 2 mixed RGB mood light options.
3. Use the +/- buttons to adjust the brightness of the selected light (10 levels).
4. Press and hold the **Light Bulb Icon** button to turn off the night light.

4. Sleep Timer

Sleep Aid with AUTO-OFF Timer



Image 6: An image illustrating the sleep aid function with an auto-off timer, showing options for 15m, 30m, 60m, 90m, and 120m. The alarm clock is shown emitting a soft, warm light.

The sleep timer allows the light to gradually dim and turn off after a set period, aiding in sleep.

1. Press the **SLEEP TIMER** button.
2. Use the +/- buttons to select the desired sleep timer duration (15, 30, 60, 90, or 120 minutes). The light will gradually dim and turn off after the selected time.
3. To cancel the sleep timer, press the **SLEEP TIMER** button repeatedly until the timer is off, or press and hold the button.

5. Display Brightness Adjustment

Dimmable Clock & Eye-caring

4 Level Display brightness Optional, including OFF



Image 7: Four images of the alarm clock demonstrating different display brightness levels, from off to full brightness, highlighting the dimmable and eye-caring features.

Press the **DIMMER** button to cycle through the 4 display brightness levels: 0% (off), 5%, 50%, and 100%. This allows you to adjust the display visibility according to your preference, especially at night.

MAINTENANCE

- Clean the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Keep the device away from water and high humidity.
- Avoid dropping the device or subjecting it to strong impacts.
- Do not attempt to disassemble or repair the device yourself. Contact customer support if issues arise.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Clock display is off or not working.	No power connection or power adapter issue. Display brightness set to 0%.	Ensure the USB cable is securely connected and the power adapter is working. Press the DIMMER button to increase display brightness.
Alarm does not sound.	Alarm not activated. Alarm volume set to 0 or sound option set to "OFF".	Press ALARM ON/OFF to activate. Check alarm settings to ensure a sound is selected and volume is not 0.
Sunrise simulation does not work.	Sunrise duration not set or set to 0.	Verify the sunrise duration is set to a value between 10-60 minutes in the alarm settings.
Night light is not turning on.	Light function not activated.	Press the Light Bulb Icon button to turn on the light.

SPECIFICATIONS

- Model:** ZH083K
- Brand:** AFEXOA
- Dimensions:** 9.5 x 3.81 x 9.5 cm
- Weight:** 400 g
- Material:** Plastic
- Display Type:** Digital
- Power Source:** Electric Cable (USB)
- Special Features:** Sunrise Simulation, Mood Light, Color-Changing Night Light, Loud Alarm, Snooze, Sleep Timer, Dimmable Display

WARRANTY AND SUPPORT

The AFEXOA ZH083K Digital Sunrise Alarm Clock comes with a standard manufacturer's warranty. For detailed warranty information, please refer to the product packaging or contact your retailer. If you encounter any issues or have questions regarding your product, please contact AFEXOA customer support through the retailer's platform or the official brand website for assistance.

Please retain your purchase receipt as proof of purchase for warranty claims.