

manuals.plus /

> [XMHEIRD](#) /

> [XMHEIRD AC Power Cord User Manual for Powermatic Cigarette Injectors](#)

XMHEIRD XSD-4000450HUSD20240910-0739

XMHEIRD AC Power Cord User Manual

Model: XSD-4000450HUSD20240910-0739

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your XMHEIRD AC Power Cord. This power cord is designed to provide reliable power to compatible devices, specifically Powermatic 2, II, 3, 3+, 2+, II+, III, III+, and PM-3 Cigarette Injectors. Please read this manual thoroughly before use and retain it for future reference.

The XMHEIRD AC Power Cord is engineered with safety and durability in mind, featuring high-quality materials and protective measures to ensure stable power delivery.




Figure 1: XMHEIRD AC Power Cord highlighting safety features such as high insulation, waterproofing, and abrasion resistance.

2. SAFETY INFORMATION

- Ensure the power cord is fully inserted into both the device and the wall outlet.
- Do not use the cord if it is damaged, frayed, or has exposed wires.
- Avoid placing heavy objects on the cord or bending it sharply.
- Keep the cord away from water, heat sources, and sharp edges.
- This AC adapter charger has passed FCC tests and features V-0 grade flame retardant, Over Voltage Protection (OVP), Over Current Protection (OCP), and Short Circuit Protection (SCP).

High Quality+ Safety Material

UL listed, safe&reliable. Made of 100% copper wire,
low resistance, low heat



Figure 2: Illustration of the cord's internal structure, showing 100% copper wire and a durable PVC jacket for high quality and safety.

3. SETUP

The XMHEIRD AC Power Cord is designed for straightforward connection. Follow these steps to set up your device:

1. **Identify the Power Port:** Locate the power input port on your compatible device (e.g., Powermatic Cigarette Injector). This cord features a non-polarized C7 connector.
2. **Connect to Device:** Insert the C7 (figure-8) connector end of the AC power cord firmly into the power input port of your device.
3. **Connect to Power Outlet:** Plug the two-prong (Type B) end of the AC power cord into a standard AC 100V-240V, 50/60Hz wall outlet.
4. **Verify Connection:** Ensure both ends of the cord are securely connected.

Non-Polarized Cable



Non-Polarized



Polarized



Figure 3: The non-polarized design of the C7 connector allows for easy insertion into compatible devices.

4. OPERATING INSTRUCTIONS

Once the XMHEIRD AC Power Cord is correctly connected to your device and a power outlet, your device should receive power. No special operation is required for the cord itself.

- Ensure the power cord is not kinked or obstructed during operation.
- The cord is designed for a steady circuit, preventing machine heat and ensuring heat-resistant performance.
- Always disconnect the power cord from the wall outlet before disconnecting it from the device, especially if the device has an on/off switch.

Connect to the HDTV

Steady Circuit, No Machine Heat & Heat-resistant Cable, More Safe for Using



Figure 4: Example of the AC power cord providing power to a device, ensuring a stable and safe connection.

5. MAINTENANCE

Proper maintenance ensures the longevity and safe operation of your AC power cord:

- **Cleaning:** Disconnect the cord from all power sources before cleaning. Wipe the cord with a dry, soft cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, coil the cord loosely. Avoid tight coiling or bending, which can damage the internal wires. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect the cord for any signs of wear, cuts, fraying, or damage to the plugs. If any damage is observed, discontinue use immediately and replace the cord.

6. TROUBLESHOOTING

If you encounter issues with your XMHEIRD AC Power Cord, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Device not powering on.	Cord not fully plugged in. Wall outlet is not active. Cord is damaged.	Ensure both ends of the cord are securely connected. Test the outlet with another device. Inspect the cord for damage; replace if necessary.
Intermittent power to device.	Loose connection. Internal cord damage.	Firmly re-seat both ends of the cord. Replace the cord if the issue persists after checking connections.
Cord feels warm during use.	Normal operation (slight warmth). Overload or faulty device.	Slight warmth is normal. If it's excessively hot, disconnect immediately and check device compatibility or for device malfunction.

If these steps do not resolve the issue, please contact customer support.

7. SPECIFICATIONS

- **Model Number:** XSD-4000450HUSD20240910-0739
- **Input:** AC100V-240V, 50/60Hz
- **Product Dimensions:** Approximately 24 x 12 x 0.2 inches
- **Item Weight:** Approximately 2.39 ounces
- **Color:** Black
- **Connector Gender:** Female-to-Female (C7 to Type B)
- **Plug Format:** Type B (US Standard)
- **Manufacturer:** ShenZhen Moveforest Electric Appliance Industry Co.,LTD
- **Safety Features:** FCC certified, V-0 grade flame retardant, OVP, OCP, SCP Protection
- **Compatible Devices:** Powermatic 2, II, 3, 3+, 2+, II+, III, III+, PM-3 Cigarette Injectors, and other devices requiring a non-polarized C7 power cord.

Universal Compatibility



Figure 5: The XMHEIRD AC power cord offers universal compatibility with various electronic devices that use a C7 connector.

8. WARRANTY AND SUPPORT

XMHEIRD is committed to providing high-quality products and customer satisfaction.

- **Warranty:** This product comes with a 12-month replacement exchange warranty from the date of purchase.
- **Returns:** We offer a 30-day hassle-free return policy.
- **Customer Support:** For any questions, concerns, or warranty claims, please contact XMHEIRD customer service through the retailer's platform where the product was purchased. Please have your order number and product model number ready.