

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Maxcom](#) /

> [Maxcom FW100 Valkiria Smartwatch User Manual](#)

## Maxcom FW100

# Maxcom FW100 Valkiria Smartwatch User Manual

Model: FW100

## INTRODUCTION

---

The Maxcom FW100 Valkiria smartwatch is designed for active individuals, offering a blend of style and functionality. This advanced timepiece provides features for health monitoring, fitness tracking, communication, and personal well-being. Please read this manual carefully to ensure proper use and maintenance of your device.

## PACKAGE CONTENTS

---

Verify that all items are present in your product package:

- Maxcom FW100 Valkiria Smartwatch
- Charging Cable
- User Manual (this document)

## SETUP

---

### 1. Charging the Device

Before first use, fully charge your smartwatch. Connect the charging cable to the charging port on the back of the watch and plug the USB end into a standard USB power adapter (not included) or a computer's USB port.



*Image: Side view of the Maxcom FW100 Valkiria smartwatch, highlighting the physical buttons and the area where charging contacts are typically located.*

## 2. Powering On/Off

- **To Power On:** Press and hold the Power button (usually the top right button) for a few seconds until the screen lights up.
- **To Power Off:** Press and hold the Power button, then select "Power Off" on the screen.

## 3. Pairing with Smartphone

1. Ensure your smartphone's Bluetooth is enabled.
2. Download and install the official Maxcom companion app from your smartphone's app store (e.g., Google Play Store or Apple App Store).
3. Open the app and follow the on-screen instructions to create an account or log in.
4. In the app, select "Add Device" or "Pair New Device" and choose "FW100 Valkiria" from the list of available devices.
5. Confirm the pairing request on both your smartphone and the smartwatch.

## OPERATING INSTRUCTIONS

### 1. Navigating the Interface

The FW100 Valkiria features a 1.3-inch AMOLED touchscreen and two physical buttons for navigation.

- **Touchscreen:** Swipe left/right, up/down to navigate through menus and widgets. Tap to select an option.
- **Power Button (Top Right):** Press to wake the screen, return to the watch face, or access the app list. Long press for power options.
- **Sport Button (Bottom Right):** Press to quickly access sports modes.



Image: The Maxcom FW100 Valkiria smartwatch showing a digital watch face with various health metrics like heart rate, steps, and calories burned.

## 2. Basic Functions

- **Time Display:** The watch face displays the current time, date, and other selected information.
- **Notifications:** Once paired, the watch will display notifications from your smartphone (calls, messages, app alerts). Swipe down from the watch face to view recent notifications.

## 3. Sports Modes

The smartwatch supports 70 sports modes. Press the Sport button to access the list of activities. Select your desired activity to start tracking. The watch also offers smart recognition for 6 basic disciplines.

## 4. Call Function

With the call function, you can make and receive calls directly from your smartwatch when it's connected to your smartphone via Bluetooth. Use the integrated microphone and speaker for hands-free communication.

## 5. Activity Tracking

The FW100 Valkiria continuously tracks your daily activity, including steps taken, distance covered, calories burned, and heart rate. View your progress on the watch or in the companion app.

## 6. Customizing Watch Faces

You can change the watch face to personalize your device. Long press on the current watch face, then swipe left or right to browse available options. More watch faces can be downloaded via the companion app.



Image: The Maxcom FW100 Valkiria smartwatch showing a classic analog watch face.

## WEARING THE WATCH

For accurate heart rate and activity tracking, wear the smartwatch snugly on your wrist, about one finger's width above your wrist bone. Ensure the sensor on the back of the watch is in contact with your skin.



*Image: A person wearing the Maxcom FW100 Valkiria smartwatch on their wrist, demonstrating proper fit.*

## **MAINTENANCE**

---

### **1. Cleaning**

- Wipe the watch screen and body with a soft, lint-free cloth.
- If necessary, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials.
- Clean the charging contacts regularly to ensure proper charging.

## 2. Battery Care

- Avoid fully discharging the battery frequently.
- Do not expose the device to extreme temperatures, as this can affect battery life.
- If storing the watch for an extended period, charge it to about 50% before storage.

## 3. Water Resistance

The Maxcom FW100 Valkiria smartwatch is designed with a certain level of water resistance. Refer to the specifications section for details. Avoid using the watch in hot water, saunas, or steam rooms, as this can compromise the water seals.

## TROUBLESHOOTING

- **Watch will not turn on:** Ensure the watch is fully charged. Connect it to the charging cable and try powering it on after a few minutes.
- **Cannot pair with smartphone:**
  - Ensure Bluetooth is enabled on your smartphone.
  - Make sure the watch is within range of your smartphone.
  - Restart both the watch and your smartphone.
  - Check if the companion app is updated to the latest version.
- **Inaccurate activity data:** Ensure the watch is worn snugly on your wrist, as described in the "Wearing the Watch" section. Clean the sensor on the back of the watch.
- **Notifications not appearing:** Check notification settings in the companion app and on your smartphone to ensure permissions are granted for the app to send notifications.

## SPECIFICATIONS

<b>Brand</b>	Maxcom
<b>Model Name</b>	FW100
<b>Screen Size</b>	1.3 Inches
<b>Display Type</b>	AMOLED
<b>Screen Protection</b>	Gorilla Glass 3
<b>Connectivity</b>	Bluetooth
<b>Special Features</b>	Activity tracking, Call function, 70 Sports modes, Smart recognition of 6 disciplines, Integrated GPS
<b>Compatible Devices</b>	Smartphone
<b>Battery Type</b>	Lithium-ion (1 included)
<b>Battery Life (Daily Use)</b>	Up to 12 days

<b>Battery Life (AOD Mode)</b>	Up to 3 days
<b>Shape</b>	Round

## SAFETY INFORMATION

---

- Do not attempt to disassemble or modify the device.
- Keep the device away from extreme heat sources and direct sunlight.
- Avoid exposing the device to strong magnetic fields.
- Consult a medical professional before starting any new exercise regimen, especially if you have pre-existing health conditions.
- This device is not a medical device and should not be used for diagnostic or treatment purposes.

## WARRANTY AND SUPPORT

---

For warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official Maxcom website. Keep your proof of purchase for warranty claims.