

EVVO V0323

EVVO CE26 Pyramid Cooker Hood User Manual

Model: V0323

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your EVVO CE26 Pyramid Cooker Hood. Please read this manual thoroughly before installation and use, and keep it for future reference.

The EVVO CE26 Pyramid cooker hood is designed to effectively remove smoke, odors, and steam from your kitchen, ensuring a clean and pleasant cooking environment. It features a powerful 650 m³/h extraction capacity, LED lighting, and a multi-layer filtration system.



Image 1: EVVO CE26 Pyramid Cooker Hood overview, highlighting its A-class energy efficiency, 90 cm width, and 650 m³/h extraction power.

2. SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Ensure the power supply matches the voltage specified on the rating plate.
- Installation must be performed by a qualified technician in accordance with local regulations.
- Do not operate the hood if the power cord is damaged.
- Maintain adequate ventilation in the room when the hood is used simultaneously with gas or other fuel-burning appliances.
- Clean the filters regularly to prevent grease accumulation, which can be a fire hazard.
- Do not flambé under the cooker hood.
- Keep children away from the appliance during operation.

3. PACKAGE CONTENTS

Verify that all components are present in the package:

- EVVO CE26 Pyramid Cooker Hood unit
- Aluminum grease filters (pre-installed)
- Active carbon filters (for recirculation mode, may be pre-installed or separate)
- Mounting hardware (screws, wall plugs, brackets)
- Instruction Manual (this document)

4. SETUP AND INSTALLATION

The EVVO CE26 Pyramid cooker hood is designed for wall-mounted installation. Proper installation is crucial for optimal performance and safety.

4.1. Planning and Preparation

- Choose a suitable location above your cooking surface, ensuring adequate clearance as per local building codes and manufacturer recommendations (typically 65-75 cm above electric hobs, 75-85 cm above gas hobs).
- Ensure the wall is strong enough to support the hood's weight (approximately 12 kg).
- Determine whether the hood will operate in extraction (ducted) or recirculation mode. For extraction, plan for ducting to the outside. For recirculation, ensure active carbon filters are installed.
- Ensure a power outlet is accessible within reach of the power cord.

4.2. Dimensions




Image 2: Dimensional drawing of the EVVO CE26 Pyramid Cooker Hood, indicating key measurements for installation.

4.3. Mounting Steps (General)

1. Mark the drilling points on the wall according to the provided template (if included) and the desired height.
2. Drill holes and insert wall plugs.
3. Secure the mounting bracket(s) to the wall.
4. Carefully lift the hood and hang it onto the mounting bracket(s).
5. Connect the ducting (if in extraction mode) or install the carbon filters (if in recirculation mode).
6. Install the chimney sections, ensuring they are properly aligned and secured.
7. Connect the hood to the electrical power supply.

For detailed, model-specific installation instructions, refer to the separate installation guide provided with your product or consult a qualified professional.

5. OPERATING INSTRUCTIONS

The EVVO CE26 Pyramid cooker hood features touch controls for easy operation.

5.1. Control Panel

The control panel is located on the front fascia of the hood and consists of touch buttons for various functions.



Image 3: The EVVO CE26 Pyramid Cooker Hood in a kitchen setting, showing the illuminated cooking area and the integrated touch controls.

5.2. Functions

- **Power On/Off:** Press the power button to turn the hood on or off.
- **Fan Speed Selection:** The hood offers three adjustable fan speeds. Press the speed buttons (usually indicated by 1, 2, 3 or +/- symbols) to select the desired extraction level.
 - Speed 1: For light cooking, simmering.
 - Speed 2: For normal cooking, moderate steam and odors.
 - Speed 3: For intensive cooking, frying, or strong odors.
- **LED Lighting:** Press the light button to turn the integrated LED lights on or off, providing illumination for your cooking area.



Image 4: Detail of the hood, highlighting its smoke-free operation due to its powerful extraction system.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your cooker hood.

6.1. Cleaning the Exterior

- Wipe the stainless steel surfaces with a soft cloth dampened with mild detergent.
- Do not use abrasive cleaners, corrosive detergents, or metal brushes, as these can damage the finish.
- Dry thoroughly after cleaning to prevent water spots.



Image 5: The hood's stainless steel construction, emphasizing its durability and aesthetic appeal.

6.2. Cleaning/Replacing Filters

Aluminum Grease Filters: These filters capture grease particles. They should be cleaned regularly (every 2-4 weeks, depending on usage) to maintain extraction efficiency.

- To remove: Locate the release latches on each filter, push, and pull down.
- To clean: Wash by hand in hot soapy water or in a dishwasher on a low-temperature cycle. Ensure they are completely dry before re-installing.
- To re-install: Insert the filters back into their slots and push until the latches click into place.

Active Carbon Filters (for recirculation mode): These filters absorb odors. They cannot be washed and

must be replaced periodically (typically every 3-6 months, depending on usage).

- To replace: Remove the aluminum grease filters. Twist or unclip the old carbon filters from the motor housing. Install new carbon filters by reversing the process.
- Replacement carbon filters can be purchased from authorized dealers.

6.3. LED Light Replacement

The hood is equipped with long-lasting LED lights. If a light needs replacement, contact a qualified service technician. Do not attempt to replace the LED modules yourself.

For information on recycling light bulbs, please refer to local recycling guidelines.

7. TROUBLESHOOTING

Before contacting customer service, refer to the following table for common issues and their solutions.

Problem	Possible Cause	Solution
Hood does not operate.	No power supply.	Check if the power plug is correctly inserted and the circuit breaker is on.
Low extraction efficiency.	Grease filters are clogged. Carbon filters are saturated (recirculation mode). Insufficient room ventilation.	Clean the aluminum grease filters. Replace the active carbon filters. Ensure windows or doors are slightly open for air intake.
Lights not working.	Faulty LED module.	Contact a qualified service technician for replacement.
Excessive noise.	Improper installation. Obstruction in the fan. Loose components.	Check installation for secure mounting. Inspect fan for foreign objects (ensure power is off). Tighten any loose screws.

8. SPECIFICATIONS

Feature	Detail
Model Number	V0323
Brand	EVVO
Type	Pyramid Wall-Mounted Cooker Hood
Material	Stainless Steel
Color	Inox (Stainless Steel)
Dimensions (W x D x H)	90 cm x 50 cm x 95.1 cm (adjustable height)
Weight	12 kg
Airflow Capacity	650 m ³ /h

Feature	Detail
Motor Power	165 W
Noise Level	69 dB
Energy Efficiency Class	A
Lighting Type	LED (2 x 1.5 W)
Control Type	Touch Buttons
Fan Speeds	3
Filter Type	5-layer Aluminum Mesh, Active Carbon
Ventilation Type	Ducted / Recirculation
Voltage	120 V
Country of Origin	China



Image 6: Energy efficiency rating 'A' of the EVVO CE26 Pyramid Cooker Hood.

9. WARRANTY AND SUPPORT

Your EVVO CE26 Pyramid Cooker Hood is covered by a manufacturer's warranty. For specific details regarding warranty terms, duration, and claims, please refer to the warranty card included with your product or contact EVVO customer support.

Returns Policy: If you wish to return a product within 30 days of receipt because you have changed your mind, please consult the retailer's return policy. If you have received a defective or damaged product, please consult the retailer's help page on returns for defective or damaged items.

Spare Parts Availability: Spare parts for this product are available for a period of 10 years within the EU. For technical assistance, spare parts, or any other inquiries, please contact EVVO customer support through their official website or the contact information provided in your product documentation.

© 2024 EVVO. All rights reserved.

This manual is for informational purposes only. EVVO reserves the right to make changes to the product without prior notice.