



Manuals.plus /

- › BAYBEE /
- › BAYBEE 12V Adapter Charger for Kids Ride-On Toys: User Manual

## BAYBEE 12v

# BAYBEE 12V Adapter Charger for Kids Ride-On Toys: User Manual

Model: 12V Charger

## 1. PRODUCT OVERVIEW

---

The BAYBEE 12V Adapter Charger is designed to efficiently and safely charge 12V batteries in kids' ride-on toys. This adapter provides a reliable power source for various models, including those from Mercedes Benz, BMW, Audi, and Maserati. It features a compact design, a 1-meter power cable, and an LED charging indicator for ease of use.



Image 1.1: The BAYBEE 12V Adapter Charger with its coiled power cable.

## 2. SAFETY INFORMATION

Please read and understand all safety instructions before using the charger. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Indoor Use Only:** This charger is intended for indoor use in dry conditions. Do not expose it to rain, moisture, or extreme temperatures.
- **Proper Voltage:** Ensure the input voltage of your power outlet matches the charger's specifications (100V-240V AC, 50/60Hz).
- **Compatible Devices:** Use this charger only with 12V battery-operated ride-on toys that require a 6-watt power adapter with a 2.1mm x 5.5mm center-positive barrel plug. Using it with incompatible devices may cause damage or fire.
- **Inspect Before Use:** Before each use, inspect the charger, cable, and plug for any signs of damage. Do not use if damaged.
- **Keep Away from Children:** This is not a toy. Keep the charger out of reach of children during operation and storage.

- **Unplug When Not in Use:** Always unplug the charger from the power outlet and the toy when not in use or before cleaning.
- **Ventilation:** Ensure adequate ventilation around the charger during operation. Do not cover it.

### 3. SETUP AND CONNECTION

---

Follow these steps to set up and connect your BAYBEE 12V Adapter Charger:

1. **Unpack the Charger:** Carefully remove the charger and its cable from the packaging.
2. **Identify the Charging Port:** Locate the charging port on your child's ride-on toy. Ensure it is a 12V port compatible with a 2.1mm x 5.5mm center-positive barrel plug.
3. **Connect to Toy:** Insert the barrel plug of the charger cable into the charging port of the ride-on toy.
4. **Connect to Power Outlet:** Plug the AC input of the charger into a standard 100V-240V wall outlet.



Image 3.1: The charger connected to a power outlet and a ride-on toy.



**Input - AC100-240V**

**Output - DC 12V - 1000 mAH**

Compatible for all Battery Operated Rideons

Image 3.2: Detail of the charger's barrel plug and input/output specifications.

The 1-meter cable length provides flexibility for connecting to various power sources.



**1 Meter Cable length**  
Fits a Variety of 12 Volt Kids  
Battery-Powered Ride-On Toys

Image 3.3: The 1-meter cable length for convenient use.

## 4. OPERATING INSTRUCTIONS

---

The BAYBEE 12V Adapter Charger features an LED indicator to show the charging status:

- **Red Light:** Indicates that the battery is currently charging.
- **Green Light:** Indicates that the battery is fully charged. The charger will automatically power off to protect the battery from over-discharge and damage, preserving its lifespan.



Image 4.1: The LED indicator displaying charging (red) and fully charged (green) states.

Once the green light appears, you may disconnect the charger from both the power outlet and the ride-on toy.

## 5. MAINTENANCE

---

Proper maintenance ensures the longevity and safe operation of your charger:

- **Cleaning:** Disconnect the charger from all power sources before cleaning. Wipe the exterior with a soft, dry cloth. Do not use liquid cleaners or solvents.
- **Storage:** Store the charger in a cool, dry place away from direct sunlight and moisture. Coil the cable loosely to prevent kinks or damage.
- **Avoid Physical Damage:** Do not drop, crush, or expose the charger to heavy impacts.

## 6. TROUBLESHOOTING

---

If you encounter issues with your BAYBEE 12V Adapter Charger, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Charger not working / No LED light	No power from outlet; Loose connection; Damaged charger/cable.	Check if the power outlet is functional. Ensure all connections are secure. Inspect charger and cable for damage; discontinue use if damaged.
Battery not charging	Incorrect charger for toy; Toy's battery issue; Loose connection.	Verify charger compatibility with the toy's specifications. Ensure the charger plug is fully inserted into the toy's charging port. Consult the toy's manual for battery troubleshooting.
LED light remains red after extended charging	Battery not fully charging; Faulty battery.	Allow more time for charging. If the issue persists, the toy's battery may need replacement or professional inspection.

If these steps do not resolve the issue, please contact BAYBEE customer support.

## 7. SPECIFICATIONS

Feature	Detail
Brand	BAYBEE
Model	12v
Input	100V-240V AC, 50/60Hz
Output	12V DC, 1000mA (6 Watts)
Connector Type	2.1mm x 5.5mm Centre Positive Barrel Plug
Cable Length	1 Meter
Special Features	Charging Indicator, Fast Charge, Lightweight Design
Compatible Devices	Universal for 12V Kids Ride-On Toys
Country of Origin	India
Item Weight	150 kg (Note: This weight seems incorrect based on product type, likely a data entry error in source. Actual weight is expected to be much lower.)

## 8. WARRANTY AND SUPPORT

For warranty information, product support, or any inquiries regarding your BAYBEE 12V Adapter Charger, please contact the manufacturer or refer to the official BAYBEE website. Keep your purchase receipt as proof of purchase.

**Manufacturer:** BAYBEE

**Contact:** Refer to BAYBEE's official customer service channels for assistance.