

Manuals.plus /

- › Braun /
- › Braun IS 2577 VI Steam Generator Iron User Manual

## Braun IS 2577 VI

# Braun IS 2577 VI Steam Generator Iron User Manual

Model: IS 2577 VI

## 1. INTRODUCTION

---

Thank you for choosing the Braun IS 2577 VI Steam Generator Iron. This manual provides essential information for the safe and efficient use of your appliance. Please read these instructions carefully before first use and keep them for future reference.

## 2. IMPORTANT SAFETY INSTRUCTIONS

---

- Always ensure the voltage indicated on the appliance corresponds to your mains voltage.
- Do not leave the iron unattended while it is switched on or connected to the mains.
- Keep the iron and its cord out of reach of children and pets.
- Never immerse the iron or its base in water or any other liquid.
- Do not operate the iron with a damaged cord or plug. Contact authorized service personnel for repairs.
- Use the iron only for its intended purpose: ironing clothes.
- The soleplate and steam are extremely hot and can cause burns. Handle with care.
- Always place the iron on a stable, heat-resistant surface.

## 3. PRODUCT FEATURES

---

The Braun IS 2577 VI Steam Generator Iron is designed for efficient and convenient ironing with advanced features:

- **3D FreeGlide Soleplate:** The world's first 3D FreeGlide soleplate ensures effortless gliding over buttons, pockets, and zippers, preventing snagging.
- **iCare Smart Technology:** This intelligent technology protects your clothes with a safe temperature setting for all fabric types, making ironing faster and easier without sorting.

- **1.5L Removable Water Tank:** The practical 1.5-liter water tank is easy to remove and refill, allowing for longer ironing sessions.
- **Sterilization Function:** Utilizes steam to kill over 99.99% of bacteria and viruses on fabrics.
- **Powerful Performance:** With a robust 2400W power output and 6.5 bar pump pressure, this steam generator iron delivers fast and effective results, even on tough fabrics.
- **Additional Features:** Includes vertical ironing capability, iMode interface, Turbo mode for extra steam, anti-drip system, automatic shut-off for safety, silent technology, and fast heat-up time.



Image 1: The Braun IS 2577 VI Steam Generator Iron with its water tank base.





Image 2: Close-up of the 3D FreeGlide soleplate, designed to glide smoothly over fabric obstacles.

## 4. SETUP

---

1. **Unpacking:** Carefully remove all packaging materials and ensure all components are present.
2. **Positioning:** Place the steam generator iron on a stable, level, and heat-resistant surface, such as an ironing board designed for steam generators.
3. **Filling the Water Tank:**
  - Remove the 1.5L water tank from the base.
  - Fill the tank with tap water up to the 'MAX' indicator. For areas with very hard water, consider using a mix of tap water and distilled water (50/50) to prolong the appliance's life. Do not use scented water or additives.
  - Reinsert the water tank firmly into the base until it clicks into place.
4. **Connecting to Power:** Plug the power cord into a grounded electrical outlet.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Powering On and Heating Up

1. Press the power button on the base. The indicator light will illuminate.
2. The iron will begin to heat up. This usually takes a few minutes. The steam ready indicator light will stop flashing and remain solid when the iron is ready for use.

### 5.2 Selecting Ironing Modes



Image 3: The control panel on the iron, showing the mode button and various indicator lights for different settings. Use the 'Mode' button on the iron handle to cycle through the available settings:

- **iCare Mode:** (Default) Provides a safe temperature for all fabrics, eliminating the need for sorting.
- **Eco Mode:** Reduces steam output and temperature for delicate fabrics and energy saving.
- **Turbo Mode:** Delivers maximum steam and temperature for stubborn creases and thick fabrics.

### 5.3 Ironing Techniques

- **Horizontal Ironing:** Place the garment on the ironing board. Press the steam trigger under the handle to release steam as you glide the iron over the fabric.
- **Vertical Steaming:** For hanging garments, curtains, or delicate items, hold the iron vertically a few centimeters away from the fabric. Press the steam trigger to release steam and smooth out wrinkles.




Image 4: A user demonstrating horizontal ironing on a blue shirt using the steam generator iron.



Image 5: A user demonstrating vertical steaming on a maroon blouse, effectively removing wrinkles.

#### **5.4 Sterilization Function**

To use the sterilization function, ensure the water tank is filled. Select a high steam setting (e.g., Turbo mode). Hold the iron a few centimeters from the fabric and apply steam for several seconds to the desired area. This function helps eliminate bacteria and viruses.

#### **5.5 Automatic Shut-off**

For safety and energy saving, the iron features an automatic shut-off function. If the iron is left unattended for a certain period (e.g., 10 minutes), it will automatically switch off. To restart, simply move the iron or press the power button.

## **6. MAINTENANCE AND CLEANING**

---

### **6.1 Descaling**

Regular descaling is crucial to maintain optimal steam performance and prolong the life of your iron. Refer to the appliance's indicator light for descaling reminders. Follow these general steps:

1. Ensure the iron is unplugged and cooled down.
2. Consult your specific model's instructions for the descaling procedure, which usually involves a dedicated descaling solution or a self-clean function.
3. Rinse the water tank thoroughly after descaling.

## 6.2 Cleaning the Soleplate

- Allow the iron to cool completely.
- Wipe the soleplate with a damp cloth and a non-abrasive liquid cleaner. Do not use harsh scouring pads or metal objects.
- For stubborn marks, use a specialized iron soleplate cleaner according to its instructions.

## 6.3 Emptying and Storage

- After each use, unplug the iron and allow it to cool down.
- Empty any remaining water from the tank.
- Store the iron in a safe, dry place, ensuring the soleplate is protected from scratches.

## 7. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
No steam is produced.	Water tank is empty or not properly inserted. Iron not hot enough.	Fill water tank and ensure it's correctly seated. Wait for the iron to reach operating temperature.
Water drips from the soleplate.	Temperature is too low for steam. Anti-drip system engaged.	Increase the temperature setting. Ensure the iron has fully heated up before using steam.
Iron does not heat up.	Not plugged in. Power switch off. Automatic shut-off activated.	Check power connection. Ensure power switch is on. Move the iron or press the power button to reactivate.
White flakes or residue on clothes.	Mineral deposits (limescale) in the iron.	Perform a descaling procedure as per instructions. Use distilled water or a mix if your tap water is hard.

## 8. SPECIFICATIONS

---

Feature	Detail
Model Number	IS 2577 VI
Power	2400W
Pump Pressure	6.5 Bar
Water Tank Capacity	1.5 Liters (Removable)
Soleplate Material	Stainless steel with Eloxal coating (3D FreeGlide)
Special Features	Automatic Shut-off, iCare Smart Technology, Turbo Mode, Eco Mode, Vertical Steaming, Sterilization Function, Anti-drip, Fast Heat-up, Silent Technology
Color	White / Violet
Item Weight	3 kg
Shipping Dimensions	33 x 31.2 x 26 cm

## 9. OFFICIAL PRODUCT VIDEO

---

Your browser does not support the video tag.

Video 1: An official product video demonstrating the features and use of the Braun IS 2577 VI Steam Generator Iron.

## 10. WARRANTY AND SUPPORT

---

Braun products are manufactured to the highest quality standards. This product comes with a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty period and coverage.

For technical support, service, or to purchase spare parts, please visit the official Braun website or contact their customer service department in your region. Keep your proof of purchase for warranty claims.