

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Eueiriup](#) /

› [Electric Wall Heater User Manual](#)

Eueiriup HKWH003-800W

Electric Wall Heater User Manual

Brand: Eueiriup | Model: HKWH003-800W

1. INTRODUCTION

This manual provides detailed instructions for the safe and efficient operation, installation, and maintenance of your Eueiriup Electric Wall Heater. Please read this manual thoroughly before using the appliance and retain it for future reference.



Image: Eueiriup Electric Wall Heater, showcasing its sleek design and wall-mounted setup.

2. IMPORTANT SAFETY INFORMATION

To reduce the risk of fire, electric shock, or injury, basic safety precautions should always be followed. This heater is designed with several safety features:

- **Anti-Tip Protection:** The heater automatically shuts off if it is accidentally knocked over.
- **Overheat Protection:** The heater will power down if it detects an internal temperature that is too high, preventing damage and fire hazards.
- **IPX4 Waterproof Rating:** Provides protection against splashing water from any direction, making it suitable for indoor use in various environments.
- **V0 Flame Retardant Material:** Constructed with materials that meet V0 flame retardancy standards for enhanced safety.
- **Child Lock:** Prevents unintended changes to settings by children.

ENJOY HEATER WITHOUT SAFE CONCERN



Image: Visual representation of the heater's safety features: Child Lock, Tip-over Protection, and Overheat Protection.

3. SETUP AND INSTALLATION

Your Eueiriup Electric Wall Heater offers versatile installation options: freestanding with wheels or wall-mounted.

3.1 Freestanding Installation


Attach the included universal wheels to the base of the heater. The concealed handles allow for easy portability between rooms. This option provides flexibility for heating different areas of your home.

3.2 Wall-Mount Installation

Use the provided mounting accessories to securely attach the heater to a wall. Ensure the wall is suitable for supporting the heater's weight and that there is adequate clearance around the unit for proper air circulation. Refer to the detailed mounting template included in the packaging for precise measurements and drilling instructions.



Image: The heater displayed in both freestanding and wall-mounted configurations, with approximate dimensions (22.44"H x 18.11"W x 3.54"D).



 Convenient storage



 Universal Wheel



 Hidden Handle

Image: Detailed view of the heater's features including universal wheels for mobility, a hidden handle for easy carrying, and integrated storage for the power cord.

4. OPERATING INSTRUCTIONS

The heater features an intuitive LED control panel for precise temperature management and mode selection.

4.1 Control Panel Overview

The LED display shows the current temperature and settings. Buttons allow for various adjustments:

- **Decrease Button (<):** Lowers temperature or setting.
- **OK Button:** Confirms selection.
- **Increase Button (>):** Raises temperature or setting.
- **Heat Indicator (SSS):** Illuminates when heating element is active.
- **Mute Switch:** Toggles sound notifications.
- **Timer Setting:** Activates and adjusts the 24-hour timer.
- **Turn On/Off:** Powers the unit on or off.

- **Menu Button:** Accesses additional settings.
- **Child Lock:** Locks the control panel to prevent accidental changes.
- **Temperature Conversion:** Switches between Fahrenheit and Celsius.

4.2 Operating Modes

The heater offers three distinct operating modes:

- **Comfort Mode:** Provides consistent heating to maintain your desired temperature.
- **Economic Mode (ECO):** Optimizes heating for energy saving. The set temperature in this mode cannot exceed the temperature set in Comfort Mode.
- **Thaw Mode (Low Mode):** Maintains a low temperature to prevent freezing, suitable for garages or basements.

Temperature can be adjusted between 45°F and 86°F (7°C and 30°C) in heating and eco modes.



Image: Close-up of the heater's LED display and control buttons, illustrating temperature regulation (45-86°F) and the three operating modes: Comfort, Economic, and Thaw.

5. KEY FEATURES

The Eueiriup Electric Wall Heater is designed for optimal performance and user convenience.

- **Energy Efficient:** This aluminum radiator heater can significantly reduce heating costs by supplementing or replacing your main heating system. It heats quickly, reaching desired temperatures in less than 60 seconds.
- **Quiet Operation:** Featuring a fan-less, oil-less, and gas-less design, the heater operates silently without disturbing noise. This design also prevents air dryness, reducing issues like winter nosebleeds and dry eyes, creating a healthier environment.
- **Efficient Convection Heating:** The heater continuously monitors room temperature, activating to maintain the set temperature. Heat is rapidly transferred to the entire aluminum frame, circulating warm air throughout the room for comprehensive warming.
- **Durable Construction:** Made entirely of aluminum, this heater is non-liquid and does not use an air blower, contributing to its longevity and quiet performance.



Image: Diagram highlighting the heater's efficient and quiet operation, emphasizing low noise, energy efficiency, and fast heating capabilities.

WHOLE ROOM CONVECTION WARMING



Image: Visual representation of how the heater provides whole room convection warming, distributing heat evenly throughout the space.

Our



All Aluminum



Non-Liquid



Non-Air Blower

Other



Non Aluminum



Containing Liquid



Contains Fan

Image: A comparison chart illustrating the advantages of the Eueiriup heater's construction: All Aluminum, Non-Liquid, and Non-Air Blower, contrasting it with typical heaters.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your heater.

- **Cleaning:** Ensure the heater is unplugged and completely cool before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
- **Storage:** If storing the heater for an extended period, ensure it is clean and dry. Store it in a cool, dry place, preferably in its original packaging.
- **Inspection:** Periodically check the power cord and plug for any signs of damage. If damage is found, do not use the heater and contact customer support.

7. TROUBLESHOOTING

If you encounter issues with your heater, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Heater does not turn on.	No power supply; Power switch off; Overheat protection activated; Tip-over switch activated.	Check power outlet and plug connection; Ensure power switch is ON; Allow heater to cool down; Place heater on a flat, stable surface.
Heater not heating effectively.	Temperature setting too low; Room size too large for heater capacity; Obstruction of air circulation.	Increase temperature setting; Ensure heater is appropriate for room size; Remove any obstructions around the heater.
LED display is not working.	Power issue; Internal fault.	Check power supply; If problem persists, contact customer support.
Child lock is active.	Child lock feature engaged.	Refer to operating instructions to deactivate child lock.

8. SPECIFICATIONS

Feature	Detail
Brand	Eueiriup
Model Number	HKWH003-800W
Special Feature	Portable, Fast Heating, Wheels
Color	White
Form Factor	Compact
Indoor/Outdoor Usage	Indoor
Product Dimensions	3"D x 13"W x 21"H
Recommended Uses For Product	Office, Living Room, Bedroom, Home Office
Mounting Type	Freestanding/ Wall Heater
Burner type	Radiant
Fuel Type	Electric
Voltage	120 Volts (AC)
Item Weight	22.9 pounds
Manufacturer	Eueiriup
ASIN	B0DBYXB3B5
Country of Origin	China
Date First Available	August 2, 2024

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact Eueiriup customer service directly. Keep your purchase receipt for warranty claims.