

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [ZOMBIES CAT](#) /

› Wireless Earbuds TF-T27 User Manual

ZOMBIES CAT TF-T27

Wireless Earbuds TF-T27 User Manual

Comprehensive guide for your ZOMBIES CAT TF-T27 Wireless Earbuds.

[Introduction](#)

[What's in the Box](#)

[Product Overview](#)

[Setup](#)

[Operating](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing the ZOMBIES CAT TF-T27 Wireless Earbuds. These earbuds are designed to provide a superior audio experience with advanced features such as Active Noise Cancelling (ANC), Environmental Noise Cancelling (ENC) for calls, and an extended 60-hour playback time. This manual will guide you through the setup, operation, and maintenance of your new earbuds to ensure optimal performance and longevity.

2. WHAT'S IN THE BOX

Smart Touch Control

Music incoming calls can be controlled at any time



Image: The product packaging, showing the earbuds, charging case, USB-C charging cable, and user manual.

- ZOMBIES CAT TF-T27 Wireless Earbuds (Left and Right)
- Wireless Charging Case
- USB-C Charging Cable
- User Manual
- Eartips (various sizes: S, M, L)

3. PRODUCT OVERVIEW

3.1 Earbuds and Charging Case



Image: The TF-T27 earbuds resting in their charging case, highlighting the digital battery display on the front. The TF-T27 earbuds feature a sleek design with a comfortable in-ear fit. The charging case includes a dual LED digital display to show the battery level of both the case and individual earbuds. The earbuds are equipped with touch-sensitive controls for easy operation.

3.2 Key Features

- **Active Noise Cancelling (ANC) & Environmental Noise Cancelling (ENC):** Equipped with a 13mm speaker and advanced ANC technology. Built-in 4 high-definition microphones enhance voice clarity by 75% and bass by 50%, ensuring excellent HI-FI stereo music quality and clear calls in noisy environments.
- **Dual Digital Display & 60H Playtime:** The charging case features a dual LED display for real-time

battery status of each earbud and the case. A full charge takes 1.5 hours, providing 6 hours of music playback from the earbuds and an additional 60 hours with the portable charging case.

- **Bluetooth 5.3:** Utilizes the latest Bluetooth 5.3 chip for high-quality lossless audio transmission, stable connection, lower latency, and reduced power consumption. Operates within a stable range of 10 meters.
- **Automatic Pairing & Touch Control:** Earbuds automatically pair with the last connected device upon opening the charging case. Sensitive smart touch sensors allow for easy control of music playback, calls, volume adjustment, track switching, and voice assistant activation.

4. SETUP

4.1 Initial Charging

Before first use, fully charge the earbuds and the charging case.

1. Connect the provided USB-C charging cable to the charging port on the case and the other end to a USB power adapter (not included).
2. The LED digital display on the case will show the charging progress.
3. Once fully charged, the display will indicate 100%.

60 Hours Long Lasting



Image: The charging case being charged via USB-C, illustrating the long battery life.

4.2 Pairing with Your Device

The earbuds support automatic pairing for convenience.

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for "TF-T27" in the list of available Bluetooth devices and select it to connect.
4. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.



Image: A smartphone displaying its Bluetooth settings, showing the TF-T27 earbuds connected.

Note: After the initial pairing, the earbuds will automatically connect to the last paired device when removed from the case, provided Bluetooth is enabled on your device.

5. OPERATING INSTRUCTIONS

5.1 Touch Controls

The TF-T27 earbuds feature intuitive touch controls on each earbud. The sensitive smart touch sensor allows for various functions:

Dual LED Wireless Earphone Battery Display Design

Clearly see the power and charging status of each earbud and charging box



100
Digital Power
Display of Case

L R
Digital Power
Display of Earbuds

Image: A visual guide to the touch controls on the earbuds, detailing actions for music, calls, and voice assistant.

Action	Left Earbud	Right Earbud
Play/Pause Music	Single Tap	Single Tap
Next Track	Triple Tap	Triple Tap
Previous Track	Double Tap	Double Tap
Volume Up	Long Press	-
Volume Down	-	Long Press
Answer/End Call	Single Tap	Single Tap
Reject Call	Long Press (2s)	Long Press (2s)
Activate Voice Assistant	Quadruple Tap	Quadruple Tap

Action	Left Earbud	Right Earbud
ANC/Transparency Mode Switch	Press and Hold (2s)	Press and Hold (2s)

5.2 ANC and ENC Technology

The TF-T27 earbuds feature both Active Noise Cancelling (ANC) for immersive listening and Environmental Noise Cancelling (ENC) for clear calls.

ANC and Built-in Dual ENC Microphones

Ensure excellent HI-FI stereo music quality while improving voice recognition and call quality in noisy environments

The image is a composite graphic. On the left, a man is shown in profile, smiling and looking at his smartphone, with one earbud visible in his ear. In the center, there is a frequency response graph with two waveforms. The left waveform is labeled 'Before Noise Reduction' and shows a large, irregular area under the curve, representing high noise levels. The right waveform is labeled 'After Noise Reduction' and shows a much flatter, lower-amplitude curve, indicating that noise has been significantly reduced. The x-axis of the graph is labeled 'HZ' with markers at 200, 500, 1000, and 2000. On the right side of the composite image, there is a detailed view of the earbud's internal components. Two chips are highlighted with white boxes and labels: 'ENC Environmental Noise Reduction Chip' and 'ANC Active Noise Reduction Chip'.

Image: A visual representation of how ANC and ENC technologies work within the earbuds to reduce noise and enhance voice.

- **ANC (Active Noise Cancelling):** Reduces ambient noise, allowing you to focus on your audio. To activate/deactivate ANC or switch to Transparency Mode, press and hold the touch sensor on either earbud for 2 seconds.
- **Transparency Mode:** Allows you to hear your surroundings while still enjoying your audio, useful for awareness in busy environments.
- **ENC (Environmental Noise Cancelling):** Utilizes built-in microphones to filter out background noise during calls, ensuring your voice is heard clearly by the other party. This feature is automatically active during calls.

Your browser does not support the video tag.

Video: An official product video demonstrating the features of the Transformers noise cancelling earbuds, including unboxing, ear tip options, charging case display, and Bluetooth pairing. This video highlights the ANC and call noise reduction capabilities, battery life, and touch controls.

6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your earbuds.

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents.
- **Eartips:** Remove eartips periodically and clean them with mild soap and water. Ensure they are completely dry before reattaching.
- **Charging Ports:** Keep the USB-C charging port free of dust and debris. Use a soft brush or compressed air if necessary.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.
- **Water Resistance:** The earbuds are water repellent. Avoid submerging them in water or exposing them to heavy rain. Dry them thoroughly if they get wet.



Image: The earbuds shown with water droplets, illustrating their water-repellent design.

7. TROUBLESHOOTING

If you encounter issues with your TF-T27 earbuds, try the following solutions:

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
Earbuds not pairing/connecting	<ul style="list-style-type: none"> ◦ Ensure earbuds are charged. ◦ Turn off and on Bluetooth on your device. ◦ Forget "TF-T27" from your device's Bluetooth list and re-pair. ◦ Place earbuds back in the case, close, wait 5 seconds, then open again.
No sound or low volume	<ul style="list-style-type: none"> ◦ Adjust volume on both earbuds and your device. ◦ Ensure earbuds are properly seated in your ears. ◦ Check for debris blocking the earbud speakers.
Charging case not charging	<ul style="list-style-type: none"> ◦ Check USB-C cable connection. ◦ Try a different USB power adapter or port. ◦ Ensure the charging port is clean.
ANC not working effectively	<ul style="list-style-type: none"> ◦ Ensure earbuds are properly sealed in your ear canal. Try different eartip sizes. ◦ Confirm ANC mode is activated via touch control.

8. SPECIFICATIONS

Feature	Detail
Model Name	TF-T27
Brand	ZOMBIES CAT
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.3
Bluetooth Range	10 meters (33 feet)
Noise Control	Active Noise Cancellation (ANC), Environmental Noise Cancelling (ENC)
Audio Driver Size	13mm Dynamic Driver
Battery Life (Earbuds)	Up to 6 hours
Total Playtime (with Case)	Up to 60 hours

Feature	Detail
Charging Time (Case)	Approx. 1.5 hours (Type-C)
Control Type	Touch Control
Water Resistance Level	Water Repellent
Frequency Range	20 Hz - 20,000 Hz
Item Weight	3.52 ounces
Product Dimensions	2.52 x 2.09 x 1.1 inches

9. WARRANTY AND SUPPORT

ZOMBIES CAT products are designed for reliability and performance. For warranty information and customer support, please refer to the warranty card included in your product packaging or visit the official ZOMBIES CAT website. If you experience any issues or have questions, please contact our customer service team for assistance.

Contact Information: Please refer to the contact details provided in your product's warranty documentation or on the manufacturer's official website.