

[Manuals.plus](#) /

› [Magicteam](#) /

› Magicteam Sunrise Alarm Clock User Manual (Model xin-D wood)

Magicteam xin-D wood

Magicteam Sunrise Alarm Clock User Manual

Model: xin-D wood

INTRODUCTION

The Magicteam Sunrise Alarm Clock is designed to enhance your waking and sleeping experience through natural light and sound simulations. This device combines a sunrise and sunset simulator, dual alarms with snooze, a variety of ringtones, and a customizable night light to create a comfortable environment. Please read this manual carefully to understand its functions and ensure proper use.

WHAT'S IN THE BOX

- Wake Up Light Clock
- Power Cable
- Adapter
- User Manual

PRODUCT FEATURES OVERVIEW

- **Natural Sunrise & Sunset Simulation:** Gradually brightens before alarm or dims for sleep.
- **Dual Alarms & Snooze:** Set two independent alarms with a 9-minute snooze function (up to 6 times).
- **28 Ringtones & Adjustable Volume:** Choose from a variety of natural sounds and melodies with 10 adjustable volume levels.
- **12 Colors Night Light:** Offers 12 dazzling colors, including rainbow and breathing light modes, with 0-10 level brightness adjustment.
- **Simplified Design & Memory Function:** Easy operation with 7 buttons and settings retained during power outages.

Sunrise & Sunset Simulation



Image: Front view of the Magicteam Sunrise Alarm Clock, displaying the time and various function icons.

SETUP

1. Initial Power-Up and Time Setting

1. Connect the power cable to the alarm clock and plug the adapter into a power outlet.
2. The display will light up. Follow the on-screen prompts or refer to the video below to set the current time (12H/24H format).

2. Setting Up Alarms

1. Press the 'Alarm 1' or 'Alarm 2' button to enter alarm setting mode.
2. Use the '+' and '-' buttons to adjust the hour and minute.
3. Select the alarm sound and volume level.
4. Choose the alarm frequency (Weekdays, Mon-Sat, Mon-Sun, Weekends).

Your browser does not support the video tag.

Video: Official guide demonstrating how to set up the clock time, alarms with snooze, sunset mode, and night light functions.

1. Sunrise & Sunset Simulation

The sunrise simulation begins 10 minutes before your set alarm time, gradually increasing light intensity to mimic a natural dawn. For sunset simulation, the light gradually dims over a period of 10 to 90 minutes, accompanied by decreasing sound volume, to aid in falling asleep.



Image: Visual representation of the sunrise simulation (light increasing) and sunset simulation (light decreasing) features.

2. Alarm & Snooze Function

The clock supports dual alarms. When an alarm sounds, press the 'Snooze' button to activate a 9-minute snooze. This can be repeated up to 6 times.



Image: Icons illustrating the dual alarm capability and the snooze function.

3. Ringtones & Volume Adjustment

Choose from 28 soothing ringtones, including natural sounds like bird chirping and ocean waves. The volume can be adjusted across 10 levels for both alarm and sunset modes.




Image: Graphic showing icons for different music and sound options, indicating the variety of ringtones available.

4. Night Light & Color Selection

The alarm clock features 12 distinct colors for its night light function. You can select a static color, a rainbow light mode that cycles through hues, or a breathing light mode. Brightness is adjustable from 0 to 10 levels.

12 Colors Night Light

Light Brightness: 20 Levels



Image: Display of the 12 available night light colors, demonstrating the customizable lighting options.

MAINTENANCE

To ensure the longevity and optimal performance of your Magicteam Sunrise Alarm Clock, follow these maintenance guidelines:

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the surface.
- **Placement:** Place the alarm clock on a stable, flat surface away from direct sunlight, heat sources, and moisture.
- **Power:** Always use the provided power adapter and cable. Disconnect from power during electrical storms or when unused for extended periods.
- **Internal Battery:** The built-in battery is for memory function only (retains settings during power outages) and is not user-replaceable.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Clock display is off or dim.	Not powered, brightness set too low.	Ensure power adapter is connected. Adjust display brightness using the dedicated button.
Alarm does not sound.	Alarm not activated, volume too low, incorrect alarm time.	Verify alarm is enabled. Check alarm time and volume settings.
Sunrise/Sunset simulation not working.	Feature not enabled, incorrect timer setting.	Ensure sunrise/sunset mode is activated and timer duration is set correctly.
Buttons are unresponsive.	Temporary software glitch.	Unplug the device for 30 seconds, then plug it back in to reset.

SPECIFICATIONS

Feature	Detail
Model Number	xin-D wood
Product Dimensions	2.36"D x 5.12"W x 5.9"H
Item Weight	0.44 Pounds
Power Source	Corded Electric
Voltage	5 Volts (DC)
Light Source Type	LED
Number of Light Sources	1
Control Method	Touch, Push Button
Material Type	Plastic
Color	Wood
Additional Features	Alarm, Memory Function, Snooze, Sunrise & Sunset Simulation, Timer

WARRANTY AND SUPPORT

Magicteam products are manufactured with high-quality standards. For specific warranty information, please refer to the documentation included with your purchase or contact Magicteam customer support. If you encounter any issues or have questions not covered in this manual, please reach out to our support team for assistance. Contact information for support can typically be found on the product packaging or the official Magicteam website.