

## saschedross AC Adapter

# saschedross AC Adapter Instruction Manual

Model: AC Adapter | Brand: saschedross

## 1. INTRODUCTION

This instruction manual provides essential information for the safe and effective use of your saschedross AC Adapter. This adapter is specifically designed as a replacement power supply for the GlocalMe Model U3 GLMU19A02 portable WiFi mobile hotspot. Please read this manual thoroughly before use and retain it for future reference.

## 2. SAFETY INFORMATION

- Ensure the adapter's input voltage (100-240V AC) matches your local power supply.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not attempt to disassemble or modify the adapter. This may cause electric shock or fire.
- Keep out of reach of children.
- Unplug the adapter from the power outlet when not in use for extended periods.
- If the battery of your GlocalMe device is old or depleted, it may not charge. This is not necessarily a fault of the charger. Use a voltmeter to verify charger functionality if issues arise.

## 3. PACKAGE CONTENTS

- 1 x saschedross AC Adapter (DC5V 2A)

## 4. PRODUCT OVERVIEW

The saschedross AC Adapter is a compact and reliable power supply designed for your GlocalMe U3 mobile hotspot. It features a standard 2-pin US plug and provides a stable DC5V 2A output for efficient charging.



**Image 1:** Views of the saschedross AC Adapter. The adapter measures approximately 2.7 inches in height, 1.2 inches in width (front view), and 1.6 inches in depth (side view). The front displays "AC Adapter Input: 100-240VAC 0.3A 50/60Hz" and regulatory marks. The plug is a standard 2-pin US type.

## 5. SETUP

---

1. **Verify Compatibility:** Ensure your device is the GlocalMe Model U3 GLMU19A02 or a compatible device requiring a DC5V 2A power supply with a compatible charging port.
2. **Connect to Device:** Plug the small end of the adapter's cable into the charging port of your GlocalMe U3 mobile hotspot.
3. **Connect to Power Outlet:** Insert the 2-pin plug of the AC adapter into a standard 100-240V AC wall outlet.
4. **Charging Indicator:** Your GlocalMe device should indicate that it is charging (refer to your GlocalMe U3 manual for specific charging indicators).

## 6. OPERATING INSTRUCTIONS

---

Once connected, the adapter will automatically begin supplying power to your GlocalMe U3 device. It is designed for continuous use during charging. For optimal battery health, avoid overcharging by

disconnecting the device once fully charged, though modern devices often have built-in overcharge protection.

## 7. MAINTENANCE

---

- **Cleaning:** Disconnect the adapter from the power outlet and the device before cleaning. Use a dry, soft cloth to wipe the surface. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Cable Care:** Avoid bending or crimping the cable excessively, as this can damage the internal wires.

## 8. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Device not charging.	Adapter not properly plugged in. Power outlet is not active. Device's battery is old/depleted. Device's charging port is damaged.	Ensure adapter is securely plugged into both the device and the wall outlet. Test the outlet with another device. If the device's battery is old (1-3 years), it may need replacement. Consult a technician if the charging port is damaged. Use a voltmeter to check adapter output.
Adapter feels hot.	Normal operation under load. Poor ventilation.	A slight warmth is normal. Ensure the adapter is in a well-ventilated area and not covered. If it becomes excessively hot, discontinue use and contact support.

## 9. SPECIFICATIONS

---

- **Model:** AC Adapter
- **Input:** 100-240V AC, 0.3A, 50/60Hz
- **Output:** DC 5V, 2A
- **Connector Type:** 2-Pin US Plug
- **Compatibility:** GlocalMe Model U3 GLMU19A02 Portable WiFi Mobile Hotspot
- **Color:** Black
- **Manufacturer:** Shenzhen Waweis Technology Co., Ltd

## 10. WARRANTY AND SUPPORT

---

For warranty information or technical support, please refer to the retailer's policy or contact the manufacturer directly. Keep your purchase receipt as proof of purchase.