

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [zelotes](#) /

› [zelotes Wireless Trackball Mouse User Manual](#)

zelotes F33

zelotes Wireless Trackball Mouse User Manual

Model: F33

INTRODUCTION

Thank you for purchasing the zelotes Wireless Trackball Mouse. This ergonomic mouse is designed to provide precise and comfortable cursor control, reducing strain on your wrist and arm. It features versatile connectivity options, adjustable DPI settings, and a long-lasting rechargeable battery. Please read this manual thoroughly to ensure proper use and maintenance of your device.

WHAT'S IN THE Box

- 1 x Trackball Bluetooth Wireless Mouse
- 1 x USB Receiver
- 1 x Charging Cable
- 1 x User Manual

PRODUCT OVERVIEW

Familiarize yourself with the components of your zelotes Wireless Trackball Mouse.



Image: Top-down view of the zelotes F33 Wireless Trackball Mouse, showcasing its ergonomic design, trackball, and blue LED lighting.



Image: Side view of the zelotes F33 Wireless Trackball Mouse, highlighting the trackball and button layout.

Your browser does not support the video tag.

Video: An overview of the F33 Bluetooth Trackball Mouse, demonstrating its features including rechargeable battery and DPI settings.

SETUP GUIDE

1. Charging the Mouse

The mouse comes with a built-in 730mAh rechargeable battery. For the best experience, fully charge the mouse before first use.

1. Connect the included USB charging cable to the charging port on the mouse.
2. Plug the other end of the cable into a USB power source (e.g., computer USB port, USB wall adapter).
3. The mouse can be used while charging.

16.8 Million Colors of Lighting

Vibrant lighting effects, equipped with independent buttons for freely switching light colors, enhancing the surrounding ambience. The light can be turned off if necessary.



730 mAh



Image: The zelotes F33 mouse connected via its USB charging cable, illustrating the rechargeable battery feature.

2. Wireless Connection Modes

This mouse supports two wireless connection modes: 2.4GHz USB wireless and Bluetooth (BT1, BT2). It can connect to three devices simultaneously.

2.1. 2.4GHz USB Wireless Mode

1. Locate the USB receiver stored in the mouse's bottom compartment.
2. Plug the USB receiver into an available USB port on your computer or device.
3. Turn on the mouse using the power switch on the bottom.
4. The mouse will automatically connect to the receiver.

Support To Connect Three Devices

Two through USB ports and one through Bluetooth and switch freely between them.



Image: Illustration of the mouse's ability to connect to three devices simultaneously: two via Bluetooth and one via 2.4G USB.

2.2. Bluetooth Mode (BT1 / BT2)

1. Turn on the mouse using the power switch.
2. Press the mode switch button on the bottom of the mouse to select either BT1 or BT2 mode. The corresponding indicator light will flash.
3. On your device (laptop, tablet, phone), go to Bluetooth settings and search for new devices.
4. Select "zelotes F33" (or similar name) from the list of available devices to pair.
5. Once paired, the indicator light will stop flashing and remain solid.

3. Switching Between Devices

To switch control between connected devices, simply press the mode switch button on the bottom of the mouse to cycle through 2.4G, BT1, and BT2 modes.

OPERATING INSTRUCTIONS

1. Thumb Operation

The trackball is designed for thumb operation, allowing you to move the cursor precisely without moving your wrist or arm. This ergonomic design helps reduce muscle strain during prolonged use.



Image: A hand demonstrating the thumb-operated trackball, emphasizing the ergonomic benefit of reducing wrist and arm strain.

2. Adjustable DPI Settings

The mouse features 5 adjustable DPI settings to suit your preference and task requirements:

- 800 DPI
- 1200 DPI
- 1600 DPI
- 2400 DPI
- 4800 DPI

Press the DPI button (usually located near the scroll wheel or on the side) to cycle through the settings. A higher DPI provides faster cursor movement, while a lower DPI offers more precise control.



Image: Detailed view of the mouse highlighting the anti-slip scroll wheel, forward/back buttons, and the DPI adjustment feature.

3. Forward/Back Buttons

Conveniently located on the side of the mouse, the forward and back buttons enhance efficiency for web browsing and document editing.

4. Adjustable Angle Design

The mouse features an innovative adjustable angle design with a detachable aluminum alloy base, allowing you to switch between 0-degree and 18-degree angles. This helps maintain a natural palm position for long-term comfort.

switch angles between 0° and 18° according to your needs.



Image: Comparison showing the zelotes F33 mouse with its base adjusted to 0-degree and 18-degree angles for ergonomic comfort.

5. LED Lighting

The mouse features vibrant LED lighting with 16.8 million colors. You can switch lighting colors using independent buttons. The lighting can be turned off if preferred.



Image: The zelotes F33 mouse showcasing its customizable LED lighting in different colors.

MAINTENANCE GUIDE

Regular cleaning of the trackball ensures smooth and precise movement.

Cleaning the Trackball:

1. **Step 1:** The trackball can be pushed out from the trackball socket at the bottom of the mouse.
2. **Step 2:** Remove the trackball and gently clean the trackball socket with a cotton cloth.
3. **Step 3:** Place the trackball back into the mouse to complete the cleaning process.

** If the surface of the trackball needs cleaning, gently wipe it with water and allow it to air dry. Avoid using chemical agents.*

Trackball Maintenance Guide

Disassembling and cleaning the trackball ensures smoother movement



Step 1:

The trackball can be pushed out from the trackball socket at the bottom of the mouse

Step 2:

Remove the trackball and gently clean the trackball socket with a cotton cloth.

Step 3:

Place the trackball back into the mouse to complete the cleaning process.

* If the surface of the trackball needs cleaning, gently wipe it with water and allow it to air dry. Avoid using chemical agents.

Image: Visual guide detailing the steps for disassembling and cleaning the trackball for optimal performance.

TROUBLESHOOTING

Problem	Solution
Mouse not responding (2.4GHz)	<p>Ensure the USB receiver is securely plugged into a working USB port.</p> <p>Check if the mouse is turned on.</p> <p>Ensure the mouse is in 2.4G mode (indicator light).</p> <p>Try plugging the receiver into a different USB port.</p> <p>Recharge the mouse battery.</p>

Problem	Solution
Mouse not connecting (Bluetooth)	<p>Ensure your device's Bluetooth is enabled.</p> <p>Check if the mouse is in BT1 or BT2 pairing mode (flashing indicator light).</p> <p>Forget the device in your Bluetooth settings and try pairing again.</p> <p>Recharge the mouse battery.</p>
Cursor movement is erratic or sticky	<p>Clean the trackball and its socket as described in the Maintenance section.</p> <p>Ensure the trackball is properly seated.</p>
LED lights not working or stuck	<p>Press the LED control button to cycle through modes or turn them on/off.</p> <p>Recharge the mouse battery.</p>

SPECIFICATIONS

Model: F33

Connectivity: Bluetooth 5.0/3.0 + 2.4GHz USB Receiver

DPI Settings: 800/1200/1600/2400/4800 DPI

Battery: Built-in 730mAh Lithium Ion rechargeable battery

Buttons: 8 Buttons (including trackball, scroll wheel, forward/back, DPI, mode switch)

Dimensions: 5.2 x 4 x 0.04 inches

Item Weight: 13.4 ounces

Compatibility: Win11, Win10, Win8, Win7, Mac OS, Chrome OS, Android 5.0 or higher

Special Features: Wireless, Portable, Programmable Buttons, Ergonomic Design, Rechargeable, Adjustable Angle (0°/18°), LED Lighting

Manufacturer: zelotes

Country of Origin: China

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact zelotes customer service through their official website or the retailer where the product was purchased. Keep your purchase receipt for warranty claims.

