

Philips TAT3519

Philips TAT3519 True Wireless Earbuds User Manual

Model: TAT3519

Brand: Philips

INTRODUCTION

This manual provides essential instructions for the safe and efficient use of your Philips TAT3519 True Wireless Earbuds. These earbuds are designed to deliver a high-quality audio experience with advanced features such as Noise Canceling Pro, Dynamic Bass, and clear call functionality, all within a comfortable and durable design.



Figure 1: Philips TAT3519 True Wireless Earbuds, charging case, and companion app.

SETUP

1. Unboxing and Initial Charge

Upon unboxing, ensure all components are present: the Philips TAT3519 earbuds, charging case, USB-C charging cable, and multiple sizes of ear tips. Before first use, fully charge the earbuds and the charging case.

- Place the earbuds into the charging case.
- Connect the USB-C cable to the charging port on the case and to a power source.
- The indicator light on the case will show charging status. A full charge provides up to 24 hours of total playtime (8 hours from earbuds + 16 hours from case). A 15-minute quick charge provides approximately 1 hour of playtime.

2. Bluetooth Pairing

The earbuds utilize Bluetooth v5.3 for stable connectivity.

1. Ensure the earbuds are in the charging case with the lid open.
2. Press and hold the pairing button on the charging case for approximately 5 seconds until the indicator light flashes, indicating pairing mode.
3. On your device (smartphone, tablet, computer), navigate to Bluetooth settings.
4. Select 'Philips TAT3519' from the list of available devices to connect.
5. Once connected, the indicator light on the case will stop flashing.

The earbuds support multipoint connectivity, allowing connection to two devices simultaneously for seamless switching between audio sources.

Multipoint Connectivity

Enjoy your favorite podcast on your phone while processing notifications on your computer without any annoying dips in sound.



Google Fast Pair

Bluetooth 5.3

Figure 2: Multipoint connectivity allows simultaneous connection to multiple devices.

OPERATING INSTRUCTIONS

1. Wearing the Earbuds

The compact design ensures a snug and secure fit. Four sizes of ear tips are included to help you find the most comfortable and effective seal for optimal sound and noise cancellation.

Comfort & Security

PHILIPS earbuds will stay securely in place, ensuring comfort no matter how intensely you move.



Non-slip silicone



Lightweight



Figure 3: The earbuds are designed for comfort and security during various activities.

2. Touch Controls

The earbuds feature intuitive touch controls for various functions:

- **Music Playback:** Tap to play/pause, double-tap for next track, triple-tap for previous track.
- **Calls:** Tap to answer/end a call.
- **Volume:** Adjust volume directly via touch (customizable in app).
- **Noise Control:** Switch between Noise Canceling Pro and Awareness Mode.
- **Voice Assistant:** Activate your device's voice assistant.

True Wireless Stereo

Use one earbud while conveniently storing the other in the charging case.

Simple Touch Controls




-  Voice/Call/Music
-  ANC mode
-  Awareness mode



Figure 4: Simple touch controls for various functions.

3. Noise Canceling Pro and Awareness Mode

The Adaptive Noise Canceling Pro feature actively suppresses external sounds, including wind, in real-time. For situations where you need to be aware of your surroundings, activate Awareness Mode to let ambient sounds in.

Noise Canceling Pro

Adaptive noise cancellation swiftly responds to your environment in real time.



Adaptive noise cancellation pro



Awareness mode



Figure 5: Noise Canceling Pro and Awareness Mode features.

4. Dynamic Bass

The 10mm dynamic drivers provide a rich audio experience with dynamic bass. Tap the left earbud to activate dynamic bass, enhancing low-frequency sounds even at lower volumes.

Here Comes the Bass

Rock your sounds with bigger bass.




Figure 6: Dynamic Bass technology for enhanced audio.

5. Clear Call Quality

Advanced AI algorithms and two built-in microphones work together to filter out background noise, ensuring crystal-clear call quality.

Clear Call Quality


Advanced AI algorithms and 2 built-in mics helps filter out noise, ensuring crystal-clear call quality.



AI Microphone



Voice



Noise



Figure 7: AI-enhanced microphones for clear call quality.

6. Philips Headphones App

Customize your listening experience using the PHILIPS Headphones app. You can tailor ANC modes, adjust equalizer settings, and personalize touch controls for each earbud.

PHILIPS App Control

Customize your ANC mode to suit different scenarios, and use the equalizer to fine-tune your sound.




Figure 8: Customize settings via the Philips Headphones App.

MAINTENANCE

1. Cleaning

Regularly clean your earbuds and charging case to maintain optimal performance and hygiene.

- Use a soft, dry, lint-free cloth to wipe the earbuds and charging case.
- Remove ear tips and clean them with mild soap and water, then dry thoroughly before reattaching.
- Gently clean the charging contacts on both the earbuds and the case with a dry cotton swab.

2. Storage

When not in use, store the earbuds in their charging case to protect them from dust, damage, and to ensure they remain charged.

3. Water Resistance (IPX4)

The Philips TAT3519 earbuds are IPX4-rated, meaning they are resistant to splashes and sweat from any direction. This makes them suitable for workouts and light rain. However, they are not designed for submersion in water.




Figure 9: IPX4 rating ensures resistance to splashes and sweat.

TROUBLESHOOTING

If you encounter issues with your Philips TAT3519 earbuds, refer to the following common solutions:

- **No Sound/Poor Sound Quality:** Ensure earbuds are properly seated in your ears and connected to your device. Check volume levels on both the earbuds and your device. Try different ear tip sizes for a better seal.
- **Pairing Issues:** Make sure Bluetooth is enabled on your device. Place earbuds back in the case, close the lid, then reopen and try pairing again. Ensure earbuds are charged.
- **Charging Problems:** Verify the charging cable and power source are working. Clean the charging contacts on both the earbuds and the case.
- **App Connectivity:** Ensure the Philips Headphones app is updated to the latest version. Restart the app and your device if connection issues persist.

For persistent issues, consult the full user manual available on the Philips support website or contact customer support.

SPECIFICATIONS

Feature	Detail
Model Name	TWS In-Ear Wireless Earbud
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.3
Audio Driver Type	Dynamic Driver
Audio Driver Size	10 Millimeters
Battery Life	24 Hours (8 hours earbuds + 16 hours case)
Charging Time	15 minutes for 1 hour playtime
Water Resistance Level	IPX4 (Water Resistant)
Noise Control Features	Adaptive Noise Cancellation
Control Method	Touch
Item Weight	3.2 ounces
Product Dimensions	4.29 x 3.82 x 1.5 inches
Included Components	USB-C Cable, Ear Tips

Beats All Day

Keep your music playing all day on a single 2 hour charge.



Figure 10: Battery life and fast charging capabilities.

OFFICIAL PRODUCT VIDEOS

Philips TAT3519 True Wireless Earbuds with Noise Canceling

Video 1: An overview of the Philips TAT3519 True Wireless Earbuds, highlighting their noise-canceling features.

Philips T3519/T3509 Earbuds with Noise Canceling Pro

Video 2: A detailed look at the Noise Canceling Pro feature in the Philips T3519/T3509 Earbuds.

WARRANTY AND SUPPORT

Philips products are manufactured to the highest standards and undergo rigorous quality checks. This product is covered by a limited warranty from the date of purchase. For detailed warranty information, product registration, and technical support, please visit the official Philips support website or contact your local Philips customer service center. Keep your proof of purchase for warranty claims.